





**TX DRIVER AT04881(UHF)
CIRCUIT DIAGRAM**