

DUAL TRACE
OSCILLOSCOPE
OS3600
Instruction Manual

From Serial No. 5000



Hainault Essex England

Telephone 01-500 1000

Telegrams Attenuate Ilford

Telex 263785

100MHz represents a major step forward in instrumentation technology for Gould Advance; and the OS3600 is planned to be the forerunner of a comprehensive range of oscilloscopes in the highest reaches of technology.

This dedication to providing oscilloscopes with major user benefits, both for general purpose and more specific applications, automatically results from the resources and in-house requirements of the multi-national Gould Corporation.

The OS3600 and its brother, the 60MHz OS3500 are eminently suitable for the measurement of digital circuits.


All are portable and ideal for field-service application. The wide range of amplifier and trigger bandwidths covered by these models allows a choice to be made which

is appropriate to the logic family being measured.

Production requirements can be satisfied when using the oscilloscope with their rack-mount adaptors — the logical layout of the front panels making operation simple for the semi-skilled operator. The use of the optional digital measuring unit DM3010 increases reading accuracy and speeds-up measurement time.

The more varied and stringent requirements of the laboratory can also be met from the Gould range. For applications not covered by these powerful models, there is almost certainly another instrument in the range which will "do the job".

In brief, consider Gould if your application is development, production or servicing. For the future!



DISPLAY

CRT 8 x 10cm rectangular.

EHT 16kV overall.

Graticule Internal, with 8 x 10cm divisions and 2mm sub-divisions. Continuously variable illumination.

Phosphor P31 standard, P7 option.

Beam Finder Compresses trace to within graticule area regardless of settings of the vertical and horizontal position controls. Provides pre-set brilliance level.

VERTICAL DEFLECTION

Input Channels Two identical.

Bandwidth D.C.–100MHz (–3dB), d.c. coupled.
2Hz–100MHz (–3dB) a.c. coupled.

Rise Time < 3.5ns.

Input Coupling DC-Ground-AC.

Input Impedance 1MΩ/25pF.

Deflection Coefficient 2mV/cm to 5V/cm in 11 ranges (1-2-5 sequence) with uncalibrated fine gain control giving at least 2.5:1 reduction in gain. Warning light indicates uncalibrated condition.

N.B. Bandwidth at 2mV/cm limited to 85MHz.

Accuracy ±3%.

Position Control Shift range ± 8cm.

Signal Delay Allows triggered edge to be viewed.

Max. Input Voltage 400V (DC plus AC pk).

Display modes

CH1 only.

CH2 only

CH1 and CH2 chopped (500kHz approx.).

CH1 and CH2 alternate.

CH1 and CH2 added.

Trigger View, CH1 or CH2.

Trigger View, CH1 and CH2 alternate or chopped.

Trigger View, alternate or chopped with CH1 and CH2 added.

N.B. Channels 1 and 2 can be inverted.

Trigger View Enables the main timebase trigger signal to be continuously displayed. A trigger signal derived from an external source will have a deflection coefficient of approximately 50mV/cm (0.5V/cm with ÷ 10).

HORIZONTAL AMPLIFIER

Bandwidth D.C. – 2.0MHz (–3dB).

Deflection Coefficient 50mV/cm (500 mV/cm with ÷ 10).

Accuracy ± 15%.

Input Impedance 1MΩ/25pF.

Max. Input Voltage 200V (D.C. + A.C. pk).

X-Y Operation With X input via External Trig. socket X specification as above. With X input via CH1

or CH2 sensitivity as attenuator setting but accuracy ± 15% (CH1) or ± 5% (CH2).
Phase error < 3° at 500kHz.

HORIZONTAL DEFLECTION

Display Modes Main Timebase.

Main Timebase intensified by Delayed Timebase. Delayed Timebase.

Main and Delayed Timebase simultaneously (alternate sweeps).

X-Y with CH1 or CH2 providing X-deflection input.

X-Y₁/Y₂ with line or ext. trig. socket providing X-deflection input.

| | Main Timebase (A) | Delayed Timebase(B) |
|---------------------------|---|--|
| Sweep Speeds | 50ns/cm to 0.5s/cm in 22 steps (1-2-5 sequence) | 50ns/cm to 0.5s/cm in 22 steps (1-2-5 sequence) |
| Fine Sweep Control | Uncalibrated. Reduces sweep rate by at least 2.5 times. (longest sweep approx. 12.5s). Warning light indicates uncalibrated condition. | Uncalibrated. Reduces sweep rate by at least 2.5 times. (longest sweep approx. 12.5s). Warning light indicates uncalibrated condition. |
| Expansion | X10 gives max. sweep rate of 5ns/cm. | X10 gives max. sweep rate of 5ns/cm. |
| Accuracy | ±3% (±5% with X10 expansion). | ±3% (±5% with X10 expansion). |
| Sweep Delay | A10-turn calibrated vernier control operates with reference to the main timebase setting. Control of delayed timebase start variable from 0.2cm to 10.2cm. Differential Accuracy: ±1.5% rdg. ±0.1%f.s. Jitter: <1 in 10000 of full scale. | The delayed timebase can be started by the main timebase sweep or triggered after a preset sweep display. |
| Trace Separation | Operates in A and B timebase alternate sweep mode and provides approx. ±4.0cm shift on the B sweep. | |
| Source | Trigger (A) Internal CH1 Internal CH2 Composite (CH1/CH2) External External ÷ 10 Line | Trigger (B) Internal CH1 Internal CH2 External External ÷ 10 |

Specification

Section 2

| | | |
|-------------------------|---|---|
| Slope | Pos/Neg. | Pos/Neg. |
| Coupling | DC DC(hf rej.), AC, AC (lf rej.), AC (hf rej.). | DC, AC, AC (lf rej.) |
| Modes | Manual level Auto (bright line) Single sweep | Manual level Trigger after delay |
| Sensitivity | Internal: To 10MHz<2mm (Below 50Hz sensitivity decreases when AC coupled) 10MHz-100MHz <1cm. 100MHz-150MHz 2cm typical External: To 10MHz<10mV (100mV with ÷ 10) (Below 50Hz sensitivity decreases when AC coupled). 10MHz-100MHz < 50mV (<0.5V with ÷ 10). 100MHz-150MHz <100mV (<2V with ÷ 10). Level range (internal): ±8cm. Level range (external): ±0.5V approx. (±5.0V with ÷ 10) | Internal: To 10MHz<2mm (Below 50Hz sensitivity decreases when AC coupled) 10MHz-100MHz <1cm. 100MHz-150MHz 2cm typical External: To 10MHz<10mV (100mV with ÷ 10) (Below 50Hz sensitivity decreases when AC coupled). 10MHz-100MHz < 50mV (<0.5V with ÷ 10). 100MHz-150MHz <100mV (<2V with ÷ 10). Level range (internal): ±8cm. Level range (external): ±0.5V approx. (±5.0V with ÷ 10) |
| External Trigger | Input impedance, 1MΩ/25pF. Max. input volt 200V (DC plus AC pk). | Input impedance, 1MΩ/25pF. Max input volt 200V (DC plus AC pk). |
| Trigger Hold-off | Continuously variable up to approx. one sweep length of main timebase, except for three slowest ranges. | |

CALIBRATOR

Voltage 1V ± 1%.

Frequency 1kHz approx.

Z MODULATION

Bandwidth DC to 10MHz.

Sensitivity +4V from zero gives complete blanking.

Input Impedance 2.2kΩ.

OUTPUTS

Main Timebase Ramp Output level zero to +4V from source impedance of 10kΩ.

Delayed Timebase Gate Output level +3v to zero from source impedance of 10kΩ.

SUPPLIES

Voltage 100V; 120V; 220V; 240V ± 10%.

Frequency 45-440Hz.

Consumption 80VA.

TEMPERATURE RANGE

Operating 0 to 50°C.

Operating within spec. +15°C to +35°C.

SIZE AND WEIGHT

Size 32.5cm x 18.0cm x 46.5cm (w x h x d) ex. handles and knobs.

Weight 10kg (22lb).

ACCESSORIES SUPPLIED

Handbook Pt. No. 450038

2 off 250MHz probe kits with x 10 attenuation PB14.

OPTIONAL ACCESSORIES

Viewing Hood Pt. No. 42224.

Protective Cover (soft) Pt. No. 42225.

Front Panel Cover (hard) Pt. No. 42226.

Trolleys TR4 or TR6.

Rack Mount Kit Pt. No. 42227.

3.1 SWITCHING ON

CAUTION: The OS3600 is convection cooled and must always be operated in a position such that air circulating through the bottom and side vents is not restricted.

1. Set the support/carrying handle to the required operating position. The handle is released by pulling outward both fixing bushes when it can be turned to lock in any of 5 positions.
2. Before connecting the OS3600 to the supply, check that the supply range switches are set to suit the supply voltage to be used and that the correct fuse is fitted. Note that the fuse has to be changed when switching between the 100V and 220V ranges. The switches and fuse holder are mounted on the back panel of the instrument. Do not operate the range selection switches while the OS3600 is switched on.

SAFETY: The OS3600 is designed to be used with the the frame earthed and it is important that the appropriate lead (Green/Yellow) of the supply, PL98, is connected to a suitable earth.

3. Push the POWER button and ensure that the indicator lamp lights. A trace should be obtained within 1 minute and full calibrated performance within 15 minutes.

3.2 OBTAINING A TRACE

1. To obtain a trace:
 - (a) Select CH1 on VERTICAL MODE switchbank.
 - (b) Select A on HORIZONTAL MODE switchbank.
 - (c) Select AUTO on NORMAL/AUTO/SINGLE sweep switchbank.
 - (d) Operate TRACE LOCATE button, adjust horizontal shift and CH1 shift to centralise the horizontal trace. These controls are identified by the horizontal and vertical arrows. The inner horizontal shift control should not be pulled out to select X10 expansion.
 - (e) Release TRACE LOCATE and adjust INTENSITY and FOCUS to obtain a sharply defined trace of reasonable intensity.
If the TRACE LOCATE is operated at any time a trace will appear on the screen if the timebase is running. A spot will appear if the timebase is not triggered or X-Y has been selected as the Horizontal Mode.
 - (f) If necessary, adjust TRACE ROTATION for precise alignment of trace with the centre graticule.

3.3 SETTING OF A Y CHANNEL

1. Using a coaxial lead (PL43) or suitable probe, connect a signal to CH1 or CH2 input socket and select the corresponding channel on the vertical mode switch bank.

2. (a) For direct coupling of the input signal select DC on the input coupling switch.
(b) For coupling via the internal 0.1 μ F capacitor select AC.
3. (a) Adjust the VOLTS/cm switch and vertical shift to obtain the required vertical deflection.
(b) The variable control concentric with the VOLTS/cm switch, allows continuous variation of sensitivity between the stepped ranges but when it is turned in an anticlockwise direction from its CAL position, a red warning light illuminates to show that the deflection sensitivity is no longer calibrated.
4. To locate the ground or zero volt level select GND on the input coupling switch. This open circuits the input signal and grounds the amplifier input.
5. If under this GND condition a vertical trace movement is observed on adjustment of the VOLTS/cm switch, reset the STEP BAL preset control for that channel. Access to this is through the bottom cover. This should not be done within 15 minutes of switching on.
6. Deflection which is normally positive-up may be inverted by selecting INVERT.

3.4 DUAL CHANNEL OPERATION

1. Signals applied to CH1 and CH2 inputs can be displayed simultaneously by selecting DUAL on the vertical mode switchbank. CHOP mode of beam-switching should be selected if the sweep speed is slower than about 1ms/cm and ALT (button out) at faster speeds.
2. Signals applied to CH1 and CH2 will be added algebraically onto a single trace when CH1 and CH2 are selected simultaneously. Operation of either INVERT switch will effect subtraction, displaying the difference of the two input signals.

3.5 TRIGGER VIEW OPERATION

Whatever vertical mode has been selected, pushing the TRIG VIEW button on the vertical mode switchbank will bring up another trace showing the signal in the A trigger amplifier. This applies to any trigger source except COMPOSITE, thereby giving three channel operation when the External Trigger source is selected. This facility is covered fully in section 3.8.

3.6 A TIMEBASE OPERATION

The speed of the A timebase is determined by the setting of the A TIME/cm switch. A variable TIME/cm control is fitted concentrically with the A TIME/cm switch which provides a further 3:1 (approx.) variation. When the variable control is turned in an anticlockwise direction from its switched CAL position a red warning light illuminates to show that the A timebase is no longer calibrated.

The gain of the internal X amplifier may be increased by ten times by pulling out the PULL X10 control on the inner horizontal shift control. This facility is available at all settings of the timebase but not when the X-Y mode is selected. The facility effectively increases the sweep length from 10cm to 100cm and thus allows close examination of any portion of the trace. Any portion of the increased sweep length may be selected for viewing on the display by adjusting the X shift controls (identified by horizontal arrows). The fine shift control will move the display by approximately 1cm when X10 is not selected and by 10cm in the magnified mode. A particular advantage of this facility is to increase the maximum sweep speed to 5ns/cm.

To adjust the time scale of the horizontal axis:

- (a) Set the A TIME/cm switch to the required setting.
- (b) If necessary, adjust the concentric VARIABLE.

3.7 A TRIGGER

The A timebase may be triggered by the following sources as selected from the TRIGGER COUPLING switch.

- (a) CH1 or CH2 selects the output of the appropriate amplifier (irrespective of which beam is displayed).
- (b) COMP (Composite) selects a mixture of CH1 and CH2 signals such that each channel may produce a stable trace (see note at the end of this section).
- (c) LINE: The power supply line input frequency derived internally from the supply transformer.
- (d) EXT: An external triggering source connected to the EXT A socket is selected when CH1 and CH2 are selected simultaneously. The sensitivity of this external input can be reduced 10 times by operation of EXT ÷ 10.

NB

The A LEVEL control allows selection of the triggering point on the trigger waveform and hence determination of the start of the horizontal trace.

The A TRIGGER COUPLING push button switches are used in conjunction with the Trigger Source switches to connect different networks into the trigger amplifier circuit, and are effective for all settings of the Trigger Source switches.

The four switch positions for the A TRIGGER COUPLING are able to latch independently; the functions are detailed as follows:

1. Positive/Negative (marked +/-) determines whether trigger occurs as the input signal passes the selected trigger level in a positive or negative-going direction. This allows the amplifier to trigger on positive-going leading edges when positive is selected (button out) or negative-going leading edges (button pressed in).

2. DC/AC. AC (button out) coupling is useful for wideband trigger on most signals. The DC position is also a wideband trigger mode but is most useful at very low frequencies or when the mark-space ratio of a pulse signal is likely to vary. The Y input coupling must also be set to DC for this mode to be effective on internal trigger.
3. LF REJECT. A filter is switched into circuit to reject low frequencies. This allows stable triggering on the high frequency component of complex waveforms, rejecting low frequency components such as 'hum'. Note that this switch position automatically reverts the trigger amplifier to an ac coupled mode even if dc trigger has been selected.
4. HF REJECT. A dc coupled filter is switched into circuit to reject high frequencies. Low frequency triggering may be effected from complex waveforms containing high frequency components. The cross-over frequency of both the h.f. and the l.f. filters are approximately 10kHz.

NOTE: Since the composite trigger signal is taken after the beam switch, its use is relevant only on dual trace displays in the ALT (alternate CH1 and CH2) mode. Reliable triggering is obtained only with dc trigger coupling when the two traces overlap. In this mode the level control defines a point on the display rather than a level of input signal and the relative position of the trigger point on the waveforms is altered with the Y shift controls.

The main application of this trigger mode is to display two signals of unrelated frequency. Relative phase relationship is lost when displaying signals of the same or related frequency.

Triggering control is effected as follows:

1. Select an A Trigger Source push button for the required trigger signal.
2. Set the timebase to display A sweep.
3. Set the A Trigger coupling for the desired trigger input requirements.
4. Adjust the LEVEL control so that the trace starts at the required point on the waveform. The Trigger View position may be used as a guide to trigger level to assist with this setting procedure (see next section).

3.8 TRIGGER VIEW

This switch is grouped with the Vertical Mode Y channel switches. It may be latched independently and provides an extra trace for viewing the trigger signal as it passes through the A trigger amplifier. The trigger view signal may be viewed together with one or both of the selected Y signals. Display of the trigger view only is not available. Trigger view is not available when Composite trigger is selected.

The Trigger view trace has three main functions.

- (a) It gives a guide to trigger level. The centre horizontal line of the graticule corresponds approximately to the dc level of the waveform that the trigger amplifier will select.
- (b) It enables the effectiveness of the LF Rej. and HF Reg. to be observed when filtering is required on a particular signal.
- (c) It enables a third Y channel to be available via the EXT A input socket when the EXT Trigger Source is selected. The trigger view trace must, however, be central on the screen for the instrument to be triggered in this mode. The A trigger level control operates as a Y shift signal on the trigger view trace.

When viewing signals from CH1 or CH2 the sensitivity of the Trigger view display is approximately that which is selected on the Y channel attenuator switches. The sensitivity to external trigger signal is approximately 50mV/cm (500mV/cm with EXT ÷ 10 selected). Bandwidth of this trace may be only half that of the two Y channels.

3.9 TRIGGER MODES (Normal, Auto and Single Sweep)

These are selected on the 3-way interlocking push button bank mounted above the vertical mode selection switches.

3.9.1 NORMAL

This mode is relevant for all trigger signals from dc to HF. The trace will blank in the absence of trigger signal.

3.9.2 AUTO

When AUTO is selected, the timebase will free-run in the absence of a correct trigger signal to display a bright line or unsynchronised display. When the TRIGGER LEVEL control is adjusted and/or the amplitude of the trigger signal is increased to obtain effective triggering, the timebase will revert automatically to normal operation. This free-run action in the absence of trigger helps in finding the trace and leads to ease of operation.

AUTO is useful for wideband signals above 40Hz. Operation below this frequency may cause mis-triggering since the timebase can revert periodically to its bright-line state.

3.9.3 SINGLE SWEEP

This facility is useful for observing a single event, particularly if a photographic record is required. By pressing the SINGLE SWEEP push button the NORMAL and AUTO buttons will be in the out position and the 'ARMED' l.e.d. indicator will illuminate showing that the timebase is ready to be triggered. On receipt of a trigger signal the timebase will operate and provide one single sweep only. To initiate further sweeps it is necessary to re-arm the timebase by pushing the single sweep button again. The single sweep facility is switched

out when NORMAL or AUTO are selected again. The procedure for operating the timebase to give a single sweep is as follows:

1. Apply a repetitive waveform and obtain a trace with the sweep switch in the NORMAL mode by adjusting the A LEVEL control.
2. Press SINGLE SWEEP button and triggering should then cease. The ARMED indicator should then illuminate in readiness for the trigger signal.
3. The next trigger pulse will initiate a sweep and the l.e.d. indicator will be extinguished on completion of the sweep. The timebase will not operate again until the SINGLE SWEEP button is pressed again.

3.10 A HOLD OFF

When the A HOLD OFF control is in its normal position, switched fully anticlockwise, the hold-off circuit provides sufficient delay for the timebase to recover before the start of the next sweep. When used as a variable control its main function is to provide effective triggering on some complex waveforms. In most positions of the timebase range switch the range of hold-off variation is about equivalent to the time taken for the timebase to complete one sweep. In the case where the timebase is required to be triggered on a complex waveform (e.g. a repetitive logic pulse pattern containing pulses of different widths) then the hold-off may be used to inhibit trigger until the desired period in the waveform is reached.

To trigger on complex waveforms:

1. Adjust the A TIME/cm switch such that the repetition time of the waveform pattern is within the total time of the timebase sweep. Adjust the trigger control in the normal manner until the Trigger indicator lights.
2. Adjust the HOLD-OFF control for a stable trace.

NOTE: When triggering at high frequency, any small jitter which is visible on the trace may be removed by fine adjustment of the HOLD-OFF control.

3.11 B TIMEBASE AND TRIGGER

The speed of the B Timebase is determined by the B TIME/cm switch which, with its uncalibrated variable control, has all the ranges of the A TIME/cm switch. The B TRIGGER SOURCE selection is similar to that for the A channel but does not incorporate LINE or COMP trigger. The B TRIGGER COUPLING is also similar to the A channel but without the HF Reject push button. The B trigger level control operates in a similar manner to the A LEVEL control but incorporates the B STARTS AFTER DELAY switched position at its extreme anticlockwise position.

Note that blue coding is used against all controls relevant to the operation of this second timebase.

3.12 DUAL TIMEBASE OPERATION – NORMAL DELAYED SWEEP

To examine a small period of a stable 'A' sweep:

1. Set the B TIME/cm about two ranges faster in speed than the A TIME/cm switch.
2. Rotate the B LEVEL control fully anticlockwise to the switched position, B STARTS AFTER DELAY.
3. Set the HORIZONTAL MODE switches to A INTENS by B.
4. Adjust the INTENSITY control to observe the intensified part of the trace.
5. Adjust the B TIME/cm and the delay multiplier potentiometer so that the intensified portion covers the period of interest.
6. Set the HORIZONTAL MODE switch to the B mode when the intensified section of the previous trace will be expanded to form the full trace. Make final adjustments to the DELAY control and B TIME/cm switch to examine the point of interest as required.

3.13 DUAL TIMEBASE OPERATION – GATED SWEEP

If the display exhibits annoying jitter because of a high degree of expansion or unstable trigger of the A sweep:

1. Return to the A INTENS BY B display mode.
2. Select the appropriate trigger source, slope and coupling on the B push button switches.
3. With the B LEVEL still in the B STARTS AFTER DELAY position, adjust the DELAY control so that the bright-up starts just before the edge of the waveform selected as the B trigger point.
4. Rotate the B LEVEL control clockwise and adjust for a stable trigger by observing the bright-up which will be seen to start at the first B trigger point after the set delay.
5. Select 'B' on the HORIZONTAL MODE switch.

3.14 DUAL TIMEBASE OPERATION – A & B ALTERNATE SWEEPS

This mode provides simultaneous display of the A INTENS BY B and the B traces by switching the beam between the A and B timebase signals on alternate timebase cycles. The traces may be prevented from overlapping by use of the TRACE SEPARATION control which provides up to about ± 4 cm of additional shift to the B trace only. When CH1 and CH2 are displayed in the ALT mode the trace sequence displays two A sweeps (CH1 and CH2) and the two B sweeps (CH1 and CH2).

To display A and B ALT proceed as follows:

1. Set the HORIZONTAL MODE to display A only and obtain a display using only the 'A' timebase controls.
2. Set the B TIME/cm switch two ranges faster in speed than the A TIME/cm switch.

3. Set the B LEVEL to B STARTS AFTER DELAY.
4. Press the A and B ALT switch and adjust the TRACE SEPARATION control to move the traces a reasonable distance apart. Then finally adjust the DELAY control and B TIME/cm for best display.
5. Gated sweep operation as 3.13 can be introduced if required.

3.15 X–Y MODES

Selection of X–Y mode on the HORIZONTAL MODE switch bank disables the timebase and the X deflection is derived from the selection A trigger signal. The X10 X magnification is inoperative in this mode.

1. EXT. X FUNCTION

External X operation is achieved by selection of External Trigger (simultaneous selection of CH1 and CH2) while applying the signal to the EXT. A input socket. The deflection sensitivity will be approximately 15mV/cm (150mV/cm with EXT \div 10 selected). AC or dc coupling can be achieved by selection of the relevant TRIGGER COUPLING mode and the HF or LF rejection filters can be introduced if required. This external X deflection can be displayed as a single trace display against the CH1 or CH2 input, their sum or difference as selected by the VERTICAL MODE switches. Alternatively, a dual trace display of both the CH1 and the CH2 inputs against the external X signal by selection of DUAL and CHOP modes. Note that the chop signal at approximately 500kHz may become visible on signals of the smaller orders of frequency. ALTERNATE is not applicable to X–Y display.

2. X–Y FUNCTION

The full flexibility of the two Y input channels can be utilised for a single trace X–Y display by selection of CH2 as the A TRIGGER SOURCE and CH1 as the VERTICAL MODE. It is recommended that DC trigger coupling is selected without use of the LF or HF filters. AC coupling of the X signal is best achieved, by the relevant Y channel input coupling switch. In this mode X shift is achieved by horizontal shift control and the relevant (CH2) vertical shift control is inoperative. Note that the X deflection accuracy is impaired if CH1 is selected for X and CH2 for Y.

3. Y LINE FUNCTION

By using the instrument in the X–Y mode and selecting the LINE TRIGGER SOURCE switch, a display of Y versus supply line frequency may be obtained.

3.16 ADDITIONAL FACILITIES

3.16.1 USE OF PASSIVE PROBE

An X10 passive probe may be used to extend the voltage range and increase the input impedance of the Y amplifiers. The input impedance of the instrument is $1M\Omega$ shunted by 25pF. The effective capacity of the input

lead must be added to this and the resultant impedance will sometimes load the signal source. The probe will reduce this to approximately 10pF and increase the resistance to 10MΩ. To obtain a flat frequency response it is necessary to adjust the probe capacitance to match capacitance of the oscilloscope as follows:

1. Set the VOLTS/cm switch to 20mV/cm, and the A TIME/cm switch to 0.2ms/cm.
2. Connect the probe to the 1V CAL pin.
3. Set the adjustable capacitor in the probe tip or termination, with a small screwdriver, for a square response with no overshoot or undershoot.

3.16.2 1 VOLT CAL OUTPUT

This pin provides a positive-going squarewave of 1V ±1% at approximately 1kHz. Shorting this pin to ground will give a square current waveform of 1mA in the shorting link, for current probe calibration.

3.16.3 REAR PANEL OUTPUTS

Two BNC sockets on the rear provide:

1. A ramp, a 4V positive-going sawtooth waveform, from a 10kΩ source impedance.
2. B gate, an approximately +3V level going to ground for the duration of the B sweep.

3.18.4 Z MODULATION

This 4mm socket allows dc coupled blanking to be applied to the c.r.t. The c.r.t. trace is blanked by a positive input. Negative inputs have no effect. The required amplitudes are:

- (a) +1V for visible modulation.
- (b) +4V for blanking at normal intensity.

The input impedance is approximately 2kΩ.





Fig. 1 Block Diagram



4.1 SYSTEM DESCRIPTION

The block diagram for the instrument is shown in Fig. 1. It is not intended to be a full logic diagram but details the functional points of the circuit and their inter-relation. The circuit can readily be divided into two main sections which are the Y and X deflection circuits, the latter includes the two timebases with their associated trigger systems.

4.1.1 Y CHANNELS

The switched Attenuator, Preamplifier and Trigger Amplifiers are identical for the two Y channels. CH1 differs in having external DVM shift facilities. The state of the decade steps of attenuation and amplifier gain switching are determined by the sensitivity selected. Variable gain and Invert functions are available on each Y channel; these functions being achieved by the use of 'cold' controls applied to a single Y-stage.

The Beam Switch is a fast electronic switch with the equivalent of a change-over action. It sequentially selects the CH1, CH2 or TRIGGER VIEW signals to be passed to subsequent stages. The Beam Switch is controlled by 3 way channel select logic and has the ability to display CH1 or CH2 singly, in pairs or both CH1 and CH2 with Trigger View as a 3 trace display. Trigger View may also be displayed with either Y channel. When DUAL is selected, the channel switch logic may be controlled by the CHOP oscillator in CHOP mode or by the Alternate pulses from the A timebase bistable in the ALT. mode. In the CHOP mode the beam switch is controlled by a free running oscillator switching the beam between the CH1 and CH2 (or Trigger View) signals as the X sweep progresses. In the Alternate mode the channel select logic state is changed at the end of each timebase sweep to give CH1, CH2, (and Trigger View) during successive sweeps.

When Trigger View is selected, the chosen A Trigger signal is conveyed to the Y amplifier as a deflection signal. The centre horizontal line marked on the graticule corresponds approximately to the trigger threshold voltage. Hence, the most sensitive trigger position is obtained when the trace is adjusted to this level. Note that Trigger View when selected on its own by the Y-mode switches is also displayed with the CH1 signal.

The signal from the selected channel is passed via a delay line and amplifiers to the Y deflection plates of the c.r.t. This delay allows examination of that point in the waveform which initiated the sweep because the deflecting signal reaches the Y plates after the timebase sweep has been initiated and the trace brightened.

4.1.2 A TIMEBASE OPERATION

The purpose of the timebase system is to generate a linear ramp or ramps to deflect the spot in the X direction. The trigger system initiates each sweep from the incoming or other signals, normally to obtain a stationary display of a repeated waveform. Two timebase systems are included to

allow detailed examination of a chosen section of a waveform. The A Timebase is used for simple sweeps described above and the B Timebase is introduced to provide the expansion when required.

The internal or external signal as selected is amplified by the Trigger Amplifier to drive a trigger circuit. If the timebase is ready to commence a sweep, a transition of the trigger circuit will set the 'A' Timebase bistable which in turn initiates the 'A' ramp. This signal is passed through the Sweep Select switch and X Output Amplifier to the X deflection plates of the c.r.t. At the end of the sweep, when the ramp reaches the required level the bistable is reset, returning the ramp to its original level. During the recovery period the bistable is held reset and this inhibition is maintained by the Hold Off circuit until the ramp generator is fully recovered, ready for the next sweep to commence on the next trigger pulse, when the cycle repeats.

The Bright-Up Amplifier normally holds the c.r.t. beam in the cut-off state. The output of the 'A' Bistable which allows the 'A' ramp to operate, also feeds the Bright Up Amplifier to raise the intensity of the c.r.t. spot to the level determined by the intensity control.

At the end of the sweep, this output of the bistable is reset and blanks the trace during the flyback period.

If the Y channels are being switched in the chopped mode, the output of this multivibrator is also fed to the Bright Up Amplifier to blank the trace while the Y switching transition takes place. This leaves the appearance of two separate traces for CH1 and CH2 on the screen unless the sweep speed is higher than that normally recommended for chop operation.

4.1.3 TRIGGER MODES

The trigger signal for either timebase, selected from either channel internal, external or line frequency sources, is a.c. or d.c. coupled before being fed into the trigger amplifier. This is biased by the required trigger level and the resultant output passed to the trigger circuit to be squared up by the Schmitt trigger.

In the Auto mode, the A Timebase is made to free run in the absence of a trigger signal so giving a bright line reference when, for example, the Y inputs are grounded.

In Single Sweep, the Single Shot bistable normally inhibits trigger pulses from reaching the 'A' timebase bistable. When the bistable is set manually, the next trigger pulse initiates one sweep and the Single Shot bistable is reset, preventing the timebase from sweeping again.

4.1.4 X EXPANSION

The gain of the X Output Amplifier normally allows the ramp to deflect the spot slightly more than the full 10cm of X scan. The X10 X Expansion increases this gain accordingly giving a full sweep display of greater than 100cm and the X shift control determines which 10cm portion of this appears on the screen. This facility is available on all timebase modes of display, but not on XY.

4.1.5 B TIMEBASE OPERATION

'A' INTENSIFIED BY B ('B' STARTS AFTER DELAY)

In this mode of operation the 'A' ramp is the same as for 'A' only. The 'B' timebase bistable is switched on at the required point in the 'A' sweep when the 'A' ramp reaches the potential set by the delay control and detected by the Delay Comparator. The 'B' ramp generator then runs either for its full period or until the end of the 'A' ramp, whichever occurs first, when the 'B' bistable is reset. The 'B' single shot bistable ensures that there is only one 'B' sweep during any one 'A' sweep. The output of the 'B' bistable drives the Bright Up Amplifier to brighten the 'B' portion of the 'A' trace above the normal level. This mode is used to identify a portion of the trace for subsequent expansion in the B Only mode.

'A' INTENSIFIED BY 'B' (GATED)

This mode of operation is similar to 'B starts after delay' above, but the B timebase bistable is set only on the receipt of the first B trigger signal after the end of the set delay period, thus synchronising the B sweep to the B trigger signal.

'B' ONLY

In this mode, the 'A' and 'B' timebase systems operate as for 'A Intensified by B' above, but the B sweep is selected by the X Select Switch and the trace is turned on only during the B sweep. The effect on the display is to select and expand the original intensified portion of the 'A' Intensified by 'B' trace to fill the full screen.

'A' AND 'B' ALTERNATE

This mode displays the A ramp and B ramp on alternate sweeps. The first sweep provides an A intensified by B trace, where the A sweep is selected for the X amplifier input, and the B ramp generator provides and intensified trace when the A ramp reaches the position set by the Delay control. On the next A sweep, the B ramp signal is selected to be fed to the X amplifier, and bright up is provided only during the period of B sweep. On this sweep, an additional shift signal controlled by the Trace Separation control is gated into the Y amplifier. This control allows the B trace to be separated from the A intensified trace by up to ± 4 cms.

4.1.6 X-Y MODE

When this mode is selected, the timebase system is inhibited and the Sweep Select switch connects the A Trigger signal to the X Output amplifier as the X deflection signal. Trigger source selection allows the CH1, CH2, External or Line signal to be chosen. Both Y channels may be displayed in X-Y by selecting CHOP mode.

4.1.7 DIGITAL MEASURING UNIT

This optional addition to the OS3600, the DM3010, contains a digital multimeter which can operate independently to measure d.c. voltage, current or resistance. In addition, it can operate with the OS3600 to provide digital readout of parameters displayed on the screen.

VOLTAGE MEASUREMENT

In this mode, the 0V of the DM3010 is connected to the CH1 shift voltage of the OS3600 and an additional shift voltage is generated within the DM3010, determined by the V/T control.

An electronic switch controlled by the Volt Measure Bistable selects as CH1 shift on alternate sweeps, either the normal CH1 shift signal or this additional offset signal. The effect is to produce two traces with an offset which can be set by the V/T control. The DM3010 measures this voltage and scales it according to the CH1 sensitivity chosen, to display the offset directly as a voltage.

TIME MEASUREMENT

In this mode, the 0V of the DM3010 is connected to the delay level set within the dual timebase system of the OS3600. The V/T control determines an offset voltage which is applied to an additional comparator on the A ramp. The output from the normal Delay Comparator or that from the Time Measurement comparator is selected by the Time Measurement Bistable on alternate A sweeps as the signal to initiate the B sweep. The effect is to produce delayed B sweeps at two positions along the A sweep. The time difference between them is indicated as the voltage measured by the DM3010 after automatic scaling according to the Time/cm set on the OS3600.

In the 1/Time or Frequency mode of operation, the measured and reference voltages of the DM3010 are reversed, inverting its reading for it to display the frequency equivalent to the selected time. The control logic inhibits the simultaneous selection of voltage and Time (or Frequency) measurement to avoid a confusing display. A maximum of 6 traces in the absence of time or voltage measurement may be displayed if A and B Alternate is selected, together with CH1, CH2 and Trigger View. The selection of time measurement will then provide the usual extra bright up signals and B sweeps on these six traces corresponding to the levels set up by the DELAY and V/T controls.

4.2 Y AMPLIFICATION

4.2.1 ATTENUATORS AND PRE-AMPLIFIERS

NOTE: The attenuators and pre-amplifiers in the Channel 1 (CH1) circuit are identical to those in Channel 2 (CH2). Accordingly, only CH1 is described. The component numbers in CH1 have an equivalent component in CH2. The odd numbered components off the p.c.b. are in CH1 and even numbered in CH2. On the p.c.b., 100 series numbers are CH1 and 200 series CH2.

The Y input signal is applied via the BNC socket on the front panel and routed to the AC/DC switch S11. In the DC mode, the signal passes, via R49 and C51 in parallel, to the NORMAL/GROUND switch S13, which, when released, passes the signal to the input attenuator selector S9dB. In the AC mode, the DC path via R49 is interrupted by C53.

The input attenuator consists of three fixed networks, giving attenuation ratios of 1, 10 and 100 : 1.

R71, R73, C61, C65 (X10) and R75, R77, C63, C67 (X100) form conventional wideband attenuator networks. C69, C71, C73 adjust the input capacitance on X1, X10 and X100 respectively. The remaining components control the pulse damping of the attenuators. S9dB selects the appropriate attenuator outputs, which is routed via the input protection circuit formed by D102, D104 and zener diodes D101 and D103, to the gate of f.e.t. TR101.

The current required to drive the low impedance section of the attenuator is provided by source follower TR101, and emitter follower TR103. D.C. drift in this section is corrected by a closed-loop circuit including bi-fet op-amp IC101. R79 and R85 tap off 90% of the input signal, which is applied to IC101 and compared with a fraction of the emitter follower output via R178. The error voltage thus produced is used to control the f.e.t. source current, via TR102. Thus, the gate/source voltage of TR101 is adjusted for zero d.c. offset. Pre-set R178 adjusts the fraction of the output fed back to IC101, to equalize the a.c. and d.c. gains of this section. Filter R110 and C103 ensure loop stability. R179 corrects for d.c. offset in IC101, thus acting as an attenuator balance control.

The output from TR103 drives the low impedance section of the gain switching film network R83, which provides the 1-2-5 sequence of gain steps between the X1, X10 and X100 steps of the input attenuator. R836 provides a X10 position which is used on 5V/cm only. The 2mV/cm range uses the 5mV/cm attenuator settings, but the basic amplifier gain is increased by shunting the emitter circuit of dual transistor IC102. The following table shows the complete range switch sequence.

| Input Attenuator | Film Network R83 | | | |
|------------------|------------------|------|------|----|
| | g | e/f | d | b |
| X1 | *2mV/5mV | 10mV | 20mV | |
| X10 | 50mV | 0.1V | 0.2V | |
| X100 | 0.5V | 1V | 2V | 5V |

*S9df closed

Long-tailed pair IC102 provides the first stage of amplification. R183 allows independent calibration of the 2mV range, and the frequency response on this range is adjusted by A.O.T. capacitor C107.

R180 compensates for any D.C. offset at the emitters of IC102, thus providing d.c. balance for the 2mV range switching.

The next stage is a conventional grounded base amplifier, with R182 correcting the d.c. offset to the following inverting stage. Two differential outputs are taken from TR104 and 105 collectors, one via R87 and 89 to the trigger pre-amplifier, the other via R130 and 131 to the inverting and gain control stage.

IC103 is coupled to form a balanced modulator. The circuit is basically a cascode amplifier, with the upper section split to form an emitter switch. If the voltage at pin 3 is substantially higher than at pin 8, the signal is steered to the collectors at pins 1 and 10. Reversing the voltages at pins 3 and 8 by operating S101 directs the signal to the collectors at pins 2 and 9, which feed the output in opposite phase from pins 1 and 10. With variable gain control R13 in the 'CAL' position the voltage between pins 3 and 8 is sufficient to ensure that virtually all the signal passes in the forward or reverse direction as appropriate. As R13 is turned away from the Cal position, the voltage between pins 3 and 8 is reduced, and the signal from one pair of collectors is partially offset by an inverted signal from the other pair. In this condition, switch S7 on R13 operates i.e.d. D15, to warn the operator that the channel is uncalibrated. Emitter follower TR112 provides a fixed d.c. reference, to maintain the correct mean d.c. level at pins 3 and 8. Pre-set R181, between the emitters of the lower section of IC103, sets the overall calibration of this channel.

Transistor array IC104 provides further amplification and Y shift. Sections c and d form a conventional grounded base stage. A long tailed pair formed by sections a and e convert the shift control voltage at pins 2 and 12 into a differential current signal, which is added to the main Y signal at the emitters of the grounded base stage.

To allow for the optional DVM unit on CH1, the derivation of the shift control voltage differs between the two channels. On CH2 the voltage is simply the attenuated output of shift control R12, while on CH1 it is necessary:-

- To add the shift voltage from the DVM to the manual shift voltage on alternate timebase sweeps.
- To adjust the shift sensitivity at this point to exactly 0.4 volts/cm for DVM calibration.

Pin 12 of IC104 is held at -4.7 volts by zener diode D109. Pin 2 is driven by emitter follower TR106 and the sensitivity at this point is set by pre-set R185. The control voltage from shift pot R is buffered by TR107 and sent via PLM pin 5 to the DVM, which adds a measured voltage and returns it via PLM pin 4. An analogue gate, IC106, connects the base of TR106 to the manual shift voltage, via pins 10 and 11, or manual plus DVM shift voltage via pins 8 and 9. The control pins 6 and 12 are operated via TR108 and 109 by signals from the timebase logic, at PLM pins 1 and 3, to give direct and DVM shift on alternate timebase sweeps.

The combined Y signal and shift output at pins 8 and 11 of IC104 passes on to the beam switch, along with the corresponding output from CH2, and an output from the trigger amplifier for trigger view. Each section of the beam switch is based on a transistor array similar to the

ones used for invert and gain control. The lower section of the IC forms a common emitter amplifier with frequency compensating components between emitters. Trimmer C125 serves to equalize the frequency responses of the Y channels. Beam switching is carried out by the upper common base section. If pin 8 of IC107 is at a higher voltage than pin 3, the signal passes via pins 2 and 9 R368, R369, to the common output for the 3 channels. Reversing the control signals on pins 3 and 8 steers the signal to pins 1 and 10, where it is discarded by short-circuiting into the supply rail. This system causes the standing emitter currents, as well as the required signal, to be switched from output to supply line. In all modes except ADD, only one of the three beam switches is active at any instant. However, in ADD mode, CH1 and CH2 are both active, and the common signal rail receives twice as much standing current as in other modes. To compensate for this, when PLM pin 12 goes high to select ADD mode, an emitter switch (section a and b of IC307) causes emitter follower (section d of IC307) to feed extra current into the common signal rail via R390 and 391. The emitter follower output also switches on section c of this IC via R392 and D301. This removes the current which previously passed through D310 to the trigger view beam switch emitters, thus increasing the collector current of this stage to match the combined currents of CH1 and CH2. Thus if ADD and trigger view modes are selected, the current into the common signal rail is constant during beam switching. Trigger view input to the beam switch differs slightly from CH1 and CH2, in the provision of A.O.T. resistor R1369 which adjusts trigger view gain to match the main Y channels, and d.c. offset control R382, which sets the trigger point to centre screen in trigger view.

In all multi-trace modes, the required beam switches are scanned by the beam switch logic at a sufficiently high frequency to give the appearance of a set of steady traces. The mode switches control the beam switch logic via 6 lines of PLM, according to the following truth table.

PLM pin 18 (ALT $\overline{X-Y}$) is primarily the ALTERNATE mode select line. Since the timebase is not running in X-Y mode, ALTERNATE cannot be used, and interconnections on the push buttons automatically select 'CHOP' mode.

Above lines are directly controlled by the mode switch push buttons. Two further logic lines are decoded by the beam switch logic, and passed via PLM to the timebase logic.

PLM Pin 19 (SINGLE TRACE) High on all single trace modes, i.e. CH1, CH2, or ADD.

PLM Pin 9 (CHANNEL PHASE) Relays the status of the beam switch bistable in ALTERNATE modes.

The beam switch logic is based on a $\div 2$ or $\div 3$ counter formed by IC306 and IC304a, clocked by a multivibrator IC304b and c, in chop mode, or by the end of sweep pulse from the timebase in alternate mode.

In all two trace modes, PLM pin 16 is high, and IC304a holds the \overline{KI} input of IC306 low. \overline{JI} which has no external connection is held low by an internal resistor. With \overline{JI} AND \overline{KI} both low, the first section is in "toggle" mode, i.e. Q1 and $\overline{Q1}$ reverse on each clock cycle. The second stage, which is connected as a shift register, follows these changes one cycle later, thus producing complementary $\div 2$ outputs at Q1 and Q2 (IC306 pins 2 and 15). When 3 traces are required, PLM pin 16 is low, and the inverted feedback from Q2 via IC304a to \overline{KI} produces a $\div 3$ counter with the following phases:-

| | $\emptyset 1$ | $\emptyset 2$ | $\emptyset 3$ |
|----|---------------|---------------|---------------|
| Q1 | 0 | 1 | 1 |
| Q2 | 1 | 0 | 1 |

Q1 and Q1 outputs and the control lines from PLM are decoded by the ECL gates of IC303, IC304, IC305 and drive the beam switches via their complementary outputs. To simplify the decoding of single trace modes, on

| LOGICAL FUNCTION OF CONTROL LINE | MODE | | | | | | | | |
|--|------------|-----|-----|------|-----|-----------|-----------|------------|-----------|
| | PLM PIN | CH1 | CH2 | DUAL | ADD | CH1 & T/V | CH2 & T/V | DUAL & T/V | ADD & T/V |
| ADD | 12 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 1 |
| CH1 | 13 | 1 | 0 | 0 | 0 | 1 | 0 | 0 | 0 |
| CH2 + ADD | 14 | 0 | 1 | 0 | 1 | 0 | 0 | 0 | 0 |
| 3 CHANNELS | 16 | 1 | 1 | 1 | 1 | 1 | 1 | 0 | 1 |
| T/V | 17 | 1 | 1 | 1 | 1 | 0 | 0 | 0 | 0 |

CH2 or ADD modes, the second section of IC306 is held in its reset state via PLM pin 14.

The chop oscillator is formed by IC304b and c, and positive feedback components C310 and R366. This produces, at IC304 pin 3, a square wave output of approximately 1MHz, which is used to clock the beam switch logic, and also via buffer transistor, TR311, to blank the c.r.t. beam during switching. If IC304 pin 10 is held high, the oscillator is stopped, by clamping IC304c low and the output of IC304b is controlled by the alternate pulse from the timebase, via D311 and R359. This will occur:-

- a) When "ALTERNATE" mode is selected, PLM pin 18 is high (unless X-Y mode, which automatically selects "CHOP", is used) and stops the oscillator via D305.

or

- b) in any "SINGLE TRACE" mode, D303, 307, 309 and TR307 decode the control lines on PLM pin 13, 14 and 17 to produce a logic 1 level, which stops the oscillator via D308. "SINGLE TRACE MODE" information is also passed to the timebase, via PLM pin 19.

In alternate, multi-trace modes, it is necessary for the state of IC306 Q2 output to be available to the timebase, to allow proper sequencing of the DVM system. TR308 and D306 decode PLM lines 18 and 19 to detect "alternate and not single trace" condition. The Q2 output passing through IC303a is shifted to TTL levels by TR309 and 310 and sent via PLM pin 9 to the timebase.

The combined output from the beam switch system drives a common base amplifier TR318 and 319. A shift signal from the timebase is added at this stage via R345 and 346. This signal is used to separate the traces for A and B timebase sweeps in "A and B alternate" mode.

The next stage is essentially a cascode amplifier, using TR312 and IC302, but a pre-set gain control R367 is included between common emitter and common base sections, to compensate for gain tolerances in the subsequent stages, and limit overdriving of the output module.

IC302 output is adjusted for d.c. offset by R341 and used to drive the delay line L2. R344 provides the correct terminating impedance of 180Ω for the delay line. A second output from IC302 buffered by common emitter stage TR305, 306, provides the Composite Trigger output. R356 allows for d.c. offset in this stage.

NOTE: Interconnection between "COMPOSITE TRIGGER" and "TRIGGER VIEW" push buttons prevent these two functions from being selected simultaneously, which would effectively connect the output of the trigger amplifier to its own input. If this is attempted, "COMPOSITE TRIGGER" is selected, and "TRIGGER VIEW" is suppressed.

R401-404 terminate the delay line to drive common base stage TR401 and TR402. Common emitter stage TR403 and TR404 provides a constant current output to drive the output module. R456 adjusts the common mode current into the output module, to set the mean plate potential on the c.r.t. R-C networks between TR403 and TR404 emitters provide frequency compensation to offset the capacitive load of the c.r.t. The tail current for this stage is normally derived from the -12 volt rail via D404. However, if "TRACE LOCATE" button S400 is operated, this supply is disconnected and a reduced current is provided via R452. This current allows the stage to operate but is not sufficient to drive the trace off screen.

C.R.T. driver IC471 consists of a differential shunt feedback stage with virtual earth inputs to pins 1 and 5, followed by an open collector cascode output stage. To improve the drive capability at high frequencies the shunting effect of collector supply resistors R473 and R474 is relieved by RF chokes L471 and 472. IC471 requires a +7V supply, which is provided by regulator IC472. The output of IC471 passes via stopper resistors R38 and 39 to the Y plates of the c.r.t.

4.3 TRIGGER

4.3.1 TRIGGER SELECTORS

The trigger source for Timebase A is selected by operation of one of the interlocked switches S508, S509, S510, S511 or S512.

The Composite CH1 and CH2 signals are generated at 50Ω impedance on the pre-amplifier board and fed via co-axial cables to S511, S510, S509 respectively. The line signal applied to S512 is derived from a secondary of the supply transformer and fed via pin 601 and a potential divider R665 and R664. C584 removes any unwanted high frequency interference.

The External input signal is fed via a high impedance potential divider with a division ratio of 2.5:1 consisting of R661 and R674 as the series element and R501 (connected across S504) as the parallel element. Input capacitance is set by C589 and frequency compensation by C586 and C588.

C587 acts as a capacitance pad when the EXT. $\div 10$ is selected. The output from this attenuator is conveyed to the Trigger Source switch via pt. 622, R23 and pt. 610 to S508a. When S508 is in the out position and CH1 and CH2 are both selected to give the External function, the signal passes via S508a, S509a, S510a, R578 and R662 to connect to the main trigger amplifier board coupling switches and R501. The sensitivity with S508 in this position is 50mV/cm approx. If, however, S508 is selected, a further $\div 10$ attenuator is inserted in the signal path consisting of R675, R660, C545, C546 and C547 fed via the low impedance network R622 and C548. The EXT. X sensitivity is 500mV/cm for this position of S508.

A selected trigger source, CH1, CH2, Composite, Line or EXT. is then conveyed to the trigger coupling switches via the link from pin 602 on the trigger source board to pin 507 on the main trigger amplifier board,

The switches S501, S502, S503 and S504 all operate independently. The function of the Slope switch, S501, will be described later (Section 4.3.2).

When D.C. only is selected, the signal from pin 507 is routed directly through S503, R599, S502 and S504 to the gate of TR501, the A trigger amplifier. When A.C. coupling is selected by S502, C543 is introduced into the circuit for wideband A.C. coupling. When L.F. Reject is selected by S503, a much smaller capacitor, C542, is introduced, allowing through only the high frequency components of the trigger signal.

When HF Reject is selected, R598 is introduced into the circuit with C514 to ground as a filter to reject high frequency components of the trigger signal.

The B selection and coupling circuitry is similar to that described above for A and is based on S513, S514, S515, S505, S506 and S507. This timebase does not have facilities for Line source, Composite source or A.C. LF rejection coupling.

4.3.2 TRIGGER AMPLIFIERS

The input stage of the amplifier circuit is formed by f.e.t.'s TR501 and TR502. Resistor R501 determines the input impedance of approximately 470k ohms.

Field effect transistors TR501/TR502 are a dual matched pair in a single package. TR501 acts as a source follower and TR502 acts as a constant current load which provides drift correction. R504 and R505 define the source current in each f.e.t., and R506 is an HF stopper.

The f.e.t. stage drives TR503, an emitter follower with two output paths; one from its emitter to the emitter of TR505, via R515 and out to the External X amplifier circuit, the other via R529 to the base of TR507, in the trigger amplifier.

For X-Y operation, the output passes through R515 to the emitter of the common base connected amplifier TR505. The output from the collector of this transistor is applied to emitter follower TR506. Resistors R510, R511 and R512 provide the emitter load, with shunt feedback from the junction of these resistors back to the base of TR505. The circuit gain is this approximately 2 and adjusted by R512. Resistor R514 provides an offset current into the base of TR505, to bias the output voltage at TR506 emitter at 2.0V. Capacitor C506 connected across the base collector junction of TR506 provides a high frequency roll-off to compensate for the delay introduced by the 'Y' Amplifier delay line. The value of this capacitor is determined during initial testing of the oscilloscope. The output from the emitter of TR506 is passed to the X-Y output at PLP pin 10 via R516.

When the X-Y function is not in use, an inhibit signal is applied from socket PLP pin 3. This is in the form of a -12V level applied through R517 to the cathode of D502. This diode is then made to conduct and draws current from R510, R511 and potentiometer R512, thus cutting off TR505 and preventing any output to the X amplifier circuit. With TR505 cut off, the tail current of TR503 will now flow through R515 and R513 in parallel with R507.

To prevent the trigger amplifier TR507/TR508 drawing current from R515 and affecting the X-Y output when X-Y is in operation, an additional inhibit signal of +12V is applied at socket PLP pin 1. This is passed via zener diode D503 and R534 to the emitters of TR507 and TR508, cutting off this stage.

During normal trigger operation, the output from TR503 emitter is applied to the base of TR507. This transistor forms a differential amplifier with TR508. The base bias for TR508 (-0.8V) is provided by the network R524, diode-connected TR504 and R525. This voltage is adjusted by potentiometers R520 and R522, via R521 and R523 respectively. R522 is the main Trigger level control, R520 provides additional bias to balance the amplifier when the A Trig Level control, R522, is central. The gain of the stage is controlled by R528, with frequency compensation provided by R527 and C509, C508.

Outputs from the collectors of TR507 and TR508 are applied to the emitter followers TR511 and TR512 via R548 and R549 respectively. These emitter followers perform the dual purpose of driving the trigger amplifier and the Trigger View signal to the Y amplifier via PLR and the matching resistors R550 and R551. When Trigger View is not required, the signal is prevented from feeding the Y amplifier by the diode gate D516 and D517. The gate is controlled by S713 on the timebase circuit via D514. The normal trigger signal from the emitter followers TR511 and TR512 is fed to the rest of the trigger amplifier via R538 and R539 to the bases of TR509 and TR510. The gain of this stage is determined by the values of R540 and R541 and frequency compensation is provided by C518.

Transistor TR509 feeds the base of TR513 via R558, and TR510 feeds the base of TR514 via R559. This differential amplifier forms the final amplifier stage prior to the Schmitt trigger input.

Circuit gain is determined by the values of emitter resistors R562 and R563, and frequency compensation is provided by R556 and C516. The common tail current flows through R561 and R536 to the -12V rail, and C517 decouples the junction of these resistors at HF.

Transistor TR514 is biased such that its collector is at 3.9V, which is the threshold voltage of an Emitter Coupled Logic (ECL) input signal. A 'high' normally being at 4.4V and a 'low' at 3.4V.

The ECL line receiver package, IC501, is used as the

Schmitt trigger circuit. The signal input is applied to the non-inverting input pin 13 and positive feedback is applied from pin 14 to pin 12 via R569 and C522. R567 is connected to the ECL bias voltage at pin 11 which sits at the logic threshold, (3.9V). The Schmitt sensitivity is determined by the ratio of R567 and R569 and the output signal at pin 14. High frequency performance is improved by the network R557 and C521.

The non-inverted output from pin 15 drives the stage IC501a via its inverting input and IC501b via its non-inverting input. IC501a is used to detect positive trigger slopes and IC501b to detect negative trigger slopes.

When the Trigger Slope switch S501 is set for negative slope, a positive bias is applied to the network R572, R573, R575 and R576, to enable IC501b and cut off IC501a, inverting the trigger output signal. Conversely, for positive slope, this bias is removed, IC501a is enabled, IC501b is cut off and the non-inverted trigger signal is transmitted.

The trigger amplifier of the B timebase is similar to that described above for A, but does not have the XY or trigger view output stages. The input stage is formed by the source follower TR520 and emitter follower TR522. This drives the amplifier TR524, TR525 for comparison against the trigger level defined by R612 with preset R610 for balance. Subsequently, differential amplifier stages TR526, TR527 and TR528; TR529 are used to drive the Schmitt trigger IC502c with slope selection as IC501.

4.3.3 TRIGGER DETECTOR

The buffered output from the A trigger circuit is coupled by C536 into the trigger detector circuit comprising TR515, TR516, TR517 and TR518. The purpose of this circuit is to detect the presence of trigger signals driving the l.e.d. indicator and controlling the timebase in the Auto mode. The square or pulsed waveform from IC501 is differentiated by C536, amplified by TR515 and fed by C533 to a diode detector circuit comprising D508 and D509, with bias provided by D510.

Each resultant negative transition is coupled via D508 into the monostable TR516 and TR517. In the absence of input, both transistors are cut off. A single trigger signal or transition will turn TR516 and TR517 on for a period of approximately 30ms determined by C531, C532 and R587. The output from the emitter of TR517 turns on for a period of approx. 30ms determined by C531, C532 and R587. The output from the emitter of TR517 turns on TR518 to energise the indicator D515. A continual succession of trigger signals above approx. 40Hz will hold the monostable in the on state and the indicator will be energised continuously. The additional output from the collector of TR518 is taken via R595 and PLP pin 3 to the timebase circuit. This is normally near to 0V in the absence of trigger signals but goes low in the presence of trigger signals to inhibit the timebase from free-running.

4.4 TIMEBASE

4.4.1 A RAMP GENERATOR

Each ramp generator is controlled by a bistable which is turned on by a valid trigger or other signal to start a sweep, and turned off at the end of each sweep to await the next start. The bistable for the A timebase is IC701b.

The triggering input, from IC501 on the trigger board, is applied to the Clock input of IC701b at pin 11. If the D input of IC701b is assumed to be high at this time, controlled by IC702c output at pin 15, then the Q output at pin 15 of IC701b will go high and \bar{Q} at pin 14 low on receipt of a positive edge clock pulse.

The Q and \bar{Q} outputs of IC701b feed the bases of transistors TR702 and TR704 connected as a long-tailed differential amplifier. With the Q output high, TR702 conducts and TR704 is turned off.

The principal operation of the ramp generator is the charging of a selected timing capacitor from a constant current source TR714. The linear voltage rise is fed into a buffer amplifier and before a ramp starts, a feedback loop stabilises this output to ground by drawing off a current via the fly back transistor TR710 which equates the charge current.

In detail, TR702 collector is coupled via R736 to the emitter of the fly-back transistor TR710. When TR702 is turned on, TR710 is cut off and TR702 draws its emitter current from R749. D713 and Zener diode D712 limit the reverse bias on the base emitter junction of TR710. As TR710 is turned off, the constant current source provided by TR714 starts to charge the timing capacitors C721 and C722 with C719 and C720 if selected. Selection of the timing capacitor and resistor value RT from the resistor network RN is done by the A TIME/CM switch S3. The timing capacitors C719 or C720 are brought into circuit by transistors IC711d and IC711c for the following conditions:- C719 is in circuit when a low timebase velocity range is selected by S3. In this position, S3 provides a positive voltage from the +12V line to the base of IC711d via resistor R753, which saturates IC711d and so connects one end of C719 to ground. In a similar manner, C720 is selected on the mid range timebase velocities, S3 now providing a positive voltage via R754 to the base of IC711c. To ensure that they are cut off when not selected, the bases of IC711d and IC711c are held at approx -4V by R742, R746 and R754, R747 respectively. R758, R759 and D717, D719 are used to 'bootstrap' the output ramp to the collectors of the transistors IC711d and IC711c, ensuring that they do not drop significantly below 0V when the timebase ramp voltage is near zero. Resistor R776 and capacitor C714 at the base of IC711d remove any charge remaining in C719 when switching to a higher velocity range.

The trimmer capacitor C722 allows calibration of the high velocity ranges when neither C719 nor C720 are selected. Note that on the mid ranges when IC711c is on and IC711d is off, C719 remains in series with C720 and their values are chosen accordingly.

The charging current from TR714 is determined by the value of RT, as selected by S3 its emitter voltage with respect to the +24V supply. The base voltage is fed from the emitter follower TR715 as determined by the potential divider network R765, R766, R780, R760 and R769 and potentiometer R767. R767 is used as the main TIME/cm calibration adjustment to set the timing currents accurately for the mid-timebase ranges when the close tolerance capacitor C720 is in circuit. TR713 is normally off but, like IC711d, it is turned on when the low velocity ranges are selected and R761 is effective to allow calibration of these ranges. D716 is reverse biased when these ranges are not selected so that R761 has no effect on calibration.

The variable sweep speed control R7 operates via the components R768, D714, D715 and TR716. In the calibrated position, the wiper of the control connects pin 4 directly to pin 7, and the associated switch S5 is open. TR716 simply acts as an emitter follower defining current in R7 but not presenting an appreciable load to the sweep rate control level at the emitter of TR715. As R7 is turned away from its end stop, S5 closes to energise the UNCAL indicator D12. After a small movement along the track, the voltage between pins 4 and 7 will exceed the necessary drop across D714 and D715 and current will be drawn through R768. Further movement of the Variable control R7 will cause the current in R768 to exceed that in R764. TR715 will be cut off and the control voltage on the base of TR714 will rise under the control of R7, reducing the voltage across RT and hence reducing the charging current to slow the ramp rate as required.

The ramp voltage is monitored at the gate of f.e.t. TR717 acting as a source follower. TR718, in the same package, provides a constant current source for TR717. As the two f.e.t.'s are almost identical and the gate of TR718 is strapped to its source, TR717 is biased automatically for near zero gate-to-source voltage. The ramp output from TR717 is further buffered by emitter followers TR719 and TR720. The output from TR719 is coupled via D719 and applied to the X selector switch IC709b and via R778 to the Ramp Output socket on the rear panel. This signal is also applied via the divider network R729, R711 and R713 to the gate IC702a. When the cathode of D719 reaches approx. +4.4V this gate switches to apply a clear signal to the A timebase bistable IC701b and complete the sweep.

With IC701b reset, TR702 is cut off and TR704 conducts. TR710 conducts as a constant current source to exceed the charging current from TR714 and the ramp voltage returns rapidly toward 0V, i.e. 'flyback' occurs. When the ramp output from TR720 reaches this level, TR723 comes into conduction and its collector current diverts emitter current from TR710. TR722 and TR723 form a comparator and the loop stabilises the ramp voltage ready to start the next sweep. TR711 conducts only as the ramp reaches its 0V level on fast flyback rates and prevents overshoot of the start point. The

ramp output from TR717 is coupled to emitter followers TR719 and TR720 which are used to buffer the ramp output to the X amplifier and delay comparators IC710a and 710b.

4.4.2 HOLD-OFF

The hold-off circuitry is provided to enable the ramp generator to recover fully at the end of its sweep before another sweep commences. It also allows the 'X' Amplifier to stabilise. The period during which the timebase is prevented from triggering can be varied by operation of the HOLD-OFF control. This allows stable triggering from complex waveforms.

The hold-off system operates in a similar manner to the timebase ramp generator. It contains two constant current sources. TR571 charges one of the hold-off capacitors C710, C712, C713 as selected by the A TIME/cm switch S3. The other constant current source TR721 acts as a flyback transistor to discharge the hold-off capacitors. The voltage on the selected hold-off capacitor turns on TR712 when the potential drops below about 3.6V. The emitter current from the emitter follower TR719 flows through D719 and the potential divider R748 and R770. When the ramp output is rising and reaches about 2V (Approx. ½ ramp period) the potential across the junction of R748 and R770 exceeds the forward potential of D710 and the emitter voltage of TR721, thus turning the flyback source off. This enables the current source TR751 to charge the selected timing capacitor. C712 and C713 are selected by IC711a and IC711b in a similar manner to the timebase capacitors C719 and C720 described previously.

As the hold-off potential goes positive, TR712 is cut off and a logic low is applied to the OR gate IC702c. Positive feedback is applied via R727 and C706 so that a rapid transition occurs at the output of this gate.

The output of IC702c is applied to the NOR gate IC702d at pin 13. Because the other input of this gate, at pin 12, is the Q output of IC701b, which is high during positive excursions of the timebase ramp, then a logic high is fed from pin 15 of IC702d to the D input of IC701b. The Q output of bistable IC701b therefore remains high, since further clock pulses cannot change its state.

When the ramp has reached its maximum positive (4.4V) level and reset occurs as previously described, the flyback commences. As the flyback continues the ramp output voltage falls and at approximately 2V, diode D710, controlled by the voltage at the junction of R748 and R770 cuts off. This allows TR721 to conduct and discharge the hold-off capacitors via R737.

Variable hold-off is achieved by varying the emitter current of TR721 from the HOLD-OFF control on the trigger p.c.b. via R741. This controls the ramp amplitude seen at the base of TR712 and so varies the hold-off time. Delay periods of up to one timebase period can be achieved.

As a result of the hold off flyback transistor being switched off when the timebase ramp amplitude exceeds 2V, charging of the hold off capacitors C710, C712 and C713 continues until about half of the ramp flyback period has occurred. When the ramp voltage has dropped below 2V the flyback current source conducts again discharging the hold-off capacitors. The discharge period continues well beyond the ramp flyback period until the voltage on the hold-off capacitor has dropped sufficiently to turn on TR712. When the main timebase bistable IC701b switches over driving the Q output low at pin 15 at the commencement of the timebase flyback period, the output of the gate IC702d pin 15 drops low. This puts a low on pin 10 of IC701b, hence further clock pulses do not change the state of the bistable. At the end of the hold off period when TR712 has turned on, the output of IC702d pin 15 is brought high again via the signal from IC702c. This results in a high being applied to pin 10 of IC701b in readiness for the next trigger signal to start another ramp. A negative going signal edge from IC702d pin 9 to capacitor C773 provides positive feedback into the hold off circuit for a rapid switch off.

At the end of each sweep, the emitter of TR703 goes positive and this transistor is coupled through D711, R731 and C763 to produce a positive 'spike' at the input to gate IC707c. This inverts the impulse to generate a narrow low going pulse on its output which is distributed as necessary to switch control circuitry in the various Alternate modes. IC707a is normally enabled except in CHOP mode and drives this pulse to inverting gate IC707b, which provides a negative going edge to the Y-amplifier via Pt. 715 to operate the beam switch.

4.4.3 AUTO, SINGLE SWEEP AND X-Y

The timebase modes, AUTO, NORMAL and SINGLE, sweep are selected by the three interlocking switches, S707, S706 and S708 respectively. Whereas in the NORMAL mode no timebase ramp will occur in the absence of trigger; in the AUTO mode the timebase free runs and produces a bright line trace.

When AUTO function is selected by depressing S707, the ground is removed from the Auto Bright Line input at PLS pin 4. This allows the junction between R720 and C705 to follow the control signal from the trigger detector circuit from PLS pin 4. In absence of trigger, D706 is cut off. D707 and D749 have their anodes taken to the +12V rail via R728 and when IC702c output at pin 14 is low, current will flow from R728 to ground via R724. This causes a logic low to appear on the preset input pin 12 of IC701b via diode D707 and R719.

At the end of the hold-off period, pin 14 of IC702c goes high. The current flowing in R728 will then pull the Preset input of IC701b high via D707. The Q output of IC701b is therefore driven high and the ramp sweep restarts without any trigger applied. When a trigger signal occurs, the trigger detector operates. TR518 on the trigger circuit turns on the 'TRIGGER' l.e.d. and also

removes current from R728 via D706 and R720. This has the effect of making the preset input of IC701b go low. The timebase will only sweep in this condition when a trigger signal clocks the bistable IC701b.

In the NORMAL mode of operation, the ground provided by S707 prevents the Preset input of IC701b from rising, by returning the current in R728 to ground via D706 and R720.

When the SINGLE SWEEP button S708 is depressed, both S706, the NORMAL switch, and S707, the AUTO switch, are released. This inhibits both normal and auto triggering of the timebase. S708 operates as a spring return action switch without any latch action. Each depression of S708 will cause the timebase to be armed in readiness for a trigger signal, which when given will cause the timebase to make one sweep and then reset.

With S708 in the released position, C701 charges via R701 from the +5V rail. On pressing S708, this charge is applied to the Preset input of IC701a at pin 5, setting the outputs to Q high and \bar{Q} low. The Q output at pin 2 of IC701a is applied to the emitter of TR701. Because the base of this transistor is held at approximately 3.3V by the network D702, R710 and R712, it conducts and passes current to the ARMED l.e.d. via R709 and PLV 12. The low \bar{Q} output at IC701a pin 3 is applied via R703 to pin 4 of OR-gate IC702a. The other input to this gate is applied from the reset line to pin 5 which is normally low except at ramp reset, therefore the output at pin 2 will be low to the clear input of IC701b.

IC701b therefore awaits a trigger pulse to initiate a ramp with the single shot ARMED l.e.d. illuminated. When this occurs and the timebase has completed the ramp, IC701b changes its state to Q low (pin 15) and \bar{Q} high (pin 14) in the normal way to commence the fly-back. This action then clocks a logic low to IC701a since the D input is permanently low on pin 7. The Q output at pin 2 of IC701a then drops low and the ARMED l.e.d. is turned off. IC701b is then held reset by IC701a. \bar{Q} signal at pin 3 via the gate IC702a. The bistable IC701a can then be prepared for another sweep by pressing the 'ARM' button S708 once again. R703 and C775 form a low pass filter to prevent narrow spikes from IC701a resetting IC701b if S708 is pressed during a sweep.

When the timebase is in the AUTO or NORMAL modes, IC701a is held preset by diode D701, thus disabling the single shot function.

It is necessary to inhibit the 'A' ramp generator during the X-Y mode of operation. When the X-Y switch S705 is depressed, +12V is applied to the anode of D705 via R716. This voltage is clamped to +5V by D705 and is applied via R714 and D704 to pin 2 of IC702a. This pin is directly coupled to the Clear input of IC701b, the timebase bistable, and holds this circuit in a permanent reset state.

4.4.4 DUAL TIMEBASE OPERATION

In the 'A Intensified by B', 'B' only and 'A & B Alternate' modes, the B timebase is initiated at a selected point during the A timebase sweep as set by the DELAY control. The B timebase may be initiated in two different ways, the simplest mode being B STARTS AFTER DELAY, which is set by S516 on the B TRIGGER LEVEL control, R612. In this mode, the setting on the DELAY control vernier determines directly the start of the B ramp. The B timebase may also be used in the 'B GATED' mode where the B timebase is merely armed on reaching the DELAY setting and awaits a trigger pulse from the B trigger amplifier before a B sweep commences. The delay period is generated as a portion of the A sweep period to the delay comparator circuit.

The A ramp is fed from the emitter of TR720 to the dual comparator IC710a and IC710b, via R897 and R898 to pins 12 and 5 respectively. The bistable IC705b is only functional if Time or 1/Time measurement is required while the DVM option DM3010 is fitted. Normally this bistable is held preset by a shorting plug on PLU pin 6 holding pin 10 of IC705b at 0V. This allows only the comparator IC710b to function since IC710a strobe is held low on pin 9. The DELAY control R5 on the front panel has exactly 4V set across it by the resistors R916, R917 and preset control R915. R917 has only about 80mV across it to act as a back-off voltage for the DELAY control to allow for various offsets in the comparators and timebase ramp generator.

The voltage at the wiper of R5 is fed to the unity gain buffer IC706 at pin 3. The output at pin 6 is then fed to the inverting input of the comparator IC710b at pin 13. When the timebase ramp has risen to the potential set by the DELAY control, the output of IC710b rises quickly to about +3.0V. R887 is used to provide some positive feedback which allows the comparator to snap over cleanly when the desired level is reached. The output from IC701b pin 1 turns off transistor TR746 by diverting the emitter current in R893 to D745 and R895.

The collector of TR746 is only allowed to rise to +4.4V (ECL LOGIC HIGH) by the action of R890. The components D744, D745, C754, C755, R894 and R895 are relevant only when the DM3010 option is used. They introduce a delay of only a few nanoseconds to compensate for any differences in group delay between the two comparators. Section 4.7 covers the operation with DM3010 in full detail.

If the B STARTS AFTER DELAY condition is selected on the B TRIGGER LEVEL control (R612 and S516), then the input on pin 7 of IC703b is low. IC713d is switched off, providing a high input to gates IC703c and IC703d on pins 11 and 12 respectively. Since gate IC703c is turned on, its output at pin 14 will stay low and cannot pass trigger signals from the B Trigger Amplifier. The output of gate IC703d pin 9 goes high, which is applied to the D input of the B timebase bistable, IC704a, at pin 7. The positive signal edge from

the comparator IC710b via TR746 then passes through the two NOR gates IC703a and IC703b to emerge at the IC703b pin 3 and provide a positive edge trigger to clock the bistable IC704a at pin 6. This action initiates the B ramp.

When the B trigger amplifier is to be used in the 'B Gated' mode S516 on the Trigger p.c.b. is closed, applying a high to IC703b pin 7 and at the same time turning on transistor IC713d. This puts a low to the inputs of gates IC703c (pin 11) and IC703d (pin 12). Any trigger pulses from the B Trigger Amplifier will now pass through gate IC703c, becoming inverted as they do so. The output of IC703c pin 14 is fed to the clock input of IC704a pin 6. However, since the D input is low (pin 7) and the bistable IC704a is reset, its state remains unchanged. When the comparator output IC710b rises as the ramp reaches the voltage preset by the DELAY control, the gate IC703d pin 13 is driven high via TR746. This raises the D input of IC704a high and enables the bistable to be clocked upon receipt of a trigger pulse and so start the B ramp generator.

Note that the gate IC703c inverts the trigger pulses and in order for the trigger to have the correct polarity, the +/- TRIGGER SLOPE switch, S505, on the Trigger p.c.b. is wired in a reverse fashion with respect to the A Trigger Amplifier.

4.4.5 B RAMP GENERATOR

The B ramp generation system with its start point stabilisation is very similar to that already described for the A Timebase. It does not include Hold-Off or Auto facilities so the circuit description will only be described briefly in this section, unless it is significantly different. When the bistable IC704a changes state to initiate the B ramp, the Q output goes high (pin 2) and \bar{Q} (pin 3) goes low. These two outputs are directly coupled to the bases of transistors TR724 and TR725. TR724 is therefore driven on and TR725 off. TR724 is coupled via R801 to the emitter of the flyback transistor TR727. This allows TR724 to draw the emitter current from TR727, thus turning it off. The constant current charging transistor TR738 then charges the timing capacitors C742, C746, C740 and trimmer C741 as selected by transistors IC713a and IC713b under the control of the B Time/cm switch S4. This switch also selects the current defining resistor RT in the constant current generator TR738, TR739 and TR740.

The potential at the timing capacitors is buffered by the source follower TR736 and emitter follower TR735 to provide the B ramp output.

The ramp output from TR735 is applied to pin 7 of OR-gate IC702 via R793 and HF compensation network R792, C735. These components together with R791 determine the switching point of IC702b and ensure it occurs at the 4.4V maximum excursion of the ramp. When this occurs, the output of IC702b goes high and applies this logic level to the Clear input of IC704a at

pin 4. The Q and \bar{Q} logic levels on this bistable are then reversed, switching the conduction states of TR724 and TR725, causing the ramp to reset.

During the waiting period before the B ramp commences, the output from TR735 is held at 0V by the action of TR733 which acts as a sweep start stabilization control. The emitter of TR733 is connected to 0V via the low value resistor R820. When the emitter of TR735 reaches 0V at the end of the flyback period, some of the current through R825 flows in diode D735 and thus turns on TR733. TR733 then controls the current in the flyback current source, TR727, at its emitter such that the voltage at the emitter of TR735 is maintained at 0V. TR734 in the emitter circuit of TR735 functions as a double diode to compensate for the voltage drops across D735 and the base-emitter of TR733. R824, R821 and C749 prevent overshoot on flyback in a similar manner to R756, R757 and C716 in the A ramp generator circuit.

When the timebase bistable IC704a is reset, the \bar{Q} output at pin 3 goes high. This then clocks the single-shot bistable IC704b at pin 11. The \bar{Q} output of IC704b therefore goes high because the D input at pin 10 is connected to ground. The high at \bar{Q} is fed to the Clear input of IC704a at pin 4 and this prevents further triggering of the 'B' bistable.

When the 'A' ramp has completed its sweep, the 'A' timebase bistable IC701b has a logic high at the \bar{Q} output on pin 14. This high is applied to the Preset input of IC704b at pin 12, reverting the \bar{Q} output at pin 14 to a logic low which is applied to the Clear input of IC704a, enabling this bistable to switch again on the next trigger pulse.

If 'A' only is selected, the 'B' timebase must be inhibited. This is accomplished by applying +5V to the anode of D734 when the 'A' only switch (S701) is depressed. This logic high holds the Clear input of IC704a at pin 4 high and therefore inhibits the 'B' bistable.

4.4.6 X MODE SELECTION

The three way analogue switch IC709 is energised as necessary to select the A ramp signal, the B ramp signal or the X-Y signal to drive the X amplifier. Selection of A or B is derived from the state of bistable IC708a and applied to IC709 via transistors IC712b, IC712c.

When A only is selected by S701, D721 conducts via R852. D722 clamps the Clear input of IC708a to 0V. With Q low and \bar{Q} high, IC712c is turned off and IC712b is turned on. IC709b is energised, selecting the 'A' ramp. Similarly when 'A Intensified by B' is selected by S702, 0V is applied directly to the Clear input of IC708a with the same result.

When 'B' Only is selected by S703, 0V is applied directly to the preset of IC708a. Q is high, \bar{Q} is low. IC712c is turned on and IC712b is turned off, enabling IC709c to select the 'B' ramp.

When 'A and B Alternate' is selected by S704, the Preset and Clear inputs to IC708a are both high and this bistable is clocked at the end of each A sweep by the signal from IC707c. In all single trace Y modes, the preset of IC708b is low and the Q output provides a high input to the J and K inputs of IC708a. The latter then switches state at the end of each A sweep, selecting 'A' and 'B' ramp signals on alternate sweeps.

When a multiple trace mode is selected, e.g. ALT or CHOP, the voltage at PLT 19 drops low and TR748 is turned off, removing the Preset from IC708b. This now forms a $\div 4$ circuit with IC708a and the X selection switches are driven to allow two consecutive 'A' sweeps followed by two consecutive 'B' sweeps. Meanwhile the beam switch in the Y amplifier chain is alternating between CH1 and CH2 to provide the required 4 trace display.

When 'A and B Alternate' is selected, trace separation is required. Operation of S704 removes the bias via R874 holding Transistor IC712a on. This is now switched in parallel with IC712b under the control of IC708a to enable IC709a on each 'B' displayed sweep. The bias set by the TRACE SEPARATION control R4 is applied to IC712c to modify the differential output current from the transistor pair IC712c and IC712d. These signals are fed into the Y signal path.

In the X-Y mode S705 is operated. IC709d is enabled directly to select for X deflection the X-Y signal from the A Trigger Amplifier. Current in R853 via D725 and D726 ensures that both the Preset and Clear signals are applied to IC708a. Q and \bar{Q} are both high, inhibiting both the 'A' and 'B' signals.

4.5 X OUTPUT AMPLIFIER

The ramp input from the timebase via IC709 is applied to the commoned base connections of TR810 and TR812 via R929. These transistors, with TR809 and TR811 form two long-tailed pairs. Transistors TR810/TR809 forming one, TR812/TR811 forming the other.

The opposite commoned base connection of TR811 and TR809 is fed with the X shift voltage from the emitter follower TR815 via R979. The base of the emitter follower is connected to R965 which forms a potential divider with R967 and R966 operated by the COARSE and FINE shift controls. Long-tailed pair TR810/TR809 has a 'tail' circuit comprising R962, R963, R961 and 'Set X1 gain' pre-set potentiometer R960. The 'tail' circuit of TR812/TR811 comprises R959, R958, R956 and 'Set X10' pre-set potentiometer R957. Resistor R928 and C831 across these last two resistors provide HF peaking.

The Long-tailed pair TR812/TR811 have the 'tail' current provided by the constant current source, TR813. The voltage at the base of this transistor is derived from the +24V rail by the potential divider R968 and R970. TR813 emitter is connected to the anodes of

D812 and D813 via R969 and 'adjust on test' component R971 in parallel with it. The cathode of D812 is taken to -12V when S705, the X-Y mode switch, is operated. Similarly, the cathode of D813 is returned to the same potential when the X10 MAGNIFICATION switch is operated. When either diode is taken to -12V the emitter of TR813 can draw current, enabling the long-tailed pair TR812/TR811 and so selecting the X10 amplifier.

A connection is also made from the anodes of D812 and D813 to the base of TR814 which supplies the 'tail' current for the other long-tailed pair TR810/TR809. A negative voltage applied at the base of TR814 will cut this transistor off and the associated long-tailed pair TR810/TR809 will be inhibited. In the absence of the negative bias, TR814 is held in conduction by the potential divider R974, R975 and R976 to the +24V rail. Hence, applying -12V via either D812 or D813 enables the long-tailed pair TR811/TR812 to give X10 X expansion or allowing D812/D813 to float enables TR809/TR810 to give X1 X gain. TR806 and TR808 operate as emitter follower buffers to the common emitter stage TR805 and TR807 respectively. The remaining part of the X amplifier now operates as two independent shunt feedback amplifiers, each driving an X plate. TR803 forms a cascode stage with TR805 as also does TR804 with TR807. The collector loads of TR803 and TR804 are the constant current sources TR801 and TR802. Shunt feedback in the amplifier section TR801, TR803, TR805, TR806 is applied via R938 together with the capacitor 'T' network C814, C818 and trimmer C816 applying HF compensation. This capacitor network operates in a way equivalent to the effect of a very low capacitance variable trimmer across R938. A similar feedback network, R944, C813, C815, C817 exists in the other amplifier half TR802, TR804, TR807 and TR808. The two amplifier halves differ in that TR805/TR806 and TR807/TR808 are PNP/NPN and NPN/PNP respectively. This enables the transistors TR805 and TR807 to provide maximum current drive to the output stages during the ramp period. Accordingly, therefore, the stage TR801/TR803 produces a positive going ramp signal at the commoned collector point, whereas that on the stage TR803/TR804 is negative going. The constant current sources TR801 and TR802 are provided with HF current boost via C807/C808 and C805/C806 respectively. This current drive is provided from TR805 and TR807 and the charge on the capacitors is recovered during the return transient via resistors R930/R941 and R931 respectively.

Components C821, R939, C810, L702 and C820, R943, C811, L701 are used to provide HF stability to each amplifier circuit. The current sources TR801 and TR802 are provided with bias voltage derived from the zener D801 and the bleed resistor R937, with C802 and C822 used for decoupling. This resistor is also used to provide current for the zener D802 which biases TR803. Output to the X plates is fed via R988 and R989 with zener diodes D815

and D816 used to drop the X plate voltage to the mean plate potential.

The commoned emitters of TR805 and TR807 are held at the fixed potential of +7.5V provided by D803, C829 and R946. Hence the voltages at the bases of TR806 and TR808 are also fixed at this value and are virtual earth points. Current drive to these virtual earth points from the common emitter amplifiers TR809 - TR812 described previously is fed via the diodes D806 and D807. Diodes D806-D811 are used in a current limiter circuit to prevent the output transistor TR801 and TR802 from saturating. The operation is best described by considering the case when TR812 is fully on and TR811 fully turned off. This would be the case when the timebase ramp is almost complete and an expanded trace has shifted well off to the right of the c.r.t. screen. TR812 emitter therefore takes all the current provided by the constant current source TR813. The current from the collector which normally flows through D806 to the base of TR806 would be sufficient to turn TR806 off and cause TR801 to saturate. However, because TR811 is not conducting the potential across R955 turns off D807, and the excess current from R955 bleeds through D810 and D811 to the collector of TR810. This prevents TR806 from being turned off and so limits the voltage at the junction of TR801 and TR803 from exceeding 100V. At the same time the voltage at the junction of TR802 and TR804 will be low, and since D807 is turned off, TR804 is prevented from saturating by the action of the current bleed through R951. TR804 normally limits at about +25V. A similar limiter circuit for the other amplifier half exists using D806, D808 and D809 which becomes effective prior to the start of trace on the left hand side of the c.r.t. display.

The TRACE LOCATE is achieved by the circuit R948, R949, D804 and D805. Normally D804 and D805 are reverse biased, with the result that no current flows in R948 and R949. When the TRACE LOCATE button is pressed +12V is applied to D804 and D805. This causes current to flow in R948 and R949 and divert some of the current from flowing in the virtual earth points at the bases of TR806 and TR808. As a result, TR806 and TR808 run out of drive current while the trace is still on the screen and the trace limits prematurely.

4.6 POWER SUPPLIES

The a.c. supply is applied to the primary windings of transformer T1 via the voltage selection switches S15 and S16, fuse FS1 and POWER switch S1. S15 connects the primary windings in series or in parallel, while S16 introduces an additional 20V tap as required. Multiple secondary windings provide low voltage a.c. inputs to the d.c. supply generation circuits. Secondary windings are also provided to supply 6.3V r.m.s. a.c. for the heaters of the c.r.t. and an a.c. input to the Trigger Amplifier circuit for use as described in Section 4.3.1.

4.6.1 LOW VOLTAGE SUPPLIES**+5V D.C. SUPPLY**

This supply is derived from the output of bridge rectifier BR1002 supplied from T1. An additional a.c. output is also taken from this winding to supply the 'External DVM' facility (SKQ).

The +9V unregulated output from BR1002 is applied to the voltage regulating integrated circuit IC1003 after smoothing by C1025. The voltage output from the regulator is determined by the ratio of R1049 and R1050. This ratio is such that 5V is obtained at the output. C1026 provides additional smoothing and de-coupling and diode D1023 protects the regulator IC in the event of the +5V output shorting to a negative rail. Fine adjustments of the output voltage of this supply can be made by selection of the Adjust on Test (A.O.T.) resistor, R1058.

-12V D.C. SUPPLY

A further secondary winding of T1 supplies the bridge rectifier formed by D5, D6, D7 and D8. The d.c. output from this bridge is applied to the reservoir capacitor C3 and the voltage regulator IC1002. The ratio of resistances of R1047 to R1048 is adjustable by potentiometer R1052 which is set to give 12V at the output of the regulator.

This output is smoothed by C1023 and the positive side is connected to 0V. As a result, the un-grounded end of C1023 is therefore at -12V and this point forms the supply rail. Diode D1022 protects IC1002 in the event of the -12V output shorting to a positive supply rail.

The same secondary winding drives D9 and D10 which with D5 and D8 form a further bridge rectifier to generate an unsmoothed full wave rectified supply to drive the graticule illumination lamps. The actual voltage applied to the lamps is controlled by the potentiometer R435 and the emitter follower TR405.

+12V SUPPLY

Diodes D1, D2, D3 and D4 form a bridge rectifier for this circuit. Smoothing is provided by C2 and 18V is thus provided for voltage regulator IC1001. The output voltage is adjusted by R1051 to give +12V. The circuit action is identical to that described for the -12V supply but in this case the negative side of the stabilised supply is grounded.

+60V, +120V AND -120V SUPPLIES

These supplies are derived from a single secondary winding, one end of which feeds a half wave rectifier D1018, giving the 60 volt output, and a voltage doubler circuit, C1021, D1011, D1010, C1019, giving the 120V output. This end of the winding is made to swing $\pm 60V$ about ground by the action of the bridge rectifier and C1017 connected between the low voltage end of the winding and ground. This allows the low voltage end to swing about by $\pm V$ where V is the voltage on C1017. Since the secondary winding supplies current to the 60V and 120V loads, this tends to charge C1017 via BR1001. The voltage across C1017 is adjusted to maintain a constant 60V output by the conduction of

TR1006. When the low voltage end of the secondary winding swings negative, diode (a) in BR1001 is turned on, and the base of TR1006 is at its most negative value (approx -1.5V).

The base of TR1006 is driven by diode D1013 and emitter follower TR1007. This transistor is biased between the +60V and -12V supplies such that its base will be at about 0V when the +60V supply is at the correct voltage. If the +60V supply is high, then the cathode of D1013 will tend to remove excess charge from C1016 on negative transients of the base of TR1006, thus reducing the conduction in TR1006 and allowing the voltage across C1017 to rise. This reduces the swing at the high voltage end of the secondary. If the 60V is low, D1013 will not conduct strongly hence R1042 will force more current into the base of TR1006 to increase conduction and so drop the voltage across C1017, consequently the 60V output will be made to rise. As a result of regulating the +60V supply, the doubled 120V supply will also be partially stabilised. A further -120V supply for the X output amplifier is provided by the doubler circuit C1029, C1030, D1028 and D1029.

+24V SUPPLY

This consists of a 12V regulator IC1004, with its low terminal connected into the +12V rail. Feedback input at the junction of R1031, R1029 is compared with the references (generated internally at pin 4) applied to pin 3. The supply voltage for this regulator is derived from the +75V line by R1027 and the 18V zener D1008 connected to the +12V line. The +24V output from IC1004 at pins 1, 6 and 10 is fed via PLD pin 4 to the timebase circuit. C1006 provides output decoupling and D1012 protects IC1004 against a short circuit to ground by loading down the +12V line.

4.6.2 E.H.T. SUPPLIES

The e.h.t. supplies for the grid, cathode and p.d.a. of the c.r.t. are supplied by a high frequency oscillator or inverter driven from the +12V and -12V supplies. Transformer T1101 is the e.h.t. oscillator transformer driven by transistor TR1103 biased to class C through the feed back winding 4 and 5 at a natural oscillating frequency of approximately 30kHz. Regulation of the -2.2kV supply is provided by a feedback control loop formed by TR1102, TR1101. The amount of drive and thus the magnitude of the e.h.t. output voltage, is determined by the base drive of TR1103 which flows through the feedback winding 4 and 5 of transformer T1101. As point 4 goes positive, increasing the conduction of TR1103, point 5 goes negative and C1105 charges negatively via D1105 and R1112. As a result, the next pulse of output current from TR1103 will be less than the preceeding one and the e.h.t. output will also be smaller unless the charge in C1105 is restored.

The average charge on C1105 is controlled by the collector current of TR1102. If this current is sufficient then C1105 will not discharge, the required current being provided by the transistor. Transistor TR1102 is controlled by an error amplifier formed by TR1101. The reference voltage for this amplifier is derived from the +12V rail via R1105, R1106, R1103 and the error voltage is applied from the 2.2kV output via R1125 to the base of TR1101. The action of the circuit is such that a current balance is achieved at this base.

If the -2.2kV output at the c.r.t. cathode becomes less negative, TR1101 conducts more, increasing the base drive to TR1102 and increasing the current in the output transistor, TR1103, due to C1105 being charged positively. If the -2.2kV output becomes more negative, i.e. the voltage is too high, then TR1101 conduction is reduced. This in turn reduces the drive to TR1102 which allows the charge on C1105 to go negative and thus reduce the output voltage.

Diode D1103 in the emitter of TR1101 is always conducting and provides temperature compensation for this transistor, with the emitter current provided by R1114. Diodes D1101 and D1102 at the base of TR1101 protect the base-emitter junction. Preset resistor R1106 functions as the 'Set e.h.t. control'.

Resistors R1101, R1102 and diode D1104, in conjunction with the choke L1101, form a current limiting circuit. Under normal operating conditions, the current through L1101 is approximately 250 - 300mA. If this should increase beyond this value, the voltage drop across L1101 will cause the decoupled +12V supply at the emitter of TR1102 to reduce to the point where D1104 becomes forward biased by virtue of the voltage across the potential divider R1101 and R1102. This diode then shorts out the error amplifier circuit and breaks the feedback loop so causing an effective current limit.

The secondary of the e.h.t. transformer T1101 drives two separate voltage multiplier circuits. The first circuit is fed from point 8 on the transformer and comprises a voltage doubler formed by C1114, D1111, D1112 and C1115. The resultant output voltage at the junction of R1123 and C1115 is 2.3kV which is smoothed by C1116 after being dropped to 2.2kV by 100V Zener diode D1114. This is the point fed back as the error voltage to TR1101 and is fed via R1120 to the cathode of the c.r.t. holding this at a fixed potential.

R1126 normally holds D1115 on and provides the ground return current for this voltage doubler via the cathode of D1111. This point is decoupled by C1117. If the cathode current drawn by the c.r.t. should become excessive (e.g. at very high Intensity settings) then the return current through D1111 will be greater than that provided by R1126. Hence, TR1105 will be turned on which effectively drives the c.r.t. grid more negative and limits the current in the tube.

An additional voltage doubler circuit C1109, D1107, D1108 and C1111 is driven from the same tap, pin 8, of the transformer but its output is referred at D1107 not to 0V but to the output potential of the bright-up amplifier, driven via emitter follower TR1104. If the emitter of TR1104 is near 0V, the voltage doubled supply, used to drive the grid of the c.r.t. would be at -2.3kV. That is the same as the output from D1112, and so more negative than the cathode by approximately 100V, the voltage across D1114. Thus the c.r.t. will be cut off. The grid is actually fed from R1119, which allows its potential with respect to the cathode to be adjusted to the point of cut off. As the output of Bright-up amplifier, described in Section 4.6.4. goes positive, the grid supply from D1108 will follow and the d.c. level fed to the grid via R1118 and R1039 will rise accordingly. The fast a.c. transition from the blanking amplifier is fed via C1015 and R1021 to the grid. As this electrode moves positively with respect to the cathode the beam of the c.r.t. is turned on. The third output from the e.h.t. oscillator is taken from pin 10 of the high voltage secondary winding and applied to X6 multiplier module to generate +14.3kV which is applied to the p.d.a. mesh of the c.r.t.

4.6.3. TUBE CONTROLS

A potential divider chain R1124, R438 and R433 is connected from the -2.2kV cathode supply to 0V. R438 is the FOCUS control and the wiper of this potentiometer is connected to that electrode. The geometry or I.P.S. electrode is taken to the wiper of a potentiometer, R440, with a control range of +100V to -12V. R447 also provides the 120V HT supply to the astigmatism control R439 which drives A3 of the c.r.t. This electrode potential is settable from +100V to +45V.

The heater of the c.r.t. is supplied directly from its own winding on the supply transformer but its mean d.c. potential is held at the cathode potential by R6.

Minor misalignment of the deflection plates can prevent the trace from aligning with the graticule lines and a correction or trace rotation coil is fitted. Current through this is set by R436 and driven via emitter follower TR406 from the +12V and -12V supply lines. The presence of D402 allows the correction current to be adjusted through zero but the connections to the coil must be reversed if a large correction current is required.

4.6.4. BRIGHT-UP AMPLIFIER

The function of the bright-up system is to turn the trace on to the level set by the INTENSITY control during each normal sweep and on continuously in X-Y mode. In the 'A Intensified by B' mode, additional bright-up is applied during B portion of the A sweep. The system is based on a shunt-feedback amplifier and responds to the algebraic sum of signals derived from the INTENSITY control, the A Timebase Bistable, the B Timebase Bistable and external Z mod. input. An

over-riding blanking input can be applied from the Chop Oscillator.

The amplifier is formed by TR1002 and TR1003, with shunt feedback via R1019 from the collector output of TR1003 to the virtual earth at the base of TR1002. TR1005 cascode connected with TR1004 provides a constant current load for TR1003 with additional high frequency drive to the output via C1004.

In the blanked condition D1004 is reverse biased and R1016 and R1018 determine the output level at approximately +5V. Subsequently, current applied via D1004 will drive the output voltage positive. Full bright-up occurs with approximately 2mA in D1004 and the output at approximately +55V. When blanked, the current from the collector of TR1001 is 4mA. 2mA is drawn through R1014 leaving 2mA in D1003. This exceeds any current via R1013 from the INTENSITY control R437.

In the normal 'A' sweep, -2mA is drawn through R1002, reducing the collector current in TR1001 to 2mA. With no current in D1003, the current in D1004 is controlled by R437, i.e. the bright-up is controlled by INTENSITY as set. This condition applies also in the X-Y mode and during the A or B sweeps of 'A and B Alternate' and 'B' only modes.

In the 'A Intensified by B' mode, the current in R1002 is less than 2mA during the A sweep, increasing to 2mA or more during the B sweep. The amount by which this current is less than 2mA is determined by the preset Contrast control R850. Thus, the resultant bright-up is determined both by the Contrast and Intensity settings.

In the Chop mode of operation, a positive drive is applied to pin 1014 during each Chop transition. Current through R1011 is applied via D1006 to exceed any current in D1004, blanking the trace as required.

A positive voltage applied to the Ext. Z mod. input will drive current via R1001 and D1001 to provide blanking.

The control currents via R1002 are derived from the timebase circuit as the summed currents from R861, R860, R859 and the collector of TR750.

In 'A' only, with S701 operated, 2mA flows through R851 and D729 into the emitter of TR749. Since the bistable IC708a is in the Cleared state for this mode, TR750 is biased into conduction by the high \bar{Q} output. The 2mA current from TR749 collector flows through this transistor and balances an equal and opposite current provided by R861. Before the A Timebase commences to sweep, the voltage at the emitter of TR703 is the same as that at the virtual earth blanking input Pt. 708 (i.e. 3V) and no current flows through R860. Also, no current flows through R859 from the B Timebase. As a result, no current drive is applied to Pt. 708. When the A ramp starts the emitter of

TR703 drops to approximately 0V and a -2mA current flows through R860 which enables the Bright-up amplifier.

In the 'B' only mode, with S703 operated, there is no current in TR749 and hence none in TR750. Before the start of the A sweep, R861 defines +2mA into Pt. 708. When the A sweep starts, this is offset by the current in R860 with no resultant bright-up. Only when the B sweep is running also does R859 introduce a further -2mA to cause bright-up.

In the 'A Intensified by B' mode, with S702 operated, R851 and the Contrast control R850 defines a current between approximately 0.7mA and 2mA into the emitter of TR749 and hence through TR750. Thus, during the A sweep the output current is between -0.6mA and -2mA (partial bright-up). When the B ramp is running also R859 introduces a further -2mA for full bright-up.

In the 'A and B Alternate' modes, with S704 selected, D730 energises the contrast path R850 and R851.

During the A display sweep, the circuit operates as for 'A Intensified by B'. During the B display sweep the \bar{Q} of IC708a will be low, turning off TR750. The current from TR749 flows through D723 but the output currents are as for 'B' only.

In X-Y, selected by S705, the A and B timebase signals are inhibited and R854 draws 4mA via D728, TR749 and TR750 for a resultant output of -2mA for a steady bright-up.

4.6.5 CALIBRATOR

This circuit provides a readily accessible calibration source for the 'Y' amplifier. Its output is provided at the front panel. The circuit consists of an operational amplifier IC714, connected as a relaxation oscillator with R983 and C844 forming the feedback timing elements. The output voltage swing of IC714 gates a current, derived from the +12V line via R985, into the output resistors R987 and the close tolerance component R699. When the output of IC714 is low, diode D822 is biased on by the positive supply line and current flows into the op-amp output. When the amplifier output is high, D822 is biased off and D821 conducts, passing current into the output calibration resistors. C845 limits the maximum slew rate of the output edges. The output available for calibration purposes is 1.0V or 1mA into a shorting link between the output pin and earth connector.

4.7 OPERATION WITH DM3010

This section covers the control circuitry of the OS3600 which operates specifically with the DM3010. The full circuit description of the DM3010 is included in the handbook for that unit and reference should be made to that also for a full understanding of the complete system.

4.7.1 TIME AND 1/TIME MEASUREMENT

In this mode of operation, the timebase system has to generate B sweeps at two positions on the A sweep. The first occurs at the time set by the normal DELAY control of the OS3600. The second is delayed with respect to the first by a period set by the v/t control of the DM3010. This section should be read in conjunction with Section 4.4.4 and 4.4.5 describing the independent operation of the dual timebase system.

At the end of each A sweep, the emitter of TR703 goes positive and this transition is coupled through D711, R731 and C763 to produce a positive 'spike' at the input to IC707c. This gate inverts the impulse to apply a clock signal to bistable IC705b. This bistable is normally held in the preset state with 0V applied to PLU pin 6. This is applied via a shorting link on PLU if a DM3010 is not fitted and via switch contacts of DM3010 if fitted. When Time or 1/Time modes are selected by DM3010, this link is broken and IC705b is free to switch state at the end of each A ramp. The Q and \bar{Q} outputs thus enable either comparator IC710a or comparator IC710b on alternate A sweeps. IC710a follows the normal DELAY setting while IC710b follows the additional delay level from the DM3010 via PLU pin 5. (See Section 4.1.7).

When the Y display mode 'CH1 and CH2 Alternate' mode is selected, R906 is connected to 0V by S712, and TR747 is free to switch under control of the signal from the beam switch bistable via PLT pin 9. The collector output of TR747 is applied to the J input of IC705b. Both bistables are clocked at the end of the A sweep and this link keeps them in step so that the normal Delayed B sweep is applied to CH1 displaying sweeps and the additionally delayed B sweep to CH2.

When Time Measurement and Trigger View modes are selected together with either CH1, CH2 or ADD, a similar situation exists as would be the case if 'CH1 and CH2 Alternate' were selected. The trace order is locked by TR747 and displays the 1st time delay on Trigger View and the second time delay on either Y channel.

Note that when 'CHOP' is selected for this combination both 1st Delay and 2nd Delay are displayed with each Y channel.

4.7.2 VOLTAGE MEASUREMENT

The generation of the additional Y shift signal which is applied to the CH1 channel when the DM3010 is set to Voltage measurement via the OS3600 is described in Section 4.2. Control of this offset switching is derived from IC705a.

This bistable is normally inhibited from responding to 'end of A sweep' clock signals by a high applied to its

preset input via PLU pin 7. This is maintained by a shorting link when no DM3010 is fitted and via the relevant switch on the DM3010 if fitted. However, when this contact is broken, IC705a is free to respond to its clock inputs and its Q and \bar{Q} output levels reverse state on alternate A sweeps, controlling the Y shift generator of CH1 via PLT pins 1 and 3.

The Q output of this bistable also controls gate IC707a to inhibit every other 'alternate' switching signal to the Y channel beam switch. Thus, when 'CH1 and CH2 Alternate' mode of Y display and DM3010 voltage measurement are selected, the sweep sequence will be CH1, CH2/normal shift, CH1/additional shift, presenting a 3 trace display.

The simultaneous application of 'A and B Alternate' timebase mode with DM3010 voltage measurement is inhibited. Warning of this prohibited combination is given as the relevant l.e.d. on the DM3010 is energised from the -12V supply via S704 and R911. This same signal line applies preset to IC705a to inhibit the voltage measurement sequence. A similar inhibit is applied to IC705a via S705, R841 and D754 when X-Y display mode is selected and voltage measurement does not apply.

When CH1, CH2 and Trigger View are in Alternate trace mode, the Y beam switch IC306a and IC306b divides by 3. The 'J' line to pin 11 of IC705b is then driven high when CH1 and Trigger View are selected, thus the 1st Time Delay is displayed on these channels and the 2nd Time Delay on CH2.

The trace order is as follows:—

CH1/1st Time Delay
Trig View/1st Time Delay
CH2/2nd Time Delay

If 'CHOP' mode is selected, TR747 is not switched into circuit with the result that both Time Delay positions are shown for each Y Channel and Trigger View.

When 'A & B Alternate' is selected for any single trace Y mode without Time measurement selected, transistor TR748 is turned on by the single trace detect signal from PLT 19. However, the selection of Time Measurement reverse biases the emitter of TR748 and this allows the IC708a and IC708b combination to divide by four. The sweep order is thus — A, A, B, B, A, A, B, B etc. It should be noted that the display selection bistables IC708a and IC708b and the Y beam switch bistables IC306a and IC306b are not synchronised, but display all the required traces by virtue of different division ratios which exist between them. The most complex mode is when 'CH1', 'CH2', 'TRIGGER VIEW' and 'A & B ALT' are selected. Twelve A sweeps are required to complete the cycle, and each trace combination is displayed twice within the cycle. The trace order is shown in the following table:—

| No. of A Sweeps | Y Mode | Sweep Selected | Delay Selected (1st or 2nd = D1 or D2) |
|-----------------|--------|----------------|---|
| 1 | CH1 | A | D1 |
| 2 | TV | A | D1 |
| 3 | CH2 | B | D2 |
| 4 | CH1 | B | D1 |
| 5 | TV | A | D1 |
| 6 | CH2 | A | D2 |
| 7 | CH1 | B | D1 |
| 8 | TV | B | D1 |
| 9 | CH2 | A | D2 |
| 10 | CH1 | A | D1 |
| 11 | TV | B | D1 |
| 12 | CH2 | B | D2 |

5.1 GENERAL

The instrument is protected electrically by 2 fuses:

1. FS1, mounted in a holder on the rear panel, is in the line of the incoming supply. This is a 20 x 5mm slow blow type. 500mA rating (part number 33685) is required for the 220/240V ranges or 1A rating (part number 34790) for the 100/120V ranges.
2. FS1001, mounted on the track side of the power supply p.c.b. behind the moulded plastic cover on the rear panel is a 20 x 5mm slow blow type, 500mA rating (part number 33685). **BEWARE – HIGH VOLTAGES ARE PRESENT ON THIS P.C.B.**

The following sections give information on obtaining access to all internal controls and removal of the various printed circuit boards and assemblies as may be found necessary during servicing.

If, during servicing, a component needs replacing, it is recommended that it is carefully desoldered, using either a vacuum desoldering pump or desolder braid, taking care not to damage either the delicate copper track of the printed circuit boards or adjacent components. It will often assist removal of the leads if the component is first cut away leaving as much of the leads as possible connected to the p.c.b. The practice of attempting to solder a new component onto the remaining leads of the old one is not recommended as it is likely to cause poor mechanical and electrical joints.

If a fault cannot be cleared it is recommended that the instrument is returned to the manufacturer for repair. When faults have been cleared, it is advisable for at least those parts that have been repaired to be recalibrated to ensure that the instrument conforms to specification. Note that all knobs are collet fixing. They are removed by prising out the central cap slackening the fixing screw or nut and withdrawing the knob from the shaft.

5.2 ACCESS

Immediate access is available to nearly all preset controls once the top and bottom covers have been removed.

Figures 13, 14 and 15 illustrate various views of the instrument showing the position and function of the preset controls and the major sub-assemblies of the instrument. Each cover is retained in position by four latch fasteners. Each fastener is released by turning it a quarter of a turn anticlockwise. In the locked position the arrow head on the fastener points towards the adjacent frame.

WARNING: the instrument should be disconnected from the supply while the covers are being removed. Dangerous high voltages are then accessible and the instrument should be operated only by qualified personnel.

The following description details the method for removing the individual assemblies.

5.2.1 Y PREAMPLIFIER AND PREAMP TRIGGER ASSEMBLY

1. Remove the knobs from the Y attenuator switches and Y shift controls.
2. Remove the two nuts holding the attenuator switches to the front panel.
3. Unclip the delay line cable from its fixings around the tube shield and check the cable routing to ensure there is sufficient slack available to withdraw the preamplifier.
WARNING: Do not stress the delay line terminations as the wire is very fragile. If a DM3010 option is fitted, it will be necessary to at least partially remove it (see Section 5.2 of the DM 3010 Handbook).
4. Remove the 2 screws and wavy washers, fixing the preamplifier to the pillars screwed to the L.H. sidebar, slacken the screw fixing the front pillar to the sidebar and move the pillar rearwards. Remove the three screws and wavy washers securing the preamplifier to the small blocks screwed to the timebase board.
5. Unplug the multiway connector from PLM at the timebase end (SKT). Unplug the Trigger View input lead (SKN) and the "UNCAL" i.e.d.'s (SKNN and SKPP). Unclip the socket (SKLL) at the end of the cable from the CH1 attenuator switch from its parking clip adjacent to the c.r.t. side contact pins or from PLA on the DM3010 option (if fitted).
6. Carefully withdraw the preamplifier outwards and backwards (taking care not to foul the assembly on any fixings or to strain the delay line terminations) as far as the delay line and coaxial leads will allow.
7. To remove the preamplifier completely carefully unsolder the delay line terminations and mark the connections to assist replacement. Ease the line out of the p.c.b. Unsolder and remove the coaxial cables, again mark them to assist replacement. Remove the preamplifier assembly.

5.2.2 Y OUTPUT DRIVER ASSEMBLY

1. Remove the DM3010 option if fitted (see DM3010 Handbook, Section 5.2).
2. Remove the knobs from the INTENSITY FOCUS AND SCALE controls.
3. Remove sockets SKG, SKH, SKJ, SKK and SKL from the plugs on the p.c.b. Note that SKK is reversible so its position should be marked to facilitate reassembly.
4. Unsolder the red and orange wires from pins 408 and 410 and unplug the pink wire from the c.r.t.
5. Desolder the earth braid from the c.r.t. shield to the Y driver p.c.b. It is important that all earth connections are made in the same places on reassembly.

6. Unsolder the two 10Ω resistors, R36 and R37, from pins 405 and 409.
7. Unclip the delay line from the top of the c.r.t. shield and manoeuvre it carefully to enable the p.c.b. to be withdrawn. If the p.c.b. has to be removed completely, carefully unsolder the delay line terminations and ease the delay line out of the p.c.b. Mark the terminations to assist replacement.

WARNING: Do not stress the delay line terminations as the wire is very fragile.

8. Remove the L.H. sidebar trim by inserting a screwdriver in the slot near the front panel and carefully prising the trim away from the sidebar. Remove the screw and wavy washer under the trim securing the p.c.b. fixing stud.
9. Remove the remaining 3 screws and washers securing the p.c.b. and carefully withdraw the assembly.

WARNING: Do not operate the instrument with SKK removed. The centre conductor is used to earth the external conducting coating of the c.r.t.

5.2.3 Y OUTPUT MODULE P.C.B. ASSEMBLY

1. Unsolder the red and orange wires at the Y driver p.c.b. end from the pins 408 and 410.
2. Unsolder the 2 10Ω resistors, R36 and R37, at the Y driver p.c.b. end from pins 405 and 407.
3. Disconnect the Y output stopper resistors R38 and R39 from the c.r.t.
4. Remove the screw and washer securing the bracket from the output module p.c.b. to the driver p.c.b.
5. Carefully prise out the rear left hand sidebar trim and remove the two screws securing the output assembly to the sidebar. Carefully ease out the assembly. To remove the output module IC471, first desolder the 7 pins and then remove the 2 screws securing the IC to the heatsink. Note that heatsink compound must be used between mating surfaces.

5.2.4 TRIGGER UNIT

1. Remove the knobs from the A Level, B Level and A Hold Off controls.
2. Unsolder the 27Ω resistors, R23 and R24, from pins 610 and 612.
3. Remove the screw and washer securing the small screen to the rear L.H. corner of the trigger source p.c.b.
4. Remove the two screws and washers securing the trigger amplifier p.c.b. to the connecting pillars mounted on the timebase p.c.b.
5. Remove the two screws securing the fixing brackets to the RH sidebar (Note that the captive nuts

will slide along the channel and will need to be re-positioned on re-assembly).

6. Remove the sockets SKP and SKR and unscrew the "p" clip from the timebase p.c.b. which retains the coaxial cables.
7. Slide the assembly rearwards to clear the potentiometer shafts and switch buttons. Tilt the front of the assembly downwards and withdraw to the extent allowed by the coaxial leads. To remove the unit completely, unsolder and remove all the coaxial leads, noting their positions for re-assembly.

WARNING: The push button switches are easily damaged by a hot soldering iron. Take great care not to overheat any of the switch pins and resolder to the top of the pin not down at the switch body.

5.2.5 EXTERNAL X ATTENUATOR P.C.B. ASSEMBLY

1. Desolder coaxial lead and R15 ($1.1k\Omega$) from the 1V Cal pin. Remove the coaxial lead screen from its fixing ring.
2. Desolder the 22Ω resistors, R25 and R26, from the Ext. A and Ext. B input sockets.
3. Desolder the 27Ω resistors, R23 and R24, from pins 610 and 612 on the trigger source p.c.b.
4. Remove the two screws (with washer and solder tag with R15 attached) securing the p.c.b.
5. Withdraw the p.c.b.

5.2.6 TIMEBASE UNIT

1. Remove the d.v.m. option if fitted.
2. Remove the trigger assembly as in 5.2.5 above.
3. Desolder the following 5 coaxial leads: The 1V cal signal lead from pins 712, 711; the A ramp output lead from pins 719, 720; the B gate output lead from pins 717, 718; the bright-up lead from pins 708, 707 and the alternate pulse lead from pins 715, 716. Mark to ease replacement.
4. Unplug SKT, SKW, SKV and SKX.
5. Unscrew the solder tag from the chassis to the rear of p.c.b. near the X plate leads.
6. Remove the two X output connectors from the c.r.t. Note that the yellow lead goes to the nearest of the two c.r.t. pins to the p.c.b.
7. Remove the 3 remaining screws (with 3 washers and one p clip) securing the top of the p.c.b. to the support rail.
8. Slide the p.c.b. rearwards to clear the push button switches, downwards at the rear end and then out through the bottom of the instrument, taking care not to catch the X output transistors on the transformer.

5.2.7 E.H.T. P.C.B. ASSEMBLY

WARNING: Beware high voltages.

1. Remove the top screen of the unit by unscrewing the three retaining screws.
2. To prevent e.h.t. flashover to the Y preamplifier, place a suitable piece of insulating material between the rear of the preamplifier p.c.b. and the e.h.t. assembly.
3. Remove the e.h.t. socket from the voltage multiplier, MPR1, with a pair of *well insulated* pliers and earth the c.r.t. final anode lead to chassis via a high voltage resistor of 1–50M Ω . Do not short the final anode directly to chassis. Do ensure that SKK is securely in place before discharging the final anode (Pin 2 of SKK is the ground connection for the external conducting coating of the c.r.t.). When the final anode has been discharged connect it to pin 2 of SKK to prevent it recharging due to energy stored within the glass of the c.r.t.
4. Discharge the h.v. output of MPR1 to chassis via a h.v. resistor of 1–50M Ω . Do not short directly to chassis.
5. Remove SKE from the e.h.t. p.c.b.
6. Unsolder the c.r.t. final anode screen and multiplier ground lead from pin 1101 and the multiplier input lead from pin 1102. Remove four screws and washers and lift out the e.h.t. p.c.b. assembly.

5.2.8 POWER SUPPLY ASSEMBLY

Access to the rear of the power supply p.c.b. is obtained by removing the brown plastic moulding at the rear of the instrument which is held by four screws and washers.

WARNING: High Voltages are present on this p.c.b.

The main power supply is a removable assembly forming the rear of the instrument. Removal of the power supply p.c.b. is most easily accomplished after removing the complete assembly from the instrument.

1. Unsolder the coaxial leads from the A RAMP and B GATE BNC sockets on the rear panel, the 0.5V a.c. trigger winding on the supply transformer, pins 1013/1015 and 1014/1016 on the p.c.b. Mark to assist replacement.
2. Remove sockets SKA, SKB, SKC and SKD from the p.c.b. and the c.r.t. base SKA.
3. Pull the actuating rod off the POWER ON switch and withdraw it rearwards through the front panel. Take care not to damage the switch when the rear panel assembly is removed as it is then in a vulnerable position.
4. Remove the four screws and washers from the inside rear of the instrument which are nearest the corners, releasing the rear mounting feet.

5. Remove the four screws and washers securing the brown plastic moulding covering the rear of the p.c.b.
6. Remove the four countersunk screws fixing the rear panel to the side frames and the two countersunk screws securing the top bar. Withdraw the unit.

5.2.9 CATHODE RAY TUBE

1. Remove the e.h.t. oscillator top screen, remove the final anode socket from the top of the multiplier MPR1 and discharge the final anode and multiplier as detailed in section 5.2.7.

WARNING: Beware high voltages, observe precautions detailed in Section 5.2.7.

2. Unsolder the earth lead for the final anode and screen from pin 1101.
3. Unclip the delay line from the two mounting clips on the top of the c.r.t. shield.
4. Remove the brown plastic rear moulding.
5. Remove the c.r.t. base and the side contact connectors (mark to assist replacement).
6. Unsolder the earthing braid connections between the c.r.t. shield and the Y driver p.c.b. Note the positions for reassembly. This is important.
7. Unclip the graticule from the front panel.
8. Remove the trace rotation socket SKK. Ensure that the final anode (e.h.t.) lead is still connected to pin 2 of SKK (see Section 5.2.7).
9. Remove the two screws securing the rear of c.r.t. shield to the e.h.t. assembly mounting bracket.
10. Slide the c.r.t. and shield rearwards sufficiently to clear the support moulding at the front of the instrument and lift out.
11. Release the c.r.t. from the shield, release the locking clamp at the rear of the shield and slide the tube forward, taking great care not to damage the side pins when doing this. Note that the leads to the trace rotation coil and the e.h.t. cable pass through grommets in the shield. Take care not to strain these leads. It is necessary to remove the contact inserts from the plastic housing of SKK in order to remove the cable. Do not knock or stress the shield as this can damage its magnetic properties.
12. To replace the c.r.t. assembly, reverse the above procedure, but tighten the locking clamp last, after pushing the c.r.t. forward within the shield to meet the front panel moulding. DO NOT overtighten this clamp as damage to the glass may result. Tighten only to the point where the rubber block is seen to distort.

WARNING: Although the danger of implosion

with this type of c.r.t. is slight, great caution should nevertheless be used when handling the c.r.t. It is advisable to wear protective clothing, in particular, some form of suitable eye protection.

5.2.10 SCALE ILLUMINATION LAMPS

1. Remove the instrument top cover.
2. Pull the lampholder(s) from the plastic moulding around the face of the c.r.t.
3. Pull the wedge shaped base lamp from its socket. The lamps are 12V 1W types, part number 40328.

5.2.11 COAXIAL CONNECTIONS

The instrument uses 13 coaxial leads for interconnection


between assemblies which are coded with coloured sleeves at each end for identification. The table in Fig. 5.1 shows the interconnection details. The first pin number in a pair refers to the inner conductor, the second to the screen.


5.3 FAULT FINDING TABLES


Fault finding is based initially on the characteristics of the fault and the tables of Section 5.3 define a suggested procedure to localise the fault to one particular area. Subsequent detailed guidance will be obtained from the relevant circuit diagram and circuit description and from the table of operating potentials in Section 5.4.

| FROM | TO |
|---|--|
| 'Y' Preamp p.c.b. pins 302, 301 | Timebase p.c.b. pins 715, 716 |
| 'Y' Preamp p.c.b. pins 308, 309 | Trigger source S511, a3, b3 |
| 'Y' Preamp trigger CH1 | Trigger source S509, b3, b1 |
| 'Y' Preamp trigger CH2 | Trigger source S512, b3, b1 |
| 'Y' Preamp p.c.b. pins 309, 0V and R308 | Power supply p.c.b. pins 1014 and 1016 |
| Ex-Atten p.c.b. pin 626, CAL | Timebase p.c.b. pins 711, 712 |
| Back panel BNC socket (B GATE) | Timebase p.c.b. pins 718, 717 |
| Back panel BNC socket (A RAMP) | Timebase p.c.b. pins 720, 719 |
| Timebase p.c.b. pin 707, 708 | Power supply p.c.b. pins 1013, 1015 |
| Trigger source p.c.b. pins 601, 0V | Transformer pins 11 and 12 |
| Timebase p.c.b. pins 703 and 704 | Trigger p.c.b. pins 511 and 512 |
| Timebase p.c.b. pins 705 and 706 | Trigger p.c.b. pins 554 and 555 |
| Timebase p.c.b. pins 709 and 710 | Timebase p.c.b. pins 701 and 702 |


Fig. 5.1 Coaxial Lead Interconnection Data








FOR INSTRUMENTS FITTED WITH DM3010





5.4 OPERATING POTENTIALS

Measurements are taken with the power supply input voltage at approximately the mid range of the supply voltage setting. The Y inputs are grounded and the amplifiers set to 2mV/cm sensitivity. The Timebase is set to A only and AUTO, with the trigger LEVEL control fully clockwise. The Y amplifier is set to CH1 only with the trace centred except where stated. To prevent possible oscillation measurements were taken with a 1kΩ resistor in series with the meter lead.

Y PREAMPLIFIER AND PREAMP TRIGGER

CH1

Set DM3010 to NORMAL mode (if fitted)

| | | |
|------------|------------------|--------|
| TR102 | EMITTER | -6.5V |
| TR103 | BASE | +0.73V |
| IC101 | PIN 6 | -4.5V |
| IC102 | PINS 1, 7 | -0.8V |
| TR104, 105 | EMITTERS | +3.3V |
| " | COLLECTORS | -5.2V |
| IC103 | PINS 5, 6 | -6.0V |
| " | PINS 1, 2, 9, 10 | -1.25V |
| IC104 | PINS 8, 11 | +2.0V |
| " | PINS 3, 4, 5, 13 | -5.3V |
| TR106 | EMITTER | -4.6V |
| TR107 | EMITTER | -5.25V |
| TR109 | COLLECTOR | +0.89V |
| TR108 | COLLECTOR | -9.5V |
| TR108, 109 | EMITTERS | +6.8V |
| IC105 | PINS 1, 5, 6, 9 | -1.9V |
| " | PIN 3 | -7.2V |
| TR110, 111 | EMITTERS | -3.5V |

CH2

CH2 only selected and trace centred.

| | | |
|------------|------------------|--------|
| TR202 | EMITTER | -6.5V |
| TR103 | BASE | +0.73V |
| IC101 | PIN 6 | -4.5V |
| IC102 | PINS 1, 7 | -0.8V |
| TR104, 105 | EMITTERS | +3.3V |
| " | COLLECTORS | -5.2V |
| IC103 | PINS 5, 6 | -6.0V |
| " | PINS 1, 2, 9, 10 | -1.25V |
| IC104 | PINS 8, 11 | +2.0V |
| " | PINS 3, 4, 5, 13 | -5.3V |
| IC105 | PINS 1, 5, 6, 9 | -1.9V |
| " | PIN 3 | -7.2V |
| TR110, 111 | EMITTERS | -3.5V |
| IC107, 207 | PINS 5, 6 | +1.2V |
| IC301 | PINS 5, 6 | +0.2V |
| TR303, 304 | BASES | +4.7V |
| IC302 | PINS 8, 11 | +5.6V |
| " | PINS 7, 9 | +3.0V |
| IC302 | PIN 3 | +1.3V |
| TR312 | EMITTER | +1.3V |
| IC307 | PIN 11 | +11.7V |
| IC307 | PIN 8 | 0V |

| | | |
|-------|-----------|-------|
| TR306 | COLLECTOR | +0.2V |
| TR305 | COLLECTOR | -0.1V |

Y DRIVER AND OUTPUT

| | | |
|--------------|---------------|----------------|
| TR401, 402 | COLLECTOR | -3.4V |
| TR403, 404 | EMITTERS | -7.2V |
| " | COLLECTORS | +1.2V |
| Y DRIVER O/P | PINS 405, 409 | +5.9V |
| Y OUTPUT | PINS 475, 476 | +33V |
| *FOCUS | PLH (4) | -1.5kV approx. |

*HIGH IMPEDANCE – REFOCUS AFTER CONNECTING METER

| | | |
|----------|---------|--------------|
| GEOMETRY | PIN 404 | +20V approx. |
|----------|---------|--------------|

TRIGGER AMPLIFIER

Trig level controls (A and B) set to mid position, no trigger signal applied.

A CHANNEL

| | | |
|------------|------------|-----------------|
| TR503 | BASE | 0V |
| TR507 | BASE | -0.71V |
| TR508 | BASE | -1.0V |
| TR507/508 | COLLECTORS | +2.8V |
| TR506 | EMITTER | +8.9V |
| " | " | (XY sel.) |
| " | " | +1.9V |
| " | " | (XY not sel.) |
| TR509, 510 | COLLECTORS | -0.56V |
| TR513, 514 | " | +3.6V |
| IC501 | PIN 5 | +3.6V |
| " | " | (POS. TRIG) |
| " | " | +4.3V |
| " | " | (NEG. TRIG) |
| " | PIN 10 | +2.0V |
| " | " | (POS. TRIG) |
| " | " | +3.6V |
| " | " | (NEG TRIG) |
| TR515 | EMITTER | -4.7V |
| TR517 | EMITTER | -7.6V |
| TR511, 512 | COLLECTORS | +5.5V |
| " | " | (TRIG VIEW SEL) |

B CHANNEL

| | | |
|-----------|------------|------------|
| TR522 | BASE | 0V |
| TR524 | BASE | -0.74V |
| TR525 | BASE | -1.0V |
| TR524/525 | COLLECTORS | +3.6V |
| TR526 | COLLECTORS | -1.2V |
| TR528/529 | COLLECTORS | +3.0V |
| IC502 | PIN 5 | +4.3V |
| " | " | (POS TRIG) |
| " | " | +3.6V |
| " | " | (NEG TRIG) |
| " | PIN 10 | +3.6V |
| " | " | (POS TRIG) |

” ” +2.0V
(NEG TRIG)

TIMEBASE

Readings are taken with A ONLY and NORMAL TRIG. modes selected with no trigger signal applied. All controls are in the CH1 position, except where stated.

| | | |
|-------|------|--------|
| TR714 | BASE | +14.5V |
| TR738 | ” | +14.5V |
| TR714 | ” | +21V * |
| TR738 | ” | +21V * |

* A & B variable TIME/CM fully anticlockwise

| | | |
|-------|-----------|-------|
| TR720 | EMITTER | 0V |
| TR710 | ” | -8.3V |
| TR703 | ” | +4V |
| TR735 | ” | 0V |
| TR727 | ” | -8.6V |
| TR726 | ” | +3.0V |
| TR749 | BASE | -2.2V |
| TR750 | COLLECTOR | +30V |

X OUTPUT AMPLIFIER

Readings are taken with the HORIZONTAL mode switched to X-Y, the A TRIGGER SOURCE to EXT and the X SHIFT adjusted for a spot in the centre of the c.r.t.

| | | |
|-----------------------|------------|--------|
| TR814 | EMITTER | -11.8V |
| TR810/812 | BASES | +1.8V |
| TR809, 811 | BASES | +1.8V |
| TR813 | EMITTER | -3.8V |
| TR805 | BASE | +6.9V |
| TR806 | ” | +7.6V |
| TR807 | ” | +8.9V |
| TR808 | ” | +7.6V |
| TR801/803/802 /804 | COLLECTORS | +60V |

POWER SUPPLY

Readings are taken with the HORIZONTAL MODE switched to X-Y and the spot centred and just visible.

| | | |
|--------|--------------------|--------------|
| IC1001 | ADJ | +10.8V |
| IC1002 | ADJ | -10.8V |
| IC1004 | PINS 1, 6, 10 | +24V |
| ” | PINS 7, 8 | +30V |
| ” | PIN 5 | +12V |
| IC1003 | ADJ | +3.8V |
| TR1005 | COLLECTOR | +79V |
| TR1004 | COLLECTOR | +15V |
| TR1003 | COLLECTOR | -11V |
| PLA | PIN 5 (mean plate) | +30V |
| PLA | PIN 6 (ASTIG) | +30V approx. |

C.R.T. FINAL ANODE

Remove the screen from the e.h.t. assembly. Remove and discharge the c.r.t. final anode socket from the voltage

multiplier MPR1. Measure the final anode voltage at the output from the multiplier.

MPR1 OUTPUT PLUG 14.3kV

BEWARE HIGH VOLTAGE – OBSERVE ALL PRECAUTIONS LISTED IN SECTION 5.2.7.

5.5 CALIBRATION PROCEDURE

5.5.1 TEST EQUIPMENT

1. Variable autotransformer. Output voltage 95-260V at 1A with r.m.s. voltmeter.
2. Digital multimeter 4½ digit with 1MΩ minimum input impedance and accuracy within 0.02%.
3. High voltage probe for multimeter capable of operation up to 20kV.
4. Voltage calibrator 1kHz square wave generator with amplitude range of 2mV to 50V ±0.2%.
5. Time mark generator. 10ns to 0.5s ±0.2%.
6. Fast rise squarewave generator. 100Hz to 1MHz flat top square wave generator with amplitude range 0.1V to 1V into 50Ω with rise time of less than 1ns.
7. R.F. sinewave generator 500kHz to 150MHz with 50kHz reference frequency. Output amplitude 10mV to 5Vpp into 50Ω, accuracy at 50kHz and 500kHz to 150MHz within 3%.
8. LF Sinewave generator.
9. Capacitance standardiser 1MΩ/25pF, BNC 50Ω terminations.
10. BNC-BNC connector lead (PL43).
11. Test oscilloscope, 10MHz bandwidth ≥ 5% accuracy ≤ 50mV/cm sensitivity with X10 low capacitance probe.

NOTE: Calibration should be carried out at 23°C ambient temperature after at least a 15 minute warm up period. All measurements are made with respect to chassis except where stated.

5.5.2 POWER SUPPLIES AND CALIBRATOR

1. Set the INTENSITY control to minimum.
2. Set the supply voltage switches in the rear panel to suit the supply. Apply the supply voltage via the variac and set to mid range of the supply voltage setting. (Check the correct supply fuse has been fitted).
3. Check the SCALE control varies the scale intensity and that the POWER ON l.e.d. is energised.
4. Connect the d.v.m. to pin 6 on PLD (power supply p.c.b.), set R1052 to give -12.00V.
5. Check the supply voltages on the following pins of PLD.

| | |
|---------|----------------|
| PLD (9) | 5.0V \pm 5% |
| PLD (4) | 24.0V \pm 5% |
| PLD (1) | +120V \pm 6% |
| PLD (3) | -120V \pm 6% |

- Connect a d.v.m. to the anode (orange lead) of C1 (1000 μ F 100V) and check for 60V \pm 6%.
- Briefly switch off the instrument, remove IC714 on the timebase p.c.b. and switch on again, connect the d.v.m. to the 1V CAL pin. Adjust R1051 on the power supply p.c.b. for 1.000V d.c. output. Connect the d.v.m. to PLD(6) and check for +12V \pm 2%. Briefly switch off the set, replace IC714 and switch on again. Confirm with an oscilloscope the presence of a square wave at the CAL output of frequency 1kHz \pm 10%.

5.5.3 E.H.T. AND C.R.T. CUT OFF VOLTAGES

- Remove the screen from the e.h.t. oscillator.
- Connect the d.v.m. via the high voltage probe to the cathode (positive band) of D1114. Adjust R1106 for -2.2kV.

BEWARE HIGH VOLTAGE.

- Set the instrument to X-Y mode and centre the spot on the screen. Adjust the INTENSITY control for +15V at the junction of the collectors of TR1003, TR1004 and R1022. The set R1119 for a just visible spot.
- Replace the e.h.t. screen.

5.5.4 Y MEAN PLATE POTENTIAL AND +7V SUPPLY

- Measure the +7V supply at pin 408 on the Y driver p.c.b., check for +7V \pm 0.5V, if necessary adjust R425 (A.O.T.) to achieve this.
- Set trace to centre line. Measure the Y plate voltages and finely adjust the Y shift control to equalise the voltages. Check the voltage lies in the range +29 to 33V. Adjust R456 (A.O.T.) if necessary.

5.5.5 TRACE ALIGNMENT GEOMETRY AND ASTIGMATISM

- Set the instrument to 1ms/cm, 50mV/cm with trigger to AUTO timebase to A ONLY and Y MODE to CH1.
- Ground CH1 input and centre trace, adjust TRACE ROTATE control for a horizontal trace. (It may be necessary to reverse SKV).
- Set CH1 input to AC. Apply a 1MHz sinewave of approximately 400mV amplitude. Trigger the signal and adjust the GEOM preset R440 for best compromise of the X and Y edges at the extreme edges of the graticule.
- Apply a 1kHz sinewave of approximately 400mV amplitude. Trigger the waveform and adjust the ASTIG preset R439 in conjunction with the FOCUS

control for the finest trace at low intensity.

- Recheck the geometry setting.

5.5.6 SCALE ILLUMINATION

Check both lamps are operating, replace if showing signs of blackening. Check that brilliance is fully variable.

Y AMPLIFIER ADJUSTMENTS

5.5.7 CHANNELS 1 & 2 – AC/DC EQUALISATION

- Set the instrument to CH1 only, 10mV/cm sensitivity d.c. coupled, triggered from CH1 a.c. coupled, A timebase only 5ms/cm.
- Apply a 100Hz square wave via 25pF capacitance standardiser and adjust R178 for a flat top to the waveform.
- Repeat for R278 for channel 2.

5.5.8 CHANNELS 1 & 2 – DC STEP ATTENUATOR BALANCE

- Set to CH1 only, 20mV/cm sensitivity, input grounded, A timebase free running (AUTO).
- Centre the trace and adjust R179 so that there is no trace movement when the attenuator is switched between 20mV/cm and 50mV/cm.
- Repeat for Channel 1 2/5mV balance adjusting R180.
- Repeat for Channel 2, 20/50mV balance adjusting R279.
- Repeat for Channel 2, 2/5mV balance adjusting R280.

5.5.9 CHANNELS 1 & 2 – INVERT BALANCE

- Set the instrument as for 5.5.8 1. above.
- Centre the trace and adjust R182 for no movement when the invert switch is operated.
- Repeat for Channel 2, adjusting R282.

5.5.10 OUTPUT BALANCE

- Set the instrument to CH1 only, 10mV/cm.
- Apply 100MHz from the generator and adjust for 4cm display. Trigger the waveform.
- Adjust R341 so that any limiting that occurs as the shift control is operated is symmetrical about the centre of the graticule.

5.5.11 ADD MODE BALANCE

- Set the instrument to DUAL, free run the timebase and centre both traces.
- Check that when ADD is selected trace movement is less than 5mm. If necessary, adjust either R333 (A.O.T.) or R334 (A.O.T.) to achieve this.

5.5.12 CHANNELS 1 & 2 GAIN CALIBRATION

- Set the instrument to CH1 only, 10mV/cm. Apply

a 50mV peak to peak squarewave from an oscilloscope calibrator, set the timebase to a suitable speed and trigger the waveform. Adjust R181 for exactly 5cm amplitude.

2. Set the instrument to 2mV/cm. Apply 10mV p.p. and adjust R183 for exactly 5cm amplitude.
3. Check the variable gain pot reduces the display amplitude to between 1 and 2cm, and is smooth in operation. Check the "UNCAL" i.e.d. operates.
4. Repeat step 1 for CH2 adjusting R281.
5. Repeat step 2 for CH2 adjusting R283.
6. Repeat step 3 for CH2.

5.5.13 CHANNELS 1 & 2 ATTENUATOR COMPENSATION

1. Select CH1 only 0.1V/cm, set the calibrator to give 5cm amplitude, adjust C65 for a square corner.
2. Select 1V/cm sensitivity, reset the calibrator and adjust C67 for a square corner.
3. Fit a 25pF capacitance standardiser in series with the input, select 10mV/cm sensitivity and adjust C69 for a square corner.
4. Select 0.1V/cm and repeat adjusting C71.
5. Select 1V/cm and repeat adjusting C73.
6. Select CH2 only and repeat steps 1-5 above, adjusting C66, 68, 70, 72, 74 respectively.

5.5.14 CH1 & CH2 ATTENUATOR ACCURACY

Using the calibrator, check all attenuator ranges on both channels for $\pm 3\%$ accuracy and square corner.

5.5.15 CH1 & CH2 INVERT SWITCHES

Invert a 5cm square wave and check that the amplitude does not change.

5.5.16 CH1 & CH2 INPUT LEAKAGE

Select 2mV/cm sensitivity and check that the trace movement when the input coupling is switched from DC to GND is less than 1mm on both channels.

5.5.17 Y AMPLIFIER PULSE RESPONSE

NOTE: If there is any reason to suspect that there are significant timebase H.F. calibration errors, these should be checked and rectified before proceeding further as the pulse response measurements will otherwise be invalid.

1. Select Channel 1, 10mV/cm, d.c. coupled A timebase only to 0.1 μ s/cm. Apply a 1ns risetime pulse, 1MHz repetition rate via a 50 Ω termination and adjust the level to give about 5cm amplitude.
2. Adjust C125 and C313 on the pre-amplifier and C408 and 409 on the output driver for optimum pulse responses paying particular attention to obtaining a square corner. It will be necessary to adjust each trimmer several times to achieve the best compromise.

3. Select Channel 2 10mV/cm d.c. coupled and adjust C225 for optimum pulse response, also readjusting C313 if necessary to obtain the best compromise and similarity between both channels.
4. Recheck channel 1 and readjust C125 if necessary.
5. Check the risetime < 3.5 ns on both channels.
6. Recheck the pulse response with a 100kHz repetition rate pulse.

5.5.18 Y BANDWIDTH

1. Select channel 1 10mV/cm sensitivity d.c. coupled. Connect a constant Amplitude Generator via a 50 Ω termination.
2. Switch to the reference frequency and adjust for 5cm deflection. Increase the generator frequency until the amplitude displayed drops to 3.5cm. The frequency should be greater than 100MHz.
3. Check the bandwidth on the 50mV, 20mV, 5mV and 2mV ranges. All should be greater than 100MHz, except the 2mV range which should be greater than 85MHz.
4. Repeat the procedure for channel 2. Should the bandwidth prove inadequate recheck the pulse response, paying particular attention to obtaining a square corner.

TIMEBASE ADJUSTMENTS

5.5.19 X MEAN PLATE POTENTIAL

1. Set the timebase to 0.1ms/cm x1, A only, the trigger to AUTO and the trigger level for a stable trace.
2. Adjust shift control to bring the start of the trace to the centre of the screen. Using the test oscilloscope, check that the sweep start voltage on each plate lies between +26V and +32V. Adjust AOT resistor R972 if necessary to achieve this.
3. Repeat for x10 expansion, adjusting R971 if necessary.

5.5.20 PRESET CONTRAST

1. Set the timebase to A intensified by B, 0.2ms/cm (A), 50 μ s/cm (B), delay to 3.0.
2. Adjust R850 for 8V "B" bright-up step at the junction of the collectors of TR1003 and TR1004 measured with the test oscilloscope. These transistors are on the power supply p.c.b. BEWARE HIGH VOLTAGE ON THE P.C.B.

5.5.21 A TRIGGER BALANCE ADJUSTMENTS

1. Set the instrument to AC, CH1, A only, 0.1ms/cm and AUTO. Apply a 10kHz sinewave of about 6cm amplitude on the display, set the A TRIGGER LEVEL to centre and the input to AC TRIGGER coupling, with CH1 as source. Adjust R520 on the

trigger p.c.b. for the trace to start approximately central in the waveform.

2. Set the TRIGGER COUPLING to DC, adjust R184 (DC TRIG. BAL.) on the Y preamplifier p.c.b. for no trigger level movement between DC coupling and AC coupling. Select the TRIGGER SOURCE to CH2, apply the input signal and repeat the procedure with R284 (CH2 DC TRIG. BAL.).
3. Select CH1 and CH2 ALTERNATE, Y inputs to AC and position both traces central on the graticule. Apply the same 10kHz input to both channels. Select COMPOSITE TRIGGER SOURCE and adjust R356 (COMP. TRIG. BAL.) on the preamplifier p.c.b. for no trace movement between AC and DC trigger coupling.
4. Select CH1 and apply a low level signal to occupy about 2mm of trace. Adjust the trigger level for stable trigger and select the TRIGGER VIEW facility. Adjust the TRIGGER VIEW BALANCE R382 for a "TRIGGER VIEW" trace in the centre of the c.r.t.

5.5.22 B TRIGGER ADJUSTMENT

1. Select CH1, AC TRIGGER SOURCES A to B to CH1, with TRIG COUPLING on AC. Set A timebase to 0.2ms/cm and B timebase to 0.1ms/cm. Select A INTENS BY B.
2. Adjust the A TRIGGER LEVEL control for a stable trigger with a 10kHz sinewave applied to CH1. (about 6cms).
3. Adjust the B TRIGGER LEVEL control for an intensified B trace. Change the HORIZONTAL MODE to B ONLY.
4. Set the B TRIGGER LEVEL control to centre and adjust R609 (B TRIG LEVEL BAL) for the start of trace to commence at the mid-point of the sinewave amplitude. Return to A ONLY and B STARTS AFTER DELAY.

5.5.23 EXTERNAL X A COMPENSATION

1. Set TRIGGER SOURCE to EXT and the VERTICAL MODE to TRIG VIEW, TRIGGER COUPLING to DC. Apply no LF or HF REJECT.
2. Apply a 0.25V 1kHz square wave from the calibrator to the EXT A input and adjust C588 for a square corner on the waveform.
3. Apply 0.5V 1kHz via a 25pF standardiser and adjust C589 for a flat top to the waveform.
4. Apply a 2.5V 1kHz direct, select EXT \div 10 and adjust C545 and C547 for a square corner and flat top.

5.5.24 EXTERNAL X B COMPENSATION

1. Centre the B TRIG LEVEL control. Set the TRIGGER SOURCE to EXT and TRIGGER

COUPLING TO DC. Connect the probe of the test oscilloscope to the emitter of TR522.

2. Apply a 2.5V 1kHz square wave from the calibrator to the EXT B input and adjust C581 for a square corner to the displayed waveform.
3. Apply 5V 1kHz via the standardiser and adjust C583 for a flat top to the waveform.
4. Apply 5V 1kHz direct, select EXT \div 10 and adjust C562 and C563 for a square corner and flat top.

5.5.25 A TIMEBASE CALIBRATION

1. Set the Y VERTICAL MODE to CH1 with input at DC, 1V/cm. Set the HORIZONTAL MODE to 'A INTENS BY B'. A TIME/cm to 1ms, B TIME/cm to 1 μ s.
2. Using the digital multimeter set on the 10V range apply to the tags of the DELAY control which connect to pins 10 and 9 of SKV. Adjust R915 for a reading of 4.00 volts.
3. Set the DELAY control to minimum and adjust the X shift control for the intensified trace to begin at the first graticule vertical marking. Set the DELAY control to maximum and adjust R960 for the intensified trace to begin on the last graticule vertical marking. Return the DELAY control to minimum again and check the intensified trace alignment with the first vertical. Re-adjust R960 as necessary such that full adjustment of the DELAY control gives 10cm of movement on the intensified trace \pm 2mm.
4. Select 'A' only and apply 0.1ms markers from the TIMEMARK GENERATOR to the CH1 input. Adjust R767 for 1 pulse/cm with the A TIME/cm set at 0.1ms/cm.
5. Apply 1 μ s markers, set the A TIME/cm to 1 μ s/cm and adjust C722 for 1 pulse/cm.
6. Apply 1ms markers, set the A TIME/cm to 1ms/cm and adjust R761 for 1 pulse/cm.
7. Apply 10 μ s/cm markers, set the TIME/cm to 0.1ms/cm, pull x10 switch and adjust R957 for one pulse/cm.
8. Set the trimmers C815 and C816 for minimum, and apply 10ns markers. The A TIME/cm should be set to 50ns/cm and the x10 switch pulled on, set C815 and C816 by adjusting in equal amounts of capacitance on each such that the best trace linearity and accuracy are obtained. One pulse every 2cm should be displayed.

5.5.26 B TIMEBASE CALIBRATION

1. Select the HORIZONTAL MODE to 'B' and apply an input of 0.1ms markers. Set the A TIME/cm to 0.2ms/cm and the B TIME/cm to 0.1ms/cm. The DELAY control should be set to zero and the 'B TRIGGER LEVEL' at the B STARTS AFTER

- DELAY position. Adjust R833 for one pulse/cm.
- Apply 1 μ s markers, set the A TIME/cm to 2 μ s/cm and the B TIME/cm to 1 μ s/cm. Adjust C741 for 1 pulse/cm.
 - Apply 1ms markers, set the A TIME/cm to 2ms/cm and the B TIME/cm to 1ms/cm. Adjust R816 for 1 pulse/cm.
 - Set the A TIME/cm to 0.2ms/cm and the B TIME/cm to 0.1ms/cm. Select A & B ALTERNATE MODE, check that the A trace and B trace start within ± 2 mm of each other. If not, change R827 (nominally 470 Ω) AOT to suit. R827 should be changed to 560 Ω if the B trace starts early or to 390 Ω if it starts late.

5.5.27 X-Y CALIBRATION

- Apply a 160mV 1kHz square wave signal at CH1 with the CH1 attenuator at 20mV/cm and input d.c. coupled. Select CH2 VERTICAL MODE & GROUNDED, CH1 TRIGGER SOURCE AND DC TRIGGER COUPLING.
- Select X-Y MODE and adjust R512 on the Trigger p.c.b. for exactly 8cm of horizontal display. (Note the calibration specification CH1 $\pm 5\%$ CH2 $\pm 15\%$).

5.5.28 X-Y PHASE ALIGNMENT

- Apply 5cms of 50kHz reference signal from an HF signal generator to CH1 & CH2 inputs. A 45 $^\circ$ line trace should now be visible on the c.r.t.
- Increase the frequency to 500kHz and the line may be observed to open out to an ellipse. Adjust the value of C506 (220pF) AOT for the ellipse to close to a line again. Check that the line does not separate more than 2mm for frequencies up to 500kHz.

5.6 CALIBRATION PROCEDURE WITH DM3010 OPTION

NOTE: It is assumed that the oscilloscope has been set according to the calibration details and that the internal set up procedure for the DM3010 has been followed in accordance with the DM3010 handbook.

5.6.1 TIMEBASE - TIME MEASUREMENT CALIBRATION

This setting procedure for the timebase with the DM3010 involves some repetition of oscilloscope adjustments described in Section 5.5 of this handbook but with the special requirements of the add on d.v.m. and the greater setting accuracy needed. All variable controls should be set to the CAL positions.

- Select CH1 VERTICAL MODE with INPUT COUPLING at DC and Y sensitivity at about 1V/cm (suitable to display about 5cm of Time-mark Generator amplitude).
- Insert the Timemark Generator to CH1 input. Set the HORIZONTAL MODE to A INTENS BY

- Set the A TIME/cm to 0.1ms and the B TIME/cm to 1 μ s. Apply 10 μ s markers.
- Set the DELAY control to near to minimum on the oscilloscope and the v/t control on the DM3010 control to minimum. Select TIME MEASURE and INPUT SCOPE on the DM3010.
- Pull the X x10 switch and observe the bright-ups at the beginning of the sweep. Adjust R96 on the DM3010 for alignment of the two bright-ups. The slope of the marker signal is useful for achieving this. Adjust the oscilloscope DELAY control to align with the leading edge of the first marker, and the R96 for coincidence.
- Turn the front panel v/t control to its fully clockwise end. Using the 4 $\frac{1}{2}$ digit DVM, measure the voltage between pin 11 (the wiper of R18) and pin 10 (0V). Adjust R54 in the DM3010 for a reading of 4.000V.
- Apply 0.1ms markers. Return the x10 switch to the x1 position. Increase the v/t control to maximum. The DM3010 should display 1.000ms ± 12 digits. Adjust R960 (X AMPLIFIER x 1 GAIN) for the two bright-ups to appear exactly 10cms apart. Adjust preset R767 so that 1 marker/cm is displayed.
- Apply 50 μ s markers. Advance the DELAY control (OS3600) such that the first bright-up occurs on the first available marker and check that the 21st available marker is intensified by the second bright-up. Now press the B ONLY mode. Readjust R767 for exact coincidence of the two B traces.
- Return the v/t control to read 0.500ms and check that the 11th marker is displayed. (Return to the A INTENS B position to check this). Adjust the v/t control for coincidence of the 1st and 11th markers on the B traces and check that the DM3010 reads 0.500ms ± 7 digits. Return the v/t control to maximum.
- Set the A TIME/cm switch to 1 μ s and the B TIME/cm to 100ns. Apply 500ns markers. Select the A INTENS BY B mode. Set the DELAY control for the first bright-up to occur on the first available marker. With the v/t control on the DM3010 set at maximum, adjust C722 on the OS3600 timebase p.c.b. for two markers/cm to be displayed. The second bright-up should now occur coincident with the 21st available marker. Select the B ONLY mode and apply final adjustment to C722 so that the two B traces coincide. The DM3010 should now read 10.00 μ s ± 12 digits.
- Set the DM3010 v/t control so that the 11th marker is displayed. (Referring back to the A INTENS BY B position) and align the two B traces. The DM3010 should read 5.00 μ s ± 7 digits.
- Since the presets C722 and R767 are slightly interactive (by approx $\pm 0.1\%$) it is best to re-check the

calibration at step 7, readjusting R767 if necessary.

12. Set the A TIME/cm switch back to $1\mu\text{s}/\text{cm}$ again and apply 100ns markers. Select A INTENS BY B (or A ONLY) and pull the x10 switch on the X SHIFT control. Adjust R957 (X x10 GAIN CONTROL) for 1 marker/cm.
13. Set the A TIME/cm switch and the B TIME/cm switch to 50ns. Apply 10ns markers. With the x10 function still selected and the X SHIFT control approximately central, adjust the trimmers C815, C816 for one marker every two centimetres. This is most easily done by firstly setting the trimmers to minimum capacitance and then adjusting each by the same amount of capacitance until the best linearity and accuracy can be obtained.
14. Select the A INTENS BY B position and return the X SHIFT switch to the x1 position. With the same setting as for the previous test, adjust the v/t control on the DM3010 to MINIMUM. Set the DELAY control (OS3600) to align with the leading edge of the first available marker. Pull the x10 control again and select the B ONLY mode. By connecting a small trimmer 0–20pF across the appropriate A.O.T. pins C754 or C755 set the two B traces for alignment. Remove the trimmer measure its value and replace it by a fixed capacitor of nearest preferred tolerance. The B trace alignment should now be within 1ns. This adjustment equalises for differential delay which may exist between the two comparators IC710a and IC710b. Note that if B trace coincidence is already within 1ns no adjustment need be made.
15. Apply 0.5ms markers. Set the A TIME/cm to 1ms and the B TIME/cm to 0.1ms. Select A INTENS BY B and return the x10 switch to the x1 position. Set the DM3010 v/t control to maximum. Adjust the DELAY control (OS3600) to align the first bright-up on the first available marker. Adjust R761 for 2 markers/cm with the second bright-up occurring on the 21st available marker. Now select B ONLY adjust R761 for coincidence of the B traces. The DM3010 should now indicate $10.00\text{ms} \pm 12$ digits.
16. Set the DM3010 v/t control to display the 11th marker pulse (using the A INTENS BY B mode). Align the v/t control for coincidence of the B traces on the B ONLY mode and check that the DM3010 reads $5.00\text{ms} \pm 7$ digits.
17. Check the DM3010 calibration with the OS3600 oscilloscope on the remaining timebase ranges to be within the specification accuracy. Also check that the full scale indication of the DM3010 is 10 times the A TIME/cm reading.

5.6.2 TIMEBASE – FREQUENCY CALIBRATION

The additional calibration is required for the $\frac{1}{T}$ (FREQUENCY) function. Correct operation of each range

should be checked by setting the v/t control for a 1cm delay in the TIME mode and then check each A Time-base range for an equivalent full scale display in the $\frac{1}{T}$ (FREQUENCY) mode. Repeat for 10cm display, checking for the equivalent $\frac{1}{10}$ full scale display.

5.6.3 Y DEFLECTION – VOLTAGE CALIBRATION

1. Select A ONLY, 0.5ms/cm and CH1 display and trigger, AC INPUT COUPLING. Select 'SCOPE' input and volts measurement. Set the CH1 attenuator switch to 10mV/cm.
2. Apply a 100mV calibration signal (1kHz square wave) and set the v/t control on the DM3010 to maximum. Adjust the Y CH1 shift approximately to set the top peaks of the lower (scope Y shift) trace with the bottom peaks of the DM3010 Y-shifted trace approximately in the centre of the c.r.t. display. Adjust R185 so that the top 'SCOPE' Y shift peaks occur on the same horizontal line as the DM3010 bottom peaks (as set by the v/t control). See Fig. 5.2. It is useful to adjust to the horizontal centre line of the graticule to achieve this.
The DM3010 should now read 100.0mV.
3. Now apply a 50mV calibration signal and re-adjust the DM3010 v/t control for trace coincidence as in step 2. Check that the DM3010 reads 50.0mV ± 12 digits.
4. Check all the remaining CH1 VOLTS/cm ranges for calibration accuracy as per step 2 to be within specification noting that the F.S.D. of the DM3010 reads 10 scale divisions in each case.

NOTE that the dynamic range of the oscilloscope amplifier limits the accuracy at extremes of signal input, i.e. beyond 8cm deflection from the centre. For this reason the above calibration uses a 10cm pk/pk signal a.c. coupled. D.C coupling of a unipolar 10cm signal would cause inaccuracy.

ABBREVIATIONS USED FOR COMPONENT DESCRIPTIONS

RESISTORS

| | | | | |
|-----|-----------------------------|----|-----|-------------------------|
| CC | Carbon Composition | ½W | 10% | unless otherwise stated |
| CF | Carbon Film | ¼W | 5% | unless otherwise stated |
| MO | Metal Oxide | ½W | 2% | unless otherwise stated |
| MF | Metal Film | ¼W | 2% | unless otherwise stated |
| MG | Metal Glaze | | 5% | unless otherwise stated |
| WW | Wire Wound | 6W | 5% | unless otherwise stated |
| CP | Control Potentiometer | | 20% | unless otherwise stated |
| PCP | Preset Potentiometer Cermet | | 20% | unless otherwise stated |

CAPACITORS

| | | | | |
|-------|-------------------------------|------|--------------|-------------------------|
| CE(1) | Ceramic | | +40% -20% | unless otherwise stated |
| CE(2) | Ceramic | 500V | ±10% | unless otherwise stated |
| CE(3) | Ceramic | 50V | ±10% | unless otherwise stated |
| SM | Silver Mica | 350V | | |
| PF | Plastic Film | | ±10% | unless otherwise stated |
| PS | Polystyrene | 63V | ±2½% | unless otherwise stated |
| PE | Polyester | | ±10% | unless otherwise stated |
| PC | Polycarbonate | | | |
| E | Electrolytic (aluminium) | | +50% -10% | unless otherwise stated |
| T | Electrolytic (solid tantalum) | | +50% -10% | unless otherwise stated |
| FT | Foil Trimmer | | | unless otherwise stated |




Fig. 2 T/B Waveforms Normal 'A' Sweep





Fig. 3 T/B Waveforms Dual Operation




Fig. 4 T/B Waveforms DM3010 Time




Fig. 5 T/B Waveforms DM3010 Voltage

Component List and Illustrations

Section 6

OS3600 TRIGGER

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|------------------|-------|-------------|----------------|---------|-------------------------|-------|-------------|--------|---------|
| RESISTORS | | | | | RESISTORS (Cont) | | | | |
| R15 | 1.1k | MF | 0.5 1/8W | 41784 | R549 | 68 | CF | | 28716 |
| R23 | 27 | CF | | 28711 | R550 | 150 | CF | | 28719 |
| R24 | 27 | CF | | 28711 | R551 | 150 | CF | | 28719 |
| R25 | 22 | CF | | 28710 | R552 | 3k3 | CF | | 21803 |
| R26 | 22 | CF | | 28710 | R553 | 10 | CF | | 21793 |
| R501 | 390k | MF | | 38656 | R554 | 3k3 | CF | | 21803 |
| R502 | 100 | CF | | 21794 | R555 | 10 | CF | | 21793 |
| R503 | 560 | CF | | 21798 | R556 | 22 | CF | | 28710 |
| R504 | 390 | MF | | 38584 | R557 | 100 | CF | | 21794 |
| R505 | 390 | MF | | 38584 | R558 | 22 | CF | | 28710 |
| R506 | 560 | CF | | 21798 | R559 | 22 | CF | | 28710 |
| R507 | 6k8 | CF | | 21807 | R560 | 10 | CF | | 21793 |
| R508 | 820 | CF | | 28724 | R561 | 1k | CF | | 21799 |
| R509 | 1k5 | MF | | 38598 | R562 | 27 | CF | | 28711 |
| R510 | 2k | MF | | 38601 | R563 | 27 | CF | | 28711 |
| R511 | 910 | MF | | 38593 | R564 | 270 | CF | | 28720 |
| R512 | 500 | PCP | | 39232 | R565 | 270 | CF | | 28720 |
| R513 | 6k8 | MF | | 38614 | R566 | 2k2 | CF | | 21802 |
| R514 | 12k | MF | | 38620 | R567 | 390 | CF | | 28722 |
| R515 | 120 | CF | | 28718 | R568 | 47 | CF | | 28714 |
| R516 | 82 | CF | | 28717 | R569 | 330 | CF | | 28721 |
| R517 | 1k8 | CF | | 28725 | R570 | 330 | CF | | 28721 |
| R518 | 100k | CF | | 21819 | R571 | 330 | CF | | 28721 |
| R519 | 10 | CF | | 21793 | R572 | 300 | CF | | 38581 |
| R520 | 20k | PCP | | 39235 | R573 | 560 | CF | | 21798 |
| R521 | 5k6 | CF | | 21806 | R574 | 1k5 | MF | | 38598 |
| R522 | 22k | CP | "A" Trig Level | 38676 | R575 | 1k2 | MF | | 38596 |
| R523 | 4k7 | CF | | 21805 | R576 | 390 | MF | | 38584 |
| R524 | 100 | CF | | 21794 | R577 | 330 | CF | | 28721 |
| R525 | 3k3 | CF | | 21803 | R578 | 47 | CF | | 28714 |
| R526 | 1k | MF | | 38594 | R579 | 47 | CF | | 28714 |
| R527 | 680 | CF | | 28723 | R580 | 430 | MF | | 38585 |
| R528 | 62 | MF | | 38565 | R581 | 10 | CF | | 21793 |
| R529 | 47 | CF | | 28714 | R582 | 47k | CF | | 21815 |
| R530 | 47 | CF | | 28714 | R583 | 12k | CF | | 21810 |
| R531 | 180 | MF | | 38576 | R584 | 68k | CF | | 21816 |
| R532 | 180 | MF | | 38576 | R585 | 560k | CF | | 32359 |
| R533 | 820 | CF | | 28724 | R586 | 270 | CF | | 28720 |
| R534 | 560 | CF | | 21798 | R587 | 470 | CF | | 21797 |
| R535 | 10k | CF | | 21809 | R588 | 100k | CF | | 21819 |
| R536 | 10 | CF | | 21793 | R589 | 10k | CF | | 21809 |
| R537 | 10 | CF | | 21793 | R590 | 56 | CF | | 28715 |
| R538 | 56 | CF | | 28715 | R591 | 1k5 | CF | | 21801 |
| R539 | 56 | CF | | 28715 | R592 | 8k2 | CF | | 21808 |
| R540 | 39 | CF | | 28713 | R593 | 270 | CF | | 28720 |
| R541 | 39 | CF | | 28713 | R594 | 3k9 | CF | | 21804 |
| R542 | 680 | CF | | 28723 | R595 | 2k2 | CF | | 21802 |
| R543 | 820 | CF | | 28724 | R596 | 680 | CF | | 28723 |
| R544 | 270 | CF | | 28720 | R597 | 10 | CF | | 21793 |
| R545 | 270 | CF | | 28720 | R598 | 220k | CF | | 21823 |
| R546 | 47 | CF | | 28714 | R599 | 47 | CF | | 28714 |
| R547 | 2k2 | CF | | 21802 | R600 | | | | |
| R548 | 68 | CF | | 28716 | R601 | 390k | MF | | 38656 |
| | | | | | R602 | 100 | CF | | 21794 |
| | | | | | R603 | 390 | MF | | 38584 |

Component List and Illustrations

Section 6

OS3600 TRIGGER (Cont)

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|-------------------------|-------|-------------|-------------------------------|---------|-------------------------|--------|-------------|------------|---------|
| RESISTORS (Cont) | | | | | RESISTORS (Cont) | | | | |
| R604 | 220 | CF | | 21796 | R658 | 100 | CF | | 21794 |
| R605 | 560 | CF | | 21798 | R659 | | | | |
| R606 | 390 | MF | | 38584 | R660 | 43k | MF | | 38633 |
| R607 | 3k3 | CF | | 21803 | R661 | 300k | MF | | 38653 |
| R608 | 3k3 | CF | | 21803 | R662 | 39 | CF | | 28713 |
| R609 | 20k | PCP | | 39235 | R663 | | | | |
| R610 | 5k6 | CF | | 21806 | R664 | 3k3 | CF | | 21803 |
| R611 | 4k7 | CF | | 21805 | R665 | 3k3 | CF | | 21803 |
| R612 | 22k | CP | "B" Trig Level (With S516) | 38677 | R671 | 39 | CF | | 28713 |
| R613 | 100 | CF | | 21794 | R672 | 300k | MF | | 38653 |
| R614 | 56 | CF | | 28715 | R673 | 43k | MF | | 38633 |
| R615 | 56 | CF | | 28715 | R674 | 300k | MF | | 38653 |
| R616 | 1k | CF | | 21799 | R675 | 360k | MF | | 38655 |
| R617 | 62 | MF | | 38565 | R676 | 360k | MF | | 38655 |
| R618 | 330 | CF | | 28721 | R677 | 300k | MF | | 38653 |
| R619 | 180 | MF | | 38576 | CAPACITORS | | | | |
| R620 | 180 | MF | | 38576 | C501 | .01μF | CE(1) | 250V | 22395 |
| R621 | 820 | CF | | 28724 | C502 | .01μF | CE(1) | 250V | 22395 |
| R622 | 100 | CF | | 21794 | C503 | .01μF | CE(1) | 250V | 22395 |
| R623 | 100 | CF | | 21794 | C504 | .01μF | CE(1) | 250V | 22395 |
| R624 | 10 | CF | | 21793 | C505 | .01μF | CE(1) | 250V | 22395 |
| R625 | 56 | CF | | 28715 | C506 | 82pF | PS | A.O.T. 63V | 37685 |
| R626 | 56 | CF | | 28715 | C507 | .01μF | CE(1) | 250V | 22395 |
| R627 | 270 | CF | | 28720 | C508 | 10pF | CE(2) | | 22364 |
| R628 | 270 | CF | | 28720 | C509 | 15pF | CE(2) | | 22366 |
| R629 | 39 | CF | | 28713 | C510 | 220pF | CE(2) | | 22379 |
| R630 | 39 | CF | | 28713 | C511 | .01μF | CE(1) | 250V | 22395 |
| R631 | 680 | CF | | 28723 | C512 | 1000pF | CE(2) | | 22387 |
| R632 | 22 | CF | | 28710 | C513 | .01μF | CE(1) | 250V | 22395 |
| R633 | 22 | CF | | 28710 | C514 | 82pF | CE(2) | | 22375 |
| R634 | 270 | CF | | 28720 | C515 | .01μF | CE(1) | 250V | 22395 |
| R635 | 27 | CF | | 28711 | C516 | 33pF | CE(2) | | 22370 |
| R636 | 27 | CF | | 28711 | C517 | .01μF | CE(2) | 250V | 22395 |
| R637 | 270 | CF | | 28720 | C518 | 39pF | CE(2) | | 22371 |
| R638 | 1k | CF | | 21799 | C519 | .01μF | CE(1) | 250V | 22395 |
| R639 | 10 | CF | | 21793 | C520 | .01μF | CE(1) | 250V | 22395 |
| R640 | 22 | CF | | 28710 | C521 | 22pF | CE(2) | | 22368 |
| R641 | 2k2 | CF | | 21802 | C522 | 15pF | CE(2) | | 22366 |
| R642 | 390 | CF | | 28722 | C523 | .01μF | CE(1) | 250V | 22395 |
| R643 | 47 | CF | | 28714 | C524 | .01μF | CE(1) | 250V | 22395 |
| R644 | 330 | CF | | 28721 | C525 | .01μF | CE(1) | 250V | 22395 |
| R645 | 330 | CF | | 28721 | C526 | .01μF | CE(1) | 250V | 22395 |
| R646 | 330 | CF | | 28721 | C527 | 5600pF | CE(1) | 500V | 22394 |
| R647 | 300 | MF | | 38581 | C528 | 10μF | E | 25V | 32180 |
| R648 | 560 | CF | | 21798 | C529 | 10μF | E | 25V | 32180 |
| R649 | 390 | MF | | 38584 | C530 | .01μF | CE(2) | 250V | 22395 |
| R650 | 1k5 | MF | | 38598 | C531 | .1μF | PE | 100V | 37018 |
| R651 | 1k2 | MF | | 38596 | C532 | .1μF | PE | 100V | 37018 |
| R652 | 10 | CF | | 21793 | C533 | 120pF | CE(2) | | 22377 |
| R653 | 10 | CF | | 21793 | C534 | .01μF | CE(1) | 250V | 22395 |
| R654 | 330 | CF | | 28721 | C535 | 270pF | CE(2) | | 22380 |
| R655 | 47 | CF | | 28714 | C536 | .01μF | CE(1) | 250V | 22395 |
| R656 | 10 | CF | | 21793 | C537 | .01μF | CE(1) | 250V | 22395 |
| R657 | 47k | CP | Hold Off | 38674 | C538 | .01μF | CE(1) | 250V | 22395 |

Component List and Illustrations

Section 6

OS3600 TRIGGER (Cont)

| Ref | Value | Description | Tol % ± | Part No | Ref | Value | Description | Tol % ± | Part No |
|--------------------------|--------|-------------|--------------|---------|----------------------------|-------------------------|--------------|---------|----------|
| CAPACITORS (Cont) | | | | | TRANSISTORS (Cont) | | | | |
| C539 | 47pF | CE(2) | | 22372 | TR505 | 2N3904 | | | 24146 |
| C540 | | | | | TR506 | 2N3904 | | | 24146 |
| C541 | 5600pF | CE(1) | 500V | 22394 | TR507 | MPSH10 | | | 40315 |
| C542 | 100pF | CE(2) | | 22376 | TR508 | MPSH10 | | | 40315 |
| C543 | 0.1μF | CE(1) | 250V | 39199 | TR509 | BF479 | | | 39270 |
| C544 | .01μF | CE(1) | 250V | 22395 | TR510 | BF479 | | | 39270 |
| C545 | 15pF | TRIMMER | | 32059 | TR511 | MPSH10 | | | 40315 |
| C546 | 56pF | CE(2) | | 22373 | TR512 | MPSH10 | | | 40315 |
| C547 | 15pF | TRIMMER | | 32059 | TR513 | MPSH10 | | | 40315 |
| C548 | 15pF | CE(2) | | 22366 | TR514 | MPSH10 | | | 40315 |
| C549 | 15pF | CE(2) | | 22366 | TR515 | MPSH10 | | | 40315 |
| C550 | .01μF | CE(1) | 250V | 22395 | TR516 | 2N5771 | | | 38089 |
| C551 | .01μF | CE(1) | 250V | 22395 | TR517 | MPSH10 | | | 40315 |
| C552 | .01μF | CE(1) | 250V | 22395 | TR518 | BC182B | | | 33205 |
| C553 | 220pF | CE(2) | | 22379 | TR519 | | | | |
| C554 | .01μF | CE(1) | 250V | 22395 | TR520 | WD392 | Dual f.e.t. | | A36243 |
| C555 | 33pF | CE(2) | | 22370 | TR521 | | | | |
| C556 | 15pF | CE(2) | | 22366 | TR522 | AE13 | Matched pair | | A31254 |
| C557 | .01μF | CE(1) | 250V | 22395 | TR523 | | | | |
| C558 | 39pF | CE(2) | | 22371 | TR524 | MPSH10 | | | 40315 |
| C559 | .01μF | CE(1) | 250V | 22395 | TR525 | MPSH10 | | | 40315 |
| C560 | 33pF | CE(2) | | 22370 | TR526 | BF479 | | | 39270 |
| C561 | .01μF | CE(1) | 250V | 22395 | TR527 | BF479 | | | 39270 |
| C562 | 15pF | TRIMMER | | 32059 | TR528 | MPSH10 | | | 40315 |
| C563 | 15pF | TRIMMER | | 32059 | TR529 | MPSH10 | | | 40315 |
| C564 | 56pF | CE(2) | | 22373 | | | | | |
| C565 | .01μF | CE(1) | 250V | 22395 | DIODES | | | | |
| C566 | 22pF | CE(2) | | 22368 | D15 | L.E.D. | | | 39884 |
| C567 | 15pF | CE(2) | | 22366 | D501 | 5V1 | ZENER | | 33923 |
| C568 | .01μF | CE(1) | 250V | 22395 | D502 | | IN4148 | | 23802 |
| C569 | .01μF | CE(1) | 250V | 22395 | D503 | 3V3 | ZENER | | 33923 |
| C570 | .01μF | CE(1) | 250V | 22395 | D504 | 9V1 | ZENER | | 33934 |
| C571 | .01μF | CE(1) | 250V | 22395 | D505 | 6V2 | ZENER | | 33930 |
| C572 | 10μF | E | 10V | 40353 | D506 | | IN4148 | | 23802 |
| C573 | | | | | D507 | | IN4148 | | 23802 |
| C574 | | | | | D508 | | IN4149 | | 1949 |
| C575 | 100pF | CE(2) | | 22376 | D509 | | IN4149 | | 1949 |
| C576 | 0.1μF | CE(1) | 250V | 39199 | D510 | | IN4148 | | 23802 |
| C577 | .01μF | CE(1) | 250V | 22395 | D511 | | IN4148 | | 23802 |
| C581 | 15pF | TRIMMER | | 32059 | D512 | | IN3595 | | 29330 |
| C582 | 15pF | CE(2) | | 22366 | D513 | | IN3595 | | 29330 |
| C583 | 6pF | TRIMMER | | 29421 | D514 | | IN4148 | | 23802 |
| C584 | 0.01 | CE(1) | 250V | 22395 | D515 | 9V1 | ZENER | | 33934 |
| C585 | 22pF | CE(2) | | 22368 | INTEGRATED CIRCUITS | | | | |
| C586 | 22pF | CE(2) | | 22368 | IC501 | 10216 | | | 33903 |
| C587 | 10pF | CE(2) | | 22364 | IC502 | 10216 | | | 33903 |
| C588 | 15pF | TRIMMER | | 32059 | MISCELLANEOUS | | | | |
| C589 | 6pF | TRIMMER | | 29421 | S501-504 | Switch Push Button | | | |
| TRANSISTORS | | | | | | A Coupling | | | A3/40738 |
| TR501 | } | WD392 | Dual f.e.t. | A36343 | S505-507 | Switch Push Button | | | |
| TR502 | | | | | B Coupling | | A3/40737 | | |
| TR503 | } | AE13 | Matched pair | A31254 | S508-512 | Switch A Trigger Source | | | A3/41672 |
| TR504 | | | | | Switch B Trigger Source | | A3/42268 | | |

Component List and Illustrations

Section 6

OS3600 TRIGGER (Cont)

| <i>Ref</i> | <i>Value</i> | <i>Description</i> | <i>Tol %±</i> | <i>Part No</i> | <i>Ref</i> | <i>Value</i> | <i>Description</i> | <i>Tol %±</i> | <i>Part No</i> |
|-----------------------------|--------------|---------------------------------------|---------------|----------------|------------|--------------|----------------------|----------------|----------------|
| MISCELLANEOUS (Cont) | | | | | | | | | |
| S516 | | Switch Select B Gated Part of R612 | | 38677 | PLR | | Plug Molex 3-Way LKG | | 39222 |
| | | | | | SKCC | | Socket BNC | Ext. X A Input | 1222 |
| PLP | | Plug Molex 14-Way | | 38297 | SKDD | | Socket BNC | Ext X B Input | 1222 |

Component List and Illustrations

Section 6

OS3600 TIMEBASE, 'X' O/P & CALIBRATOR

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|------------------|-------|-------------|--------|---------|-------------------------|-------|-------------|--------|---------|
| RESISTORS | | | | | RESISTORS (Cont) | | | | |
| R701 | 10k | CF | | 21809 | R756 | 12k | CF | | 21810 |
| R702 | 2k2 | CF | | 21802 | R757 | 33k | CF | | 21814 |
| R703 | 180 | CF | | 21795 | R758 | 470k | CF | | 32330 |
| R704 | | | | | R759 | 470k | CF | | 32330 |
| R705 | | | | | R760 | 22k | CF | | 21812 |
| R706 | | | | | R761 | 5k | PCP | | 39234 |
| R707 | 2k2 | CF | | 21802 | R762 | 10k | CF | | 21809 |
| R708 | 4k7 | CF | | 21805 | R763 | 56 | CF | | 28715 |
| R709 | 270 | CF | | 28720 | R764 | 68k | CF | | 21816 |
| R710 | 1k2 | MF | | 38596 | R765 | 18k | MF | | 38624 |
| R711 | 470 | CF | | 21797 | R766 | 9k1 | MF | | 38617 |
| R712 | 3k3 | MF | | 38606 | R767 | 50k | PCP | | 39268 |
| R713 | 3k9 | CF | | 21804 | R768 | 5k6 | CF | | 21806 |
| R714 | 100 | CF | | 21794 | R769 | 39k | CF | | 28728 |
| R715 | 2k2 | CF | | 21802 | R770 | 2k7 | CF | | 28726 |
| R716 | 1k5 | CF | | 21801 | R771 | 910 | MF | | 38593 |
| R717 | | | | | R772 | 2k7 | CF | | 28726 |
| R718 | | | | | R773 | 390 | CF | | 28722 |
| R719 | 2k7 | CF | | 28726 | R774 | 47 | CF | | 28714 |
| R720 | 390 | CF | | 28722 | R775 | 47 | CF | | 28714 |
| R721 | 1k | CF | | 21799 | R776 | 47 | CF | | 28714 |
| R722 | 680 | CF | | 28723 | R777 | 15 | CF | | 28708 |
| R723 | 680 | CF | | 28723 | R778 | 10k | CF | | 21809 |
| R724 | 1k | CF | | 21799 | R779 | 1k2 | CF | | 21800 |
| R725 | 1k2 | CF | | 21800 | R780 | 39k | CF | | 28728 |
| R726 | 360 | MF | | 38583 | R781 | 33k | CF | | 21814 |
| R727 | 1k5 | CF | | 21801 | R782 | 390 | CF | | 28722 |
| R728 | 3k3 | CF | | 21803 | R783 | 3k9 | CF | | 21804 |
| R729 | 220 | CF | | 21796 | R784 | 1k | CF | | 21799 |
| R730 | 10 | CF | | 21793 | R785 | 470 | CF | | 21797 |
| R731 | 100 | CF | | 21794 | R786 | 680 | CF | | 28723 |
| R732 | 10 | CF | | 21793 | R787 | 2k7 | CF | | 28726 |
| R733 | 820 | MF | | 38592 | R788 | 8k2 | CF | | 21808 |
| R734 | 1k5 | CF | | 21801 | R789 | 1k | CF | | 21799 |
| R735 | 6k8 | CF | | 21807 | R790 | 2k2 | CF | | 21802 |
| R736 | 470 | CF | | 21797 | R791 | 3k9 | CF | | 21804 |
| R737 | 150k | MF | | 38646 | R792 | 470 | CF | | 21797 |
| R738 | 10k | CF | | 21809 | R793 | 220 | CF | | 21796 |
| R739 | 3k3 | CF | | 21803 | R794 | 39 | CF | | 28713 |
| R740 | 1k5 | CF | | 21801 | R795 | 470 | CF | | 21797 |
| R741 | 270k | CF | | 32356 | R796 | 10k | CF | | 21809 |
| R742 | 8k2 | CF | | 21808 | R797 | | | | |
| R743 | 10k | CF | | 21809 | R798 | 15 | CF | | 28708 |
| R744 | 10k | CF | | 21809 | R799 | 1k | CF | | 21799 |
| R745 | 220k | MF | | 38650 | R800 | 1k | CF | | 21799 |
| R746 | 15k | CF | | 28727 | R801 | 390 | CF | | 28722 |
| R747 | 15k | CF | | 28727 | R802 | 360 | MF | | 38583 |
| R748 | 470 | CF | | 21797 | R803 | 6k8 | CF | | 21807 |
| R749 | 510 | MF | | 38587 | R804 | 820 | MF | | 38592 |
| R750 | 10 | CF | | 21793 | R805 | 10 | CF | | 21793 |
| R751 | 560 | CF | | 21798 | R806 | 2k7 | CF | | 28726 |
| R752 | 220 | CF | | 21796 | R807 | 10 | CF | | 21793 |
| R753 | 1k5 | CF | | 21801 | R808 | 1k8 | CF | | 28725 |
| R754 | 1k5 | CF | | 21801 | R809 | 510 | MF | | 38587 |
| R755 | 8k2 | CF | | 21808 | R810 | 560 | CF | | 21798 |




Fig. 7A Timebase 'X' O/P & Calibrator Circuit Diagram

Component List and Illustrations

Section 6

OS3600 TIMEBASE, 'X' O/P & CALIBRATOR (Cont)

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|-------------------------|-------|-------------|--------|---------|-------------------------|-------|-------------|--------|---------|
| RESISTORS (Cont) | | | | | RESISTORS (Cont) | | | | |
| R811 | 15k | CF | | 28727 | R872 | 6k8 | CF | | 21807 |
| R812 | 1k5 | CF | | 21801 | R873 | 4k7 | CF | | 21805 |
| R813 | 10k | CF | | 21809 | R874 | 12k | CF | | 21810 |
| R814 | 8k2 | CF | | 21808 | | | | | |
| R815 | 22k | CF | | 21812 | R880 | 6k8 | CF | | 21807 |
| R816 | 5k | PCP | | 39234 | R881 | 120 | CF | | 28718 |
| R817 | 8k2 | CF | | 21808 | R882 | 100 | CF | | 21794 |
| R818 | 15k | CF | | 28727 | R883 | 12k | CF | | 21810 |
| R819 | 220 | CF | | 21796 | R884 | 12k | CF | | 21810 |
| R820 | 4R7 | CF | | 29433 | R885 | 100 | CF | | 21794 |
| R821 | 12k | CF | | 21810 | R886 | 5k6 | CF | | 21806 |
| R822 | 470k | CF | | 32330 | R887 | 47k | CF | | 21815 |
| R823 | 470k | CF | | 32330 | R888 | 47k | CF | | 21815 |
| R824 | 33k | CF | | 21814 | R889 | | | | |
| R825 | 3k3 | CF | | 21803 | R890 | 3k9 | CF | | 21804 |
| R826 | 470 | CF | | 21797 | R891 | 470 | CF | | 21797 |
| R827 | 430 | MF | | 38585 | R892 | | | | |
| R828 | 100 | CF | | 21794 | R893 | 3k3 | CF | | 21803 |
| R829 | 56 | CF | | 28715 | R894 | 390 | CF | | 28722 |
| R830 | 68k | CF | | 21816 | R895 | 390 | CF | | 28722 |
| R831 | 39k | CF | | 28728 | R896 | 560 | CF | | 21798 |
| R832 | 9k1 | MF | | 38617 | R897 | 47 | CF | | 28714 |
| R833 | 50k | PCP | | 39268 | R898 | 47 | CF | | 28714 |
| R834 | 18k | MF | | 38624 | R899 | 47k | CF | | 21815 |
| R835 | 5k6 | CF | | 21806 | R900 | 10 | CF | | 21793 |
| R836 | 1k2 | CF | | 21800 | R901 | 4k7 | CF | | 21805 |
| R837 | 47 | CF | | 28714 | R902 | 1k | CF | | 21799 |
| R838 | 1k5 | CF | | 21801 | R903 | 4k7 | CF | | 21805 |
| R839 | 39k | CF | | 28728 | R904 | 4k7 | CF | | 21805 |
| R840 | | | | | R905 | 4k7 | CF | | 21805 |
| R841 | 5k6 | CF | | 21806 | R906 | 10 | CF | | 21793 |
| R842 | 10k | CF | | 21809 | R907 | 6k8 | CF | | 21807 |
| | | | | | R908 | 6k8 | CF | | 21807 |
| R850 | 10k | PCP | | 39265 | R909 | 56k | CF | | 28729 |
| R851 | 4k3 | MF | | 38609 | R910 | 4k7 | CF | | 21805 |
| R852 | 5k6 | CF | | 21806 | R911 | 2k2 | CF | | 21802 |
| R853 | 3k9 | CF | | 21804 | R912 | 10k | CF | | 21809 |
| R854 | 2k2 | CF | | 21802 | R913 | 100 | CF | | 21794 |
| R855 | 10k | CF | | 21809 | R914 | 100 | CF | | 21794 |
| R856 | 2k2 | CF | | 21802 | R915 | 1k | PCP | | 39233 |
| R857 | 2k2 | CF | | 21802 | R916 | 680 | CF | | 28723 |
| R858 | 2k2 | CF | | 21802 | R917 | 100 | CF | | 21794 |
| R859 | 1k5 | CF | | 21801 | R918 | | | | |
| R860 | 1k5 | CF | | 21801 | R919 | 4k7 | CF | | 21805 |
| R861 | 4k7 | CF | | 21805 | R920 | 3k3 | CF | | 21803 |
| R862 | 4k7 | CF | | 21805 | R921 | 1k | CF | | 21799 |
| R863 | 4k7 | CF | | 21805 | R922 | | | | |
| R864 | 4k7 | CF | | 21805 | | | | | |
| R865 | 6k8 | CF | | 21807 | R928 | 270 | CF | | 28720 |
| R866 | 6k8 | CF | | 21807 | R929 | 22 | CF | | 28710 |
| R867 | 4k7 | CF | | 21805 | R930 | 1k | CF | | 21799 |
| R868 | 6k8 | CF | | 21807 | R931 | 620 | MF | | 38589 |
| R869 | 4k7 | CF | | 21805 | R932 | 47 | CF | | 28714 |
| R870 | 6k8 | CF | | 21807 | R933 | 220 | CF | | 21796 |
| R871 | 6k8 | CF | | 21807 | R934 | 220 | CF | | 21796 |

Component List and Illustrations

Section 6

OS3600 TIMEBASE, 'X' O/P & CALIBRATOR (Cont)

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|-------------------------|-------|-------------|----------|---------|-------------------|--------|-------------|--------|---------|
| RESISTORS (Cont) | | | | | CAPACITORS | | | | |
| R935 | 150k | MF | | 38646 | C701 | 1000pF | CE(2) | | 22387 |
| R936 | 150k | MF | | 38646 | C702 | .01μF | CE(1) | 250V | 22395 |
| R937 | 36k | MO | | 28811 | C703 | 10μF | E | 10V | 40353 |
| R938 | 36k | MO | | 28811 | C704 | .01μF | CE(1) | 250V | 22395 |
| R939 | 68 | CF | | 28716 | C705 | .01μF | CE(1) | 250V | 22395 |
| R940 | 680 | CF | | 28723 | C706 | 33pF | CE(2) | | 22370 |
| R941 | 330 | CF | | 28721 | C707 | 0.01μF | CE(1) | 250V | 22395 |
| R942 | 560 | CF | | 21798 | C708 | .01μF | CE(1) | 250V | 22395 |
| R943 | 68 | CF | | 28716 | C709 | 1μF | T | 35V | 34895 |
| R944 | 36k | MO | | 28811 | C710 | 47pF | CE(2) | | 22372 |
| R945 | 10 | CF | | 21793 | C711 | .01μF | CE(1) | 250V | 22395 |
| R946 | 470 | CF | | 21797 | C712 | 1μF | PE | 100V | 37389 |
| R947 | 47 | CF | | 28714 | C713 | .01μF | PE | 100V | 39190 |
| R948 | 6k8 | CF | | 21807 | C714 | 10μF | E | 10V | 40353 |
| R949 | 6k8 | CF | | 21807 | C715 | 220pF | CE(2) | | 22379 |
| R950 | 10 | CF | | 21793 | C716 | 56pF | CE(2) | | 22373 |
| R951 | 33k | MF | | 38630 | C717 | .1μF | PE | 100V | 37018 |
| R952 | 51k | MF | | 38635 | C718 | 68pF | CE(2) | | 22374 |
| R953 | 22 | CF | | 28710 | C719 | 2.2μF | PC | | 40853 |
| R954 | 10k | MF | | 38618 | C720 | .022μF | PC | | 40854 |
| R955 | 10k | MF | | 38618 | C721 | 180pF | SM | ½pF | 4515 |
| R956 | 470 | CF | | 21797 | C722 | 45pF | FT | | 36274 |
| R957 | 1k | PCP | | 39233 | C723 | .01μF | CE(1) | 250V | 22395 |
| R958 | 220 | CF | | 21796 | C724 | 10μF | E | 25V | 32180 |
| R959 | 220 | CF | | 21796 | C725 | | | | |
| R960 | 10k | PCP | | 39265 | C726 | .01μF | CE(1) | 250V | 22395 |
| R961 | 5k6 | CF | | 21806 | C727 | | | | |
| R962 | 2k2 | MF | | 38602 | C728 | .01μF | CE(1) | 250V | 22395 |
| R963 | 2k2 | MF | | 38602 | C729 | .01μF | CE(1) | 250V | 22395 |
| R964 | 4k7 | CF | | 21805 | C730 | .01μF | CE(1) | 250V | 22395 |
| R965 | 2k2 | CF | | 21802 | C731 | .01μF | CE(1) | 250V | 22395 |
| R966 | 56k | CF | | 28729 | C732 | .01μF | CE(1) | 250V | 22395 |
| R967 | 5k6 | CF | | 21806 | C733 | .01μF | CE(1) | 250V | 22395 |
| R968 | 36k | MF | | 38631 | C734 | .01μF | CE(1) | 250V | 22395 |
| R969 | 1k6 | MF | | 38599 | C735 | 68pF | CE(2) | | 22374 |
| R970 | 12k | MF | | 38620 | C736 | .01μF | CE(1) | 250V | 22395 |
| R971 | 10k | CF | A.O.T. | 21809 | C737 | .01μF | CE(1) | 250V | 22395 |
| R972 | 4k7 | CF | A.O.T. | 21805 | C738 | .01μF | CE(1) | 250V | 22395 |
| R973 | 750 | MF | | 38591 | C739 | 56pF | CE(2) | | 22373 |
| R974 | 5k6 | MF | | 38612 | C740 | 180pF | SM | ½pF | 4515 |
| R975 | 11k | MF | | 38619 | C741 | 45pF | FT | | 36274 |
| R976 | 30k | MF | | 38629 | C742 | 2.2μF | PC | | 40853 |
| R977 | 10 | CF | | 21793 | C743 | 10μF | E | 10V | 40353 |
| R978 | 3k9 | CF | | 21804 | C744 | 10μF | E | 25V | 32180 |
| R979 | 22 | CF | | 28710 | C745 | .01μF | CE(1) | 250V | 22395 |
| R980 | 220 | CF | | 21796 | C746 | .022μF | PC | | 40854 |
| R981 | 220 | CF | | 21796 | C747 | 220pF | CE(2) | | 22379 |
| R982 | 680 | CF | | 28723 | C748 | .01μF | CE(1) | 250V | 22395 |
| R983 | 9k1 | MF | | 38617 | C749 | 56pF | CE(2) | | 22373 |
| R984 | 3k3 | CF | | 21803 | C750 | .01μF | CE(1) | 250V | 22395 |
| R985 | 10k1 | MF | 0.5 1/8W | 37778 | C751 | 10μF | E | 25V | 32180 |
| R986 | | | | | C752 | .01μF | CE(1) | 250V | 22395 |
| R987 | 1k3 | MF | | 38597 | C753 | .1μF | PE | 100V | 37018 |
| R988 | 100 | CF | | 21794 | C754 | | | | |
| R989 | 100 | CF | | 21794 | C755 | | | | |
| R990 | 10k | CF | | 21809 | C756 | 10μF | E | 10V | 40353 |

Component List and Illustrations

Section 6

OS3600 TIMEBASE, 'X' O/P & CALIBRATOR (Cont)

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|--------------------------|--------|-------------|--------|---------|--------------------------|---------|-------------|--------|---------|
| CAPACITORS (Cont) | | | | | CAPACITORS (Cont) | | | | |
| C757 | .01μF | CE(1) | 250V | 22395 | C841 | 10μF | E | 25V | 32180 |
| C758 | 56pF | CE(2) | | 22373 | C842 | 33μF | E | 16V | 32173 |
| C759 | .01μF | CE(1) | 250V | 22395 | C843 | 33μF | E | 16V | 32173 |
| C760 | .01μF | CE(1) | 250V | 22395 | C844 | 0.15μF | PE | 250V | 35601 |
| C761 | 1μF | T | 35V | 34895 | C845 | 39pF | CE(2) | | 22371 |
| C762 | 1μF | T | 35V | 34895 | TRANSISTORS | | | | |
| C763 | 100pF | CE(2) | | 22376 | TR701 | BC212 | | | 29327 |
| C764 | .01μF | CE(1) | 250V | 22395 | TR702 | 2N5771 | | | 38089 |
| C765 | .01μF | CE(1) | 250V | 22395 | TR703 | 2N3906 | | | 21533 |
| C766 | 10μF | E | 25V | 32180 | TR704 | 2N5771 | | | 38089 |
| C767 | .01μF | CE(1) | 250V | 22395 | TR710 | BC182 | Selected | | 40349 |
| C768 | .01μF | CE(1) | 250V | 22395 | TR711 | 2N5771 | | | 38089 |
| C769 | .01μF | CE(1) | 250V | 22395 | TR712 | BC214C | | | 36019 |
| C770 | .01μF | CE(1) | 250V | 22395 | TR713 | 2N3904 | | | 24146 |
| C771 | .01μF | CE(1) | 250V | 22395 | TR714 | BC214C | Selected | | 40348 |
| C772 | 10μF | E | 25V | 32180 | TR715 | BC182B | | | 33205 |
| C773 | 27pF | CE(2) | | 22369 | TR716 | BC212 | | | 29327 |
| C774 | 0.01μF | CE(1) | 250V | 22395 | TR717 } TR718 } | J412-1 | Dual f.e.t. | | 44703 |
| C775 | 680pF | CE(2) | | 22385 | TR719 | MPS2369 | | | 36625 |
| C776 | 22μF | T | 16V | 54220 | TR720 | MPS2369 | | | 36625 |
| C777 | .01μF | CE(1) | 250V | 22395 | TR721 | 2N3904 | | | 24146 |
| C801 | 0.01μF | CE(1) | 250V | 22395 | TR722 | ZTX3906 | | | 41811 |
| C802 | 0.01μF | CE(1) | 250V | 22395 | TR723 | ZTX3906 | | | 41811 |
| C803 | 0.01μF | CE(1) | 250V | 22395 | TR724 | 2N5771 | | | 38089 |
| C804 | 0.01μF | CE(1) | 250V | 22395 | TR725 | 2N5771 | | | 38089 |
| C805 | 0.01μF | CE(1) | 250V | 22395 | TR726 | 2N3906 | | | 21533 |
| C806 | 0.01μF | CE(1) | 250V | 22395 | TR727 | BC182B | Selected | | 40349 |
| C807 | 0.01μF | CE(1) | 250V | 22395 | TR733 | 2N5771 | | | 38089 |
| C808 | 0.01μF | CE(1) | 250V | 22395 | TR734 | 2N3904 | | | 24146 |
| C809 | 0.01μF | CE(1) | 250V | 22395 | TR735 | 2N3904 | | | 24146 |
| C810 | 2.7pF | SM | ½pF | 816 | TR736 } TR737 } | J412-1 | Dual f.e.t. | | 44703 |
| C811 | 2.7pF | SM | ½pF | 816 | TR738 | BC214C | Selected | | 40348 |
| C812 | 0.01μF | CE(1) | 250V | 22395 | TR739 | BC182B | | | 33205 |
| C813 | 1.5pF | CE(2) | | 40356 | TR740 | BC212 | | | 29327 |
| C814 | 1.5pF | CE(2) | | 40356 | TR746 | MPS2369 | | | 36625 |
| C815 | 9pF | FT | | 36272 | TR747 | MPS2369 | | | 36625 |
| C816 | 9pF | FT | | 36272 | TR748 | 2N3904 | | | 24146 |
| C817 | 1.5pF | CE(2) | | 40356 | TR749 | 2N3904 | | | 24146 |
| C818 | 1.5pF | CE(2) | | 40356 | TR750 | 2N3904 | | | 24146 |
| C819 | 0.01μF | PF | | 37018 | TR751 | BC212 | | | 29327 |
| C820 | 150pF | CE(2) | | 22378 | TR801 | BF470 | | | 38416 |
| C821 | 150pF | CE(2) | | 22378 | TR802 | BF470 | | | 38416 |
| C822 | 0.01μF | CE(1) | 250V | 22395 | TR803 | BF469 | | | 38418 |
| C823 | 0.01μF | CE(1) | 250V | 22395 | TR804 | BF469 | | | 38418 |
| C824 | 0.01μF | CE(1) | 250V | 22395 | TR805 | 2N5771 | | | 38089 |
| C825 | 10μF | E | 25V | 32180 | TR806 | 2N2369 | | | 23307 |
| C826 | 0.01μF | CE(1) | 250V | 22395 | TR807 | 2N2369 | | | 23307 |
| C827 | 0.01μF | CE(1) | 250V | 22395 | TR808 | 2N5771 | | | 38089 |
| C828 | 0.01μF | CE(1) | 250V | 22395 | TR809 | BF371 | | | 36275 |
| C829 | 100nF | PE | | 37018 | | | | | |
| C830 | 470pF | CE(2) | | 22383 | | | | | |
| C831 | 15pF | CE(2) | | 22366 | | | | | |
| C832 | 0.01μF | CE(1) | 250V | 22395 | | | | | |
| C833 | 0.01μF | CE(1) | 250V | 22395 | | | | | |


Component List and Illustrations

Section 6

OS3600 TIMEBASE, 'X' O/P & CALIBRATOR (Cont)

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|---------------------------|-------|-------------|--------|---------|----------------------------|-------|---------------------|--------|----------|
| TRANSISTORS (Cont) | | | | | DIODES (Cont) | | | | |
| TR810 | | BF371 | | 36275 | D749 | | IN4148 | | 23802 |
| TR811 | | BF371 | | 36275 | D750 | | IN4148 | | 23802 |
| TR812 | | BF371 | | 36275 | D751 | | IN4148 | | 23802 |
| TR813 | | 2N3904 | | 24146 | D752 | | | | |
| TR814 | | 2N3904 | | 24146 | D753 | | IN4148 | | 23802 |
| TR815 | | 2N3904 | | 24146 | D754 | | IN4148 | | 23802 |
| DIODES | | | | | D801 | 5V6 | ZENER | | 33929 |
| D701 | | IN4148 | | 23802 | D802 | 3V9 | ZENER | | 33925 |
| D702 | | IN4148 | | 23802 | D803 | 7V5 | ZENER | | 33932 |
| D703 | | IN4148 | | 23802 | D804 | | IN4149 | | 1949 |
| D704 | | IN4148 | | 23802 | D805 | | IN4149 | | 1949 |
| D705 | | IN4148 | | 23802 | D806 | | IN4149 | | 1949 |
| D706 | | IN4148 | | 23802 | D807 | | IN4149 | | 1949 |
| D707 | | IN4148 | | 23802 | D808 | | FH1100 | | 40352 |
| D708 | | IN4148 | | 23802 | D809 | | FH1100 | | 40352 |
| D709 | | IN4148 | | 23802 | D810 | | IN4149 | | 1949 |
| D710 | | IN4148 | | 23802 | D811 | | IN4149 | | 1949 |
| D711 | | IN4148 | | 23802 | D812 | | IN4148 | | 23802 |
| D712 | 3V9 | ZENER | | 33925 | D813 | | IN4148 | | 23802 |
| D713 | | IN4148 | | 23802 | D814 | 5V1 | ZENER | | 33928 |
| D714 | | IN4148 | | 23802 | D815 | 33V | ZENER | | 33947 |
| D715 | | IN4148 | | 23802 | D816 | 33V | ZENER | | 33947 |
| D716 | | IN4148 | | 23802 | | | | | |
| D717 | | IN4148 | | 23802 | D821 | | IN4148 | | 23802 |
| D718 | | IN4148 | | 23802 | D822 | | IN4148 | | 23802 |
| D719 | | IN4148 | | 23802 | INTEGRATED CIRCUITS | | | | |
| D720 | 2V7 | ZENER | | 33921 | IC701 | | 10231 | | 39247 |
| D721 | | IN4148 | | 23802 | IC702 | | 10103 | | 40346 |
| D722 | | IN4148 | | 23802 | IC703 | | 10102 | | 30243 |
| D723 | | IN4148 | | 23802 | IC704 | | 10231 | | 39247 |
| D724 | | IN4148 | | 23802 | IC705 | | 74LS112 | | 36468 |
| D725 | | IN4148 | | 23802 | IC706 | | 741 | | 36736 |
| D726 | | IN4148 | | 23802 | IC707 | | 74LS10 | | 36867 |
| D727 | | IN4148 | | 23802 | IC708 | | 74LS112 | | 36468 |
| D728 | | IN4148 | | 23802 | IC709 | | CD4066 | | 40345 |
| D729 | | IN4148 | | 23802 | IC710 | | 1414 | | 35682 |
| D730 | | IN4148 | | 23802 | IC711 | | CA3086 | | 42907 |
| D731 | 3V9 | ZENER | | 33925 | IC712 | | CA3086 | | 42907 |
| D732 | | IN4148 | | 23802 | IC713 | | CA3086 | | 42907 |
| D733 | | IN4148 | | 23802 | IC714 | | 709 | | 40179 |
| D734 | | IN4148 | | 23802 | MISCELLANEOUS | | | | |
| D735 | | IN4148 | | 23802 | S701-705 | | Switch Pushbutton | | A3/40735 |
| D736 | | IN4148 | | 23802 | S706-708 | | Switch Pushbutton | | A3/40736 |
| D737 | | IN4148 | | 23802 | S709-713 | | Switch Pushbutton | | |
| D738 | | IN4148 | | 23802 | | | Y Mode Select | | A3/43001 |
| D739 | | IN4148 | | 23802 | L701 | | Ferrite Bead FX1242 | | 26986 |
| D740 | 5V6 | ZENER | | 33929 | L702 | | Ferrite Bead FX1242 | | 26986 |
| D741 | | IN4148 | | 23802 | PLS | | Plug Molex 14 Way | | 38297 |
| D742 | | IN4148 | | 23802 | PLT | | Plug Molex 19 Way | | 42502 |
| D743 | | | | | PLU | | Plug Molex 11 Way | | 40323 |
| D744 | | IN4148 | | 23802 | PLV | | Plug Molex 13 Way | | 39387 |
| D745 | | IN4148 | | 23802 | PLW | | Plug Molex 9 Way | | 39386 |
| D746 | | IN4148 | | 23802 | PLX | | Plug Molex 13 Way | | 39287 |
| D747 | | IN4148 | | 23802 | | | | | |
| D748 | | IN4148 | | 23802 | | | | | |

| | | | | | | | | | | | | | | |
|-------|------|------|-------|------|------|------|--|------|------|------|------|------|------|-------|
| | R982 | R984 | R983 | R980 | R985 | R987 | | R15 | R950 | R953 | | R936 | R939 | R940 |
| RESIS | | | | R981 | | | | | | | | R976 | R979 | R982 |
| CAP | C841 | C844 | C843 | C842 | | C845 | | | | | C814 | C818 | C821 | C807 |
| | | | | | | | | | | | C823 | C816 | C824 | C835 |
| MISC | | | IC714 | | D822 | D821 | | | | D812 | | | D806 | TR806 |
| | | | | | | | | SKEE | | D813 | | | | L702 |
| | | | | | | | | | | | | | | TR810 |
| | | | | | | | | | | | | | | TR814 |



Component List and Illustrations

Section 6

OS3600 'Y' PRE-AMP BEAM SWITCH 'Y' DRIVER & O/P

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|------------------|-------|-------------------------|--------|----------|------|----------|-------------|--------|---------|
| RESISTORS | | | | | | | | | |
| R11 | 4k7 | CP Pot Y Shift | | A4/42203 | R101 | 22 | CF | | 28710 |
| R12 | 4k7 | CP Pot Y Shift | | A4/42203 | R102 | 10 | CF | | 21793 |
| R13 | 2k2 | CP Log. (+S7) Fine Gain | | A4/42993 | R103 | 2k2 | CF | | 21802 |
| R14 | 2k2 | CP Log. (+S8) Fine Gain | | A4/42993 | R104 | 47 | CF | 1/8W | 43146 |
| R27 | 47 | CF | | 28714 | R105 | 47 | CF | 1/8W | 43146 |
| R28 | 100 | CF | | 21794 | R106 | 82 | CF | 1/8W | 43149 |
| R43 | 56 | CF | | 28715 | R107 | 1k | CF | | 21799 |
| R44 | 56 | CF | | 28715 | R108 | 2k2 | CF | | 21802 |
| R45 | 39 | CF | | 28713 | R109 | 22k | CF | | 21812 |
| R46 | 39 | CF | | 28713 | R110 | 100 | CF | | 21794 |
| R47 | 10 | CF | | 21793 | R111 | 47 | CF | 1/8W | 43146 |
| R48 | 10 | CF | | 21793 | R112 | 10 | CF | | 21793 |
| R49 | 10 | CF | | 21793 | R113 | 820 | CF | | 28724 |
| R50 | 10 | CF | | 21793 | R114 | 47 | CF | 1/8W | 43146 |
| R51 | 10 | CF | | 21793 | R115 | 10k | CF | | 21809 |
| R52 | 10 | CF | | 21793 | R116 | 1k2 | CF | | 21800 |
| R53 | 18 | CF | | 28709 | R117 | 10 | CF | | 21793 |
| R54 | 18 | CF | | 28709 | R118 | 470 | CF | | 21797 |
| R55 | 10k | CF | | 21809 | R119 | 150 | MF | | 38574 |
| R56 | 10k | CF | | 21809 | R120 | 2k | MF | | 38601 |
| R59 | 39 | CF | | 28713 | R121 | 2k | MF | | 38601 |
| R60 | 39 | CF | | 28713 | R122 | 10 | CF | | 21793 |
| R61 | 39 | CF | | 28713 | R123 | 220 | CF | 1/8W | 43359 |
| R62 | 39 | CF | | 28713 | R124 | 820 | MF | | 38592 |
| R63 | 39 | CF | | 28713 | R125 | 820 | MF | | 38592 |
| R64 | 39 | CF | | 28713 | R126 | 1k8 | CF | | 28725 |
| R71 | 900k | MF | 0.5 | 31929 | R127 | 100 | CF | 1/8W | 43150 |
| R72 | 900k | MF | 0.5 | 31929 | R128 | 100 | CF | 1/8W | 43150 |
| R73 | 111k | MF | 0.5 | 31930 | R129 | 470 | CF | | 21797 |
| R74 | 111k | MF | 0.5 | 31930 | R130 | 100 | CF | | 21794 |
| R75 | 990k | MF | 0.5 | 31927 | R131 | 100 | CF | | 21794 |
| R76 | 990k | MF | 0.5 | 31927 | R132 | 1k5 | CF | | 21801 |
| R77 | 10k1 | MF | 0.5 | 37778 | R133 | 390 | CF | | 28722 |
| R78 | 10k1 | MF | 0.5 | 37778 | R134 | not used | | | |
| R79 | 100k | MF | | 38642 | R135 | 10 | CF | | 21793 |
| R80 | 100k | MF | | 38642 | R136 | 1k2 | MF | | 38596 |
| R81 | 1k2 | CF | | 21800 | R137 | 1k2 | MF | | 38596 |
| R82 | 1k2 | CF | | 21800 | R138 | 47 | CF | 1/8W | 43146 |
| R83 | | Resistor Network | | A3/43135 | R139 | 47 | CF | 1/8W | 43146 |
| R84 | | Resistor Network | | A3/43136 | R140 | 3k6 | MF | | 38607 |
| R85 | 900k | MF | 0.5 | 31929 | R141 | 22k | CF | | 21812 |
| R86 | 900k | MF | 0.5 | 31929 | R142 | 470 | CF | | 21797 |
| R87 | 270 | MF | | 38580 | R143 | 100 | CF | | 21794 |
| R88 | 270 | MF | | 38580 | R144 | 100 | CF | | 21794 |
| R89 | 270 | MF | | 38580 | R145 | 100 | CF | 1/8W | 43150 |
| R90 | 270 | MF | | 38580 | R146 | 100 | CF | 1/8W | 43150 |
| R91 | 470k | CC | | 4906 | R147 | 22 | CF | | 28710 |
| R92 | 470k | CC | | 4906 | R148 | 270 | MF | | 38580 |
| R93 | 470k | CC | | 4906 | R149 | 270 | MF | | 38580 |
| R94 | 470k | CC | | 4906 | R150 | 560 | MF | | 38588 |
| R95 | 75 | MF | | 38567 | R151 | 560 | MF | 1 | 43622 |
| R96 | 75 | MF | | 38567 | R152 | 470 | MF | 1 | 43622 |
| | | | | | R153 | 470 | MF | | 21797 |
| | | | | | R154 | 470 | CF | | 21797 |
| | | | | | R155 | 68 | MF | | 38566 |

Component List and Illustrations

Section 6

OS3600 'Y' PRE-AMP BEAM SWITCH, 'Y' DRIVER & O/P (Cont)

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|-------------------------|----------|-------------|--------|---------|------|----------|-------------|--------|---------|
| RESISTORS (Cont) | | | | | | | | | |
| R156 | 1k2 | CF | | 21800 | R211 | 47 | CF | 1/8W | 43146 |
| R157 | 1k2 | CF | | 21800 | R212 | not used | | | |
| R158 | 3k | MF | | 38605 | R213 | 820 | CF | | 28724 |
| R159 | 3k | MF | | 38605 | R214 | 47 | CF | 1/8W | 43146 |
| R160 | 10 | CF | | 21793 | R215 | 10k | CF | | 21809 |
| R161 | 51 | MF | | 38563 | R216 | 1k2 | CF | | 21800 |
| R162 | 10 | CF | | 21793 | R217 | 10 | CF | | 21793 |
| R163 | 47 | CF | | 28714 | R218 | 470 | CF | | 21797 |
| R164 | 330 | CF | | 28721 | R219 | 150 | MF | | 38574 |
| R165 | 330 | CF | | 28721 | R220 | 2k | MF | | 38601 |
| R166 | 100 | MF | | 38570 | R221 | 2k | MF | | 38601 |
| R167 | 100 | MF | | 38570 | R222 | 10 | CF | | 21793 |
| R168 | 620 | MF | | 38589 | R223 | 220 | CF | 1/8W | 43359 |
| R169 | 4k7 | CF | | 21805 | R224 | 820 | MF | | 38592 |
| R170 | 27 | CF | | 28711 | R225 | 820 | MF | | 38592 |
| R171 | 470 | CF | | 21797 | R226 | 1k8 | CF | | 28725 |
| R172 | 2k7 | MF | | 38604 | R227 | 100 | CF | 1/8W | 43150 |
| R173 | 2k7 | CF | | 28726 | R228 | 100 | CF | 1/8W | 43150 |
| R174 | 5k6 | CF | | 21806 | R229 | 470 | CF | | 21797 |
| R175 | 5k6 | CF | | 21806 | R230 | 100 | CF | | 21794 |
| R176 | 3k9 | CF | | 21804 | R231 | 100 | CF | | 21794 |
| R177 | 3k9 | CF | | 21804 | R232 | 1k5 | CF | | 21801 |
| R178 | 1k | PCP | | 39233 | R233 | 390 | CF | | 28722 |
| R179 | 20k | PCP | | 39235 | R234 | not used | | | |
| R180 | 50k | PCP | | 39268 | R235 | 10 | CF | | 21793 |
| R181 | 200 | PCP | | 39231 | R236 | 1k2 | MF | | 38596 |
| R182 | 50 | PCP | | 39267 | R237 | 1k2 | MF | | 38596 |
| R183 | 100 | PCP | | 39230 | R238 | 47 | CF | 1/8W | 43146 |
| R184 | 1k | PCP | | 39233 | R239 | 47 | CF | 1/8W | 43146 |
| R185 | 1k | PCP | | 39233 | R240 | 3k6 | MF | | 38607 |
| R186 | 47 | CF | | 28714 | R241 | 22k | CF | | 21812 |
| R187 | 47 | CF | | 28714 | R242 | 470 | CF | | 21797 |
| R188 | 22 | CF | 1/8W | 43142 | R243 | 100 | CF | | 21794 |
| R189 | 2k2 | CF | 1/8W | 43357 | R244 | 100 | CF | | 21794 |
| R190 | 100 | CF | 1/8W | 43150 | R245 | 100 | CF | 1/8W | 43150 |
| R191 | 3k3 | CF | 1/8W | 43358 | R246 | 100 | CF | 1/8W | 43150 |
| R192 | 680 | CF | | 28723 | R247 | 22 | CF | | 28710 |
| R193 | 1k2 | CF | | 21800 | R248 | 270 | MF | | 38580 |
| R194 | 47 | CF | | 28714 | R249 | 270 | MF | | 38580 |
| R195 | 47 | CF | | 28714 | R250 | 560 | MF | | 38588 |
| R196 | 100 | CF | | 21794 | R251 | 560 | MF | | 38588 |
| R197 | 270 | CF | | 28720 | R252 | 470 | MF | 1 | 43622 |
| R198 | 33k | CF | | 21814 | R253 | 470 | MF | 1 | 43622 |
| R199 | 220 | CF | | 21796 | R254 | 470 | CF | | 21797 |
| R200 | not used | | | | R255 | 68 | MF | | 38566 |
| R201 | 22 | CF | | 28710 | R256 | 1k2 | CF | | 21800 |
| R202 | 10 | CF | | 21793 | R257 | 1k2 | CF | | 21800 |
| R203 | 2k2 | CF | | 21802 | R258 | 3k | MF | | 38605 |
| R204 | 47 | CF | 1/8W | 43146 | R259 | 3k | MF | | 38605 |
| R205 | 47 | CF | 1/8W | 43146 | R260 | 10 | CF | | 21793 |
| R206 | 82 | CF | 1/8W | 43149 | R261 | 51 | MF | | 38563 |
| R207 | 1k | CF | | 21799 | R262 | 10 | CF | | 21793 |
| R208 | 2k2 | CF | | 21802 | R263 | 47 | CF | | 28714 |
| R209 | 22k | CF | | 21812 | R264 | 330 | CF | | 28721 |
| R210 | 100 | CF | | 21794 | R265 | 330 | CF | | 28721 |

Component List and Illustrations

Section 6

OS3600 'Y' PRE-AMP BEAM SWITCH, 'Y' DRIVER & O/P (Cont)

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|-------------------------|----------|-------------|--------|---------|------|----------|--------------------------------|--------|---------|
| RESISTORS (Cont) | | | | | | | | | |
| R266 | 100 | MF | | 38570 | R323 | 2k2 | CF | | 21802 |
| R267 | 100 | MF | | 38570 | R324 | 47 | CF | 1/8W | 43146 |
| R268 | 510 | MF | | 38587 | R325 | 47 | CF | 1/8W | 43146 |
| R269 | 1k | CF | | 21799 | R326 | 270 | CF | | 28720 |
| R270 | 27 | CF | | 28711 | R327 | 270 | CF | | 28720 |
| R271 | 330 | CF | | 28721 | R328 | 1k5 | CF | | 21801 |
| R272 | 12k | CF | | 21810 | R329 | 33 | CF | | 28712 |
| R273 | 1k | CF | | 21799 | R330 | 68 | CF | | 28716 |
| R274 | 10 | CF | | 21793 | R331 | 68 | CF | | 28716 |
| R275 | not used | | | | R332 | 18k | CF | | 21811 |
| R276 | 3k9 | CF | | 21804 | R333 | | CF | A.O.T | |
| R277 | 3k9 | CF | | 21804 | R334 | | CF | A.O.T | |
| R278 | 1k | PCP | | 39233 | R335 | 10 | CF | | 21793 |
| R279 | 20k | PCP | | 39235 | R336 | 47 | CF | 1/8W | 43146 |
| R280 | 50k | PCP | | 39268 | R337 | 47 | CF | 1/8W | 43146 |
| R281 | 200 | PCP | | 39231 | R338 | 100 | CF | 1/8W | 43150 |
| R282 | 50 | PCP | | 39267 | R339 | 100 | CF | 1/8W | 43150 |
| R283 | 100 | PCP | | 39230 | R340 | 10 | CF | | 21793 |
| R284 | 1k | PCP | | 39233 | R341 | 200 | PCP | | 39231 |
| R285 | not used | | | | R342 | 430 | MF | | 38585 |
| R286 | 47 | CF | | 28714 | R343 | 430 | MF | | 38585 |
| R287 | 47 | CF | | 28714 | R344 | 220 | CF | | 21796 |
| R288 | 22 | CF | 1/8W | 43142 | R345 | 1k | CF | | 21799 |
| R289 | 2k2 | CF | 1/8W | 43357 | R346 | 1k | CF | | 21799 |
| R290 | not used | | | | R347 | 100 | CF | 1/8W | 43150 |
| R291 | 3k3 | CF | 1/8W | 43358 | R348 | 100 | CF | 1/8W | 43150 |
| R292 | 680 | CF | | 28723 | R349 | 820 | CF | | 28724 |
| R293 | 1k2 | CF | | 21800 | R350 | 820 | CF | | 28724 |
| R294 | 47 | CF | | 28714 | R351 | not used | | | |
| R295 | 47 | CF | | 28714 | R352 | 51 | MF | | 38563 |
| | | | | | R353 | 120 | CF | | 28718 |
| R298 | 33k | CF | | 21814 | R354 | 47 | CF | 1/8W | 43146 |
| | | | | | R355 | 1k5 | CF | | 21801 |
| R301 | 47 | CF | | 28714 | R356 | 1k | PCP | | 39233 |
| R302 | 47 | CF | | 28714 | R357 | 3k3 | CF | | 21803 |
| R303 | 33 | CF | | 28712 | R358 | 100k | CF | | 21819 |
| R304 | 8k2 | CF | | 21808 | R359 | 1k | CF | | 21799 |
| R305 | 100 | CF | 1/8W | 43150 | R360 | 10 | CF | | 21793 |
| R306 | 100 | CF | 1/8W | 43150 | R361 | 2k2 | CF | | 21802 |
| R307 | 560 | CF | | 21798 | R362 | 2k2 | CF | | 21802 |
| R308 | 150 | CF | | 28719 | R363 | 1k2 | CF | | 21800 |
| R309 | 150 | CF | | 28719 | R364 | 470 | CF | | 21797 |
| R310 | 47 | CF | | 28714 | R365 | 680 | CF | | 28723 |
| R311 | 47 | CF | | 28714 | R366 | 330 | CF | | 28721 |
| R312 | 22 | CF | 1/8W | 43142 | R367 | 1k | PCP | | 39233 |
| R313 | 2k2 | CF | 1/8W | 43357 | R368 | 47 | CF | | 28714 |
| R314 | 220 | CF | | 21796 | R369 | 47 | CF | | 28714 |
| R315 | 3k3 | CF | 1/8W | 43358 | R370 | | Resistor Network 2.2k 8 way | | 43185 |
| R316 | 620 | MF | | 38589 | | | Resistor Network 2.2k 8 way | | 43185 |
| R317 | 620 | MF | | 38589 | R371 | | | | |
| R318 | 100 | CF | 1/8W | 43150 | | | | | |
| R319 | 100 | CF | 1/8W | 43150 | R372 | 47 | CF | | 28714 |
| R320 | 150 | CF | | 28719 | R373 | 47 | CF | | 28714 |
| R321 | 100 | CF | 1/8W | 43150 | R374 | 47 | CF | | 28714 |
| R322 | 3k9 | CF | | 21804 | R375 | 47 | CF | | 28714 |

Component List and Illustrations

Section 6

OS3600 'Y' PRE-AMP BEAM SWITCH, 'Y' DRIVER & O/P (Cont)

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|-------------------------|----------|-------------|--------|---------|-------|----------|-------------|----------------|----------|
| RESISTORS (Cont) | | | | | | | | | |
| R376 | 1k | CF | | 21799 | R432 | 220k | CF | | 21823 |
| R377 | 2k2 | CF | | 21802 | R433 | 6M2 | MG | ½W | 42132 |
| R378 | 2k2 | CF | | 21802 | R434 | 560 | CF | | 21798 |
| R379 | 100 | CF | 1/8W | 43150 | R435 | 1k | CP | Scale Illum. | A4/38680 |
| R380 | 100 | CF | 1/8W | 43150 | R436 | 2k2 | CP | Trace Rotation | A4/38678 |
| R381 | 10 | CF | | 21793 | R437 | 10k | CP | Intensity | A4/38681 |
| R382 | 10k | PCP | | 39265 | R438 | 1M | CP | Focus | A4/38679 |
| R383 | 5k6 | CF | | 21806 | R439 | 100k | PCP | | 39269 |
| R384 | 5k6 | CF | | 21806 | R440 | 1M | PCP | | 39431 |
| R385 | 1k | CF | | 21799 | R441 | not used | | | |
| R386 | 2k2 | CF | | 21802 | R442 | 1k | CF | | 21799 |
| R387 | 1k2 | CF | | 21800 | R443 | not used | | | |
| R388 | 1k | CF | | 21799 | R444 | 47 | CF | | 28714 |
| R389 | 1k | CF | | 21799 | | | | | |
| R390 | 1k2 | CF | | 21800 | R447 | 39k | CF | | 28728 |
| R391 | 1k2 | CF | | 21800 | R448 | 82k | CF | | 21818 |
| R392 | 1k | CF | | 21799 | R449 | not used | | | |
| R393 | 1k | CF | | 21799 | R450 | 10 | CF | | 21793 |
| R394 | 750 | MF | | 38591 | R451 | 10 | CF | | 21793 |
| R395 | 2k2 | CF | | 21802 | R452 | 1k5 | CF | | 21801 |
| R396 | 330 | CF | | 28721 | R453 | 47 | CF | | 28714 |
| R397 | 100 | CF | 1/8W | 43150 | R454 | 47 | CF | | 28714 |
| R398 | 100 | CF | 1/8W | 43150 | R455 | 68 | CF | | 28716 |
| R399 | 100 | CF | 1/8W | 43150 | R456 | 33 | CF | A.O.T. | 28712 |
| | | | | | R457 | 10 | CF | | 21793 |
| R401 | 100 | CF | | 21794 | | | | | |
| R402 | 680 | CF | | 28723 | R471 | 10 | CF | | 21793 |
| R403 | 100 | CF | | 21794 | R472 | 10 | CF | | 21793 |
| R404 | 680 | CF | | 28723 | R473 | 510 | MO | 5 6W | 40318 |
| R405 | 100 | CF | | 21794 | R474 | 510 | MO | 5 6W | 40318 |
| R406 | 100 | CF | | 21794 | R475 | 10 | CF | | 21793 |
| R407 | 470 | CF | | 21797 | R476 | 47 | CF | ½W | 18534 |
| R408 | 820 | CF | | 28724 | | | | | |
| R409 | 560 | CF | | 21798 | R1341 | 100 | CF | | 21794 |
| R410 | 560 | CF | | 21798 | R1342 | 100 | CF | | 21794 |
| R411 | 330 | CF | | 28721 | | | | | |
| R412 | 270 | CF | | 28720 | R1351 | 47 | CF | | 28714 |
| R413 | 270 | CF | | 28720 | R1352 | 47 | CF | | 28714 |
| R414 | 180 | CF | | 21795 | | | | | |
| R415 | 82 | CF | | 28717 | R1356 | 47 | CF | | 28714 |
| R416 | 82 | CF | | 28717 | R1357 | 47 | CF | | 28714 |
| R417 | 560 | CF | | 21798 | | | | | |
| R418 | 560 | CF | | 21798 | R1362 | 100 | CF | 1/8W | 43150 |
| R419 | not used | | | | R1363 | not used | | | |
| R420 | 10k | CF | | 21809 | R1364 | 47 | CF | | 28714 |
| R421 | 4k7 | CF | | 21805 | R1365 | 47 | CF | | 28714 |
| R422 | 180 | CF | | 21795 | R1366 | 22 | CF | 1/8W | 43142 |
| R423 | 180 | CF | | 21795 | R1367 | 22 | CF | 1/8W | 43142 |
| R424 | 470 | CF | | 21797 | R1368 | 22 | CF | 1/8W | 43142 |
| R425 | 150 | CF | A.O.T. | 28719 | R1369 | 390 | CF | A.O.T. | 28722 |
| R426 | 22 | CF | | 28710 | R1370 | 1k | CF | | 21799 |
| R428 | 150 | CF | | 28719 | R1371 | 110 | CF | | 21796 |
| R429 | 470 | CF | ½W | 18546 | R1372 | 3k3 | CF | | 21803 |
| R430 | not used | | | | R1373 | 820 | CF | | 28724 |
| R431 | 100 | CF | | 21794 | R1374 | 1k5 | CF | | 21801 |

Component List and Illustrations

Section 6

063600 'Y' PRE-AMP BEAM SWITCH, 'Y' DRIVER & O/P (Cont)

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|-------------------------|----------|-------------|--------|----------|------|----------|-------------|--------|---------|
| RESISTORS (Cont) | | | | | | | | | |
| R1375 | not used | | | | C103 | 22μF | E | 25V | 32181 |
| R1376 | 5k6 | CF | | 21806 | C104 | .01μF | CE(1) | 250V | 42569 |
| R1377 | 5k6 | CF | | 21806 | C105 | .01μF | CE(1) | 250V | 42569 |
| R1378 | 5k6 | CF | | 21806 | C106 | .01μF | CE(1) | 250V | 42569 |
| R1379 | 5k6 | CF | | 21806 | C107 | 5.6pF | CE(2) | A.O.T. | 22361 |
| R1380 | 2k7 | CF | | 28726 | C108 | .01μF | CE(1) | 250V | 42569 |
| R1381 | 330 | CF | | 28721 | C109 | .01μF | CE(1) | 250V | 42569 |
| R1382 | 100 | CF | 1/8W | 43150 | C110 | .01μF | CE(1) | 250V | 42569 |
| R1383 | not used | | | | C111 | 1pF | CE(3) | | 36594 |
| R1384 | 100 | CF | 1/8W | 43150 | C112 | .01μF | CE(1) | 250V | 42569 |
| CAPACITORS | | | | | | | | | |
| C51 | 4700pF | CE(1) | | 22393 | C113 | 5.6pF | CE(3) | | 36603 |
| C52 | 4700pF | CE(1) | | 22393 | C114 | .01μF | CE(1) | 250V | 42569 |
| C53 | 0.1μF | PE | 400V | 29495 | C115 | .01μF | CE(1) | 250V | 42569 |
| C54 | 0.1μF | PE | 400V | 29495 | C116 | .01μF | CE(1) | 250V | 42569 |
| C55 | 10pF | CE(2) | | 22364 | C117 | not used | | | |
| C56 | 10pF | CE(2) | | 22364 | C118 | .01μF | CE(1) | 250V | 42569 |
| C57 | 27pF | CE(2) | | 22369 | C119 | not used | | | |
| C58 | 27pF | CE(2) | | 22369 | C120 | not used | | | |
| C59 | 8.2pF | CE(2) | | 22363 | C121 | .01μF | CE(1) | 250V | 42569 |
| C60 | 8.2pF | CE(2) | | 22363 | C122 | not used | | | |
| C61 | 47pF | Button Mica | | 29918 | C123 | 12pF | CE(3) | | 36607 |
| C62 | 47pF | Button Mica | | 29918 | C124 | 330pF | CE(2) | 100V | 43438 |
| C63 | 330pF | Button Mica | | 31293 | C125 | 4/27pF | FT | | 36273 |
| C64 | 330pF | Button Mica | | 31293 | C126 | 1pF | CE(3) | | 36594 |
| C65 | 2/10pF | TRIMMER | | A4/43123 | C127 | 1pF | CE(3) | | 36594 |
| C66 | 2/10pF | TRIMMER | | A4/43123 | C128 | .01μF | CE(1) | 250V | 42569 |
| C67 | 2/10pF | TRIMMER | | A4/43123 | C129 | not used | | | |
| C68 | 2/10pF | TRIMMER | | A4/43123 | C130 | .01μF | CE(1) | 250V | 42569 |
| C69 | 2/10pF | TRIMMER | | 43183 | C131 | 15pF | CE(2) | | 22366 |
| C70 | 2/10pF | TRIMMER | | 43183 | C132 | 220pF | CE(2) | | 22379 |
| C71 | 2/10pF | TRIMMER | | 43183 | C133 | .01μF | CE(1) | 250V | 42569 |
| C72 | 2/10pF | TRIMMER | | 43183 | C134 | .01μF | CE(1) | 250V | 42569 |
| C73 | 2/10pF | TRIMMER | | 43183 | C135 | not used | | | |
| C74 | 2/10pF | TRIMMER | | 43183 | C136 | .01μF | CE(1) | 250V | 42569 |
| C75 | 27pF | CE(2) | | 22369 | C137 | 220pF | CE(2) | | 22379 |
| C76 | 18pF | CE(2) | | 22367 | C138 | 120pF | CE(2) | | 22377 |
| C77 | 27pF | CE(2) | | 22369 | C139 | | | A.O.T. | |
| C78 | 18pF | CE(2) | | 22367 | C140 | | | A.O.T. | |
| C79 | .01μF | CE(1) | | 22395 | C201 | .01μF | CE(1) | 250V | 42569 |
| C80 | .01μF | CE(1) | | 22395 | C202 | 5.6pF | CE(2) | | 22361 |
| C81 | 5600pF | CE(1) | | 22394 | C203 | 22μF | E | 25V | 32181 |
| C82 | 5600pF | CE(1) | | 22394 | C204 | .01μF | CE(1) | 250V | 42569 |
| C83 | 15pF | CE(2) | | 22366 | C205 | .01μF | CE(1) | 250V | 42569 |
| C84 | 15pF | CE(2) | | 22366 | C206 | .01μF | CE(1) | 250V | 42569 |
| C87 | 2.7pF | CE(3) | | 36599 | C207 | 5.6pF | CE(2) | A.O.T. | 22361 |
| C88 | 2.7pF | CE(3) | | 36599 | C208 | .01μF | CE(1) | 250V | 42569 |
| C89 | 12pF | CE(2) | | 22365 | C209 | .01μF | CE(1) | 250V | 42569 |
| C90 | 12pF | CE(2) | | 22365 | C210 | .01μF | CE(1) | 250V | 42569 |
| C91 | 10nF | CE(2) | | 22395 | C211 | 1pF | CE(3) | | 36594 |
| C92 | 10nF | CE(2) | | 22395 | C212 | .01μF | CE(1) | 250V | 42569 |
| C101 | .01μF | CE(1) | 250V | 42569 | C213 | 5.6pF | CE(3) | | 36603 |
| C102 | 5.6pF | CE(2) | | 22361 | C214 | .01μF | CE(1) | 250V | 42569 |
| | | | | | C221 | .01μF | CE(1) | 250V | 42569 |
| | | | | | C222 | not used | | | |

Component List and Illustrations

Section 6

OS3600 'Y' PRE-AMP BEAM SWITCH, 'Y' DRIVER & O/P (Cont)

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|--------------------------|----------|-------------|--------|---------|-------|----------|-------------|--------|----------|
| CAPACITORS (Cont) | | | | | | | | | |
| C223 | 12pF | CE(3) | | 36607 | C407 | 15pF | CE(2) | | 22366 |
| C224 | 330pF | CE(2) | 100V | 43438 | C408 | 1.5/9pF | FT | | 36272 |
| C225 | 4/27pF | FT | | 36273 | C409 | 4/27pF | FT | | 36273 |
| C226 | 1pF | CE(3) | | 36594 | C410 | not used | | | |
| C227 | 1pF | CE(3) | | 36599 | C411 | .01μF | CE(1) | 250V | 22395 |
| C228 | .01μF | CE(1) | 250V | 42569 | C412 | 8.2pF | CE(2) | | 22363 |
| C229 | .01μF | CE(1) | 250V | 42569 | C413 | .01μF | CE(1) | 250V | 22395 |
| C230 | .01μF | CE(1) | 250V | 42569 | C414 | not used | | | |
| C231 | 15pF | CE(2) | | 22366 | C415 | .01μF | CE(1) | 250V | 22395 |
| C232 | 220pF | CE(2) | | 22379 | C416 | .01μF | CE(1) | 250V | 22395 |
| C233 | .01μF | CE(1) | 250V | 42569 | C417 | 33μF | E | 16V | 32173 |
| C234 | .01μF | CE(1) | 250V | 42569 | C418 | .01μF | CE(1) | 250V | 22395 |
| C235 | 220pF | CE(2) | | 22379 | C419 | 5.6pF | CE(2) | | 22361 |
| C236 | .01μF | CE(1) | 250V | 42569 | | | | | |
| C237 | 220pF | CE(2) | | 22379 | C471 | .01μF | CE(1) | 250V | 22395 |
| C238 | 120pF | CE(2) | | 22377 | C472 | .01μF | CE(1) | 250V | 22395 |
| C239 | | A.O.T. | | | C473 | .1μF | CE(1) | 25V | 36709 |
| C240 | | A.O.T. | | | | | | | |
| TRANSISTORS | | | | | | | | | |
| C301 | .01μF | CE(1) | 250V | 42569 | TR101 | AE37 | | | A4/40414 |
| C302 | .01μF | CE(1) | 250 | 42569 | TR102 | BF371 | | | 36275 |
| C303 | 22μF | E | 25V | 32181 | TR103 | MPS H10 | | | 40315 |
| C304 | .01μF | CE(1) | 250V | 42569 | TR104 | BF479 | | | 39270 |
| C305 | 22μF | E | 25V | 32181 | TR105 | BF479 | | | 39270 |
| C306 | .047μF | CE(1) | 10V | 19657 | TR106 | BC212 | | | 29327 |
| C307 | .047μF | CE(1) | 10V | 19657 | TR107 | BC182B | | | 33205 |
| C308 | .047μF | CE(1) | 10V | 19657 | TR108 | BC212 | | | 29327 |
| C309 | .047μF | CE(1) | 10V | 19657 | TR109 | BC212 | | | 29327 |
| C310 | 270pF | CE(2) | | 22380 | TR110 | MPS H10 | | | 40315 |
| C311 | not used | | | | TR111 | MPS H10 | | | 40315 |
| C312 | 560pF | CE(2) | | 22384 | TR112 | BC182B | | | 33205 |
| C313 | 1.5/9pF | FT | | 36272 | | | | | |
| C314 | not used | | | | TR201 | AE37 | | | A4/40414 |
| C315 | 270pF | CE(2) | | 22380 | TR202 | BF371 | | | 36275 |
| C316 | .01μF | CE(2) | 250V | 42569 | TR203 | MPS H10 | | | 40315 |
| | | | | | TR204 | BF479 | | | 39270 |
| C319 | .047μF | CE(1) | 10V | 19657 | TR205 | BF479 | | | 39270 |
| C320 | .047μF | CE(1) | 10V | 19657 | | | | | |
| C321 | 22μF | E | 25V | 32181 | TR210 | MPS H10 | | | 40315 |
| C322 | 5.6pF | CE(2) | | 22361 | TR211 | MPS H10 | | | 40315 |
| C323 | 12pF | CE(3) | 50V | 36607 | TR212 | BC182B | | | 33205 |
| C324 | 330pF | CE(2) | 100V | 43438 | | | | | |
| C325 | 4/27pF | FT | | 36273 | TR303 | BF479 | | | 39270 |
| C326 | 2.2pF | CE(3) | | 36598 | TR304 | BF479 | | | 39270 |
| C327 | 2.2pF | CE(3) | | 36598 | TR305 | BF479 | | | 39270 |
| C328 | 2.2pF | CE(3) | | 36598 | TR306 | BF479 | | | 39270 |
| C329 | 2.2pF | CE(3) | | 36598 | TR307 | BC212 | | | 29327 |
| C330 | 2.2pF | CE(3) | | 36598 | TR308 | BC182B | | | 33205 |
| C331 | 2.2pF | CE(3) | | 36598 | TR309 | 2N5771 | | | 38089 |
| C332 | 5.6pF | CE(2) | | 22361 | TR310 | MPS 2369 | | | 36625 |
| | | | | | TR311 | 2N5771 | | | 38089 |
| C401 | 560pF | CE(2) | | 22384 | TR312 | ZTX326A | | | 41753 |
| C402 | 560pF | CE(2) | | 22384 | | | | | |
| C403 | 560pF | CE(2) | | 22384 | TR401 | BF479 | | | 39270 |
| C404 | 560pF | CE(2) | | 22384 | TR402 | BF479 | | | 39270 |
| C405 | 8.2pF | CE(2) | | 22363 | TR403 | ZTX326A | | | 41753 |
| C406 | 18pF | CE(2) | | 22367 | TR404 | ZTX326A | | | 41753 |


Component List and Illustrations

Section 6

OS3600 'Y' PRE-AMP BEAM SWITCH, 'Y' DRIVER & O/P (Cont)

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|----------------------------|-------|-------------|----------|---------|----------------------|-------|-----------------------|----------|---------|
| TRANSISTORS (Cont) | | | | | | | | | |
| TR405 | | BFY51 | | 29329 | IC301 | | SL2363C | | 42631 |
| TR406 | | BFX88 | | 23337 | IC302 | | SL3145 | | 40784 |
| | | | | | IC303 | | MC10102 | | 39243 |
| | | | | | IC304 | | MC10102 | | 39243 |
| D101 | 3V3 | ZENER | | 33923 | IC305 | | MC10103 | | 40346 |
| D102 | | IN3595 | | 29330 | IC306 | | MC10135 | | 42128 |
| D103 | 3V3 | ZENER | | 33923 | IC307 | | CA 3086 | | 42907 |
| D104 | | IN3595 | | 29330 | | | | | |
| D105 | 8V2 | ZENER | | 33933 | IC402 | | 78L05 | | 40406 |
| D106 | 3V3 | ZENER | | 33923 | IC471 | | OM504 | | 42124 |
| D107 | | IN3595 | | 29330 | | | | | |
| D108 | 4V7 | ZENER | | 33927 | | | | | |
| D109 | 4V7 | ZENER | | 33927 | | | | | |
| D110 | 2V7 | ZENER | | 33921 | | | | | |
| | | | | | MISCELLANEOUS | | | | |
| D201 | 3V3 | ZENER | | 33923 | L101 | | Ferrite Bead FX1242 | | 26986 |
| D202 | | IN3595 | | 29330 | L102 | | Ferrite Bead FX1242 | | 26986 |
| D203 | 3V3 | ZENER | | 33923 | L201 | | Ferrite Bead FX1242 | | 26986 |
| D204 | | IN3595 | | 29330 | L202 | | Ferrite Bead FX1242 | | 26986 |
| D205 | 8V2 | ZENER | | 33933 | L301 | | Ferrite Bead FX1242 | | 26986 |
| D206 | 3V3 | ZENER | | 33923 | L302 | | Ferrite Bead FX1242 | | 26986 |
| D207 | | IN3595 | | 29330 | | | | | |
| D301 | 6V2 | ZENER | | 33930 | L471 | 1μH | Choke | | 41449 |
| D302 | | IN4148 | | 23802 | L472 | 1μH | Choke | | 41449 |
| D303 | | IN4148 | | 23802 | T101 | | Balancing Transformer | A4/43216 | |
| D304 | | IN4148 | | 23802 | T102 | | Balancing Transformer | A4/43216 | |
| D305 | | IN4148 | | 23802 | | | | | |
| D306 | | IN4148 | | 23802 | S7 | | CH1 Uncal | | |
| D307 | | IN4148 | | 23802 | | | Part of R13 | A4/42993 | |
| D308 | | IN4148 | | 23802 | S8 | | CH2 Uncal | | |
| D309 | | IN4148 | | 23802 | | | Part of R14 | A4/42993 | |
| D310 | | IN4148 | | 23802 | S9 | | Attenuator CH1 | 42135 | |
| D311 | | IN4148 | | 23802 | S10 | | Attenuator CH2 | 42136 | |
| D401 | | IN4148 | | 23802 | S11/12 | | AC/DC/GND CH1 | A3/40734 | |
| D402 | 9V1 | ZENER | | 33934 | S13/14 | | AC/DC/GND CH2 | A3/40734 | |
| D403 | | IN4148 | | 23802 | S101 | | Invert CH1 | A3/40742 | |
| D404 | | IN4148 | | 23802 | S201 | | Invert CH2 | A3/40742 | |
| | | | | | S400 | | Trace Locate | A3/40741 | |
| INTEGRATED CIRCUITS | | | | | | | | | |
| IC101 | | LF355BN | | 42050 | PLG | | Molex 2-Way | | 41391 |
| IC102 | | SL360C | | 42126 | PLH | | Molex 4-Way | | 41393 |
| IC103 | | SL2363C | Selected | 42630 | PLJ | | Molex 2-Way | | 41391 |
| IC104 | | SL3145 | | 40784 | PLK | | Molex 3-Way | | 54181 |
| IC105 | | SL3145 | | 40784 | PLL | | Molex 12-Way | | 37879 |
| IC106 | | 4066B | | 40044 | PLM | | Molex 19-Way | | 42502 |
| IC107 | | SL2363C | | 42631 | PLN | | Molex 3-Way | | 41395 |
| IC201 | | LF355BN | | 42050 | SKAA | | Socket BNC 50Ω | | 1222 |
| IC202 | | SL360C | | 42126 | SKBB | | Socket BNC 50Ω | | 1222 |
| IC203 | | SL2363C | Selected | 42630 | | | | | |
| IC204 | | SL3145 | | 40784 | PLNN | | Molex 3-Way | | 37881 |
| IC205 | | SL3145 | | 40784 | PLPP | | Molex 3-Way | | 37881 |
| IC207 | | SL2363C | | 42631 | | | | | |

| | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--------------|------|----------------------|------|--------------|----------------|----------------------|------|------|--------------|--------------|------|--------------|------|--------------|--|--|--|--------------|--|--|--|--|--|---|
| | R186 R190 | R188 | R187 R189 R191 | R303 | R192 R196 | R1366 R1372 | R389 R301 R302 | R346 | R317 | R334 R319 | R322 R318 | R318 | R345 R333 | H300 | R336 R337 | R341 R342 R343 R344 R345 R346 R347 | R348 R349 R350 R351 R352 R353 R354 R355 R356 R357 R358 R359 | R360 R361 R362 R363 R364 R365 R366 R367 R368 R369 R370 R371 R372 R373 R374 R375 R376 R377 R378 R379 R380 R381 R382 R383 R384 R385 R386 R387 R388 R389 R390 R391 R392 R393 R394 R395 R396 R397 R398 R399 R400 | R399 R400 | R401 R402 R403 R404 R405 R406 R407 R408 R409 R410 R411 R412 R413 R414 R415 R416 R417 R418 R419 R420 R421 R422 R423 R424 R425 R426 R427 R428 R429 R430 R431 R432 R433 R434 R435 R436 R437 R438 R439 R440 R441 R442 R443 R444 R445 R446 R447 R448 R449 R450 R451 R452 R453 R454 R455 R456 R457 R458 R459 R460 R461 R462 R463 R464 R465 R466 R467 R468 R469 R470 R471 R472 R473 R474 R475 R476 R477 R478 R479 R480 R481 R482 R483 R484 R485 R486 R487 R488 R489 R490 R491 R492 R493 R494 R495 R496 R497 R498 R499 R500 | R501 R502 R503 R504 R505 R506 R507 R508 R509 R510 R511 R512 R513 R514 R515 R516 R517 R518 R519 R520 R521 R522 R523 R524 R525 R526 R527 R528 R529 R530 R531 R532 R533 R534 R535 R536 R537 R538 R539 R540 R541 R542 R543 R544 R545 R546 R547 R548 R549 R550 R551 R552 R553 R554 R555 R556 R557 R558 R559 R560 R561 R562 R563 R564 R565 R566 R567 R568 R569 R570 R571 R572 R573 R574 R575 R576 R577 R578 R579 R580 R581 R582 R583 R584 R585 R586 R587 R588 R589 R590 R591 R592 R593 R594 R595 R596 R597 R598 R599 R600 | R601 R602 R603 R604 R605 R606 R607 R608 R609 R610 R611 R612 R613 R614 R615 R616 R617 R618 R619 R620 R621 R622 R623 R624 R625 R626 R627 R628 R629 R630 R631 R632 R633 R634 R635 R636 R637 R638 R639 R640 R641 R642 R643 R644 R645 R646 R647 R648 R649 R650 R651 R652 R653 R654 R655 R656 R657 R658 R659 R660 R661 R662 R663 R664 R665 R666 R667 R668 R669 R670 R671 R672 R673 R674 R675 R676 R677 R678 R679 R680 R681 R682 R683 R684 R685 R686 R687 R688 R689 R690 R691 R692 R693 R694 R695 R696 R697 R698 R699 R700 | R701 R702 R703 R704 R705 R706 R707 R708 R709 R710 R711 R712 R713 R714 R715 R716 R717 R718 R719 R720 R721 R722 R723 R724 R725 R726 R727 R728 R729 R730 R731 R732 R733 R734 R735 R736 R737 R738 R739 R740 R741 R742 R743 R744 R745 R746 R747 R748 R749 R750 R751 R752 R753 R754 R755 R756 R757 R758 R759 R760 R761 R762 R763 R764 R765 R766 R767 R768 R769 R770 R771 R772 R773 R774 R775 R776 R777 R778 R779 R780 R781 R782 R783 R784 R785 R786 R787 R788 R789 R790 R791 R792 R793 R794 R795 R796 R797 R798 R799 R800 | R801 R802 R803 R804 R805 R806 R807 R808 R809 R810 R811 R812 R813 R814 R815 R816 R817 R818 R819 R820 R821 R822 R823 R824 R825 R826 R827 R828 R829 R830 R831 R832 R833 R834 R835 R836 R837 R838 R839 R840 R841 R842 R843 R844 R845 R846 R847 R848 R849 R850 R851 R852 R853 R854 R855 R856 R857 R858 R859 R860 R861 R862 R863 R864 R865 R866 R867 R868 R869 R870 R871 R872 R873 R874 R875 R876 R877 R878 R879 R880 R881 R882 R883 R884 R885 R886 R887 R888 R889 R890 R891 R892 R893 R894 R895 R896 R897 R898 R899 R900 | R901 R902 R903 R904 R905 R906 R907 R908 R909 R910 R911 R912 R913 R914 R915 R916 R917 R918 R919 R920 R921 R922 R923 R924 R925 R926 R927 R928 R929 R930 R931 R932 R933 R934 R935 R936 R937 R938 R939 R940 R941 R942 R943 R944 R945 R946 R947 R948 R949 R950 R951 R952 R953 R954 R955 R956 R957 R958 R959 R960 R961 R962 R963 R964 R965 R966 R967 R968 R969 R970 R971 R972 R973 R974 R975 R976 R977 R978 R979 R980 R981 R982 R983 R984 R985 R986 R987 R988 R989 R990 R991 R992 R993 R994 R995 R996 R997 R998 R999 R1000 |
|--|--------------|------|----------------------|------|--------------|----------------|----------------------|------|------|--------------|--------------|------|--------------|------|--------------|--|--|--|--------------|--|--|--|--|--|---|



- PLM12 ● Y MODE SWITCH LOGIC L1 (A00)
- PLM17 ● " " " " L5 (TRIG VIEW)
- PLM13 ● " " " " L2 (CH1)
- PLM16 ● " " " " L6 (ALT XY)
- PLM 9 ● SINGLE TRACE DETECT
- PLM19 ● Y MODE SWITCH LOGIC L4 (S)
- PLM16 ● " " " " L3 (CH2+ADD)
- PLM14 ● " " " " L3 (CH2+ADD)

30L302 (SCR) ALT PULSE
 Y 303, 304 (SCR) CHOP BLANKING

Component List and Illustrations

Section 6

OS3500 POWER SUPPLY

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|------------------|-------|-------------|--------------------|----------|-------------------------|--------|-------------|--------|----------|
| RESISTORS | | | | | RESISTORS (Cont) | | | | |
| R6 | 100k | CF | | 21819 | R1036 | 33k | CF | | 21814 |
| R428 | 150 | CF | | 28719 | R1037 | | | | |
| R429 | 470 | CF | ½W | 18546 | R1038 | | | | |
| R432 | 220k | CF | | 21823 | R1039 | 1M | CF | | 31840 |
| R433 | 6.2M | MG | 5 | 42132 | R1040 | | | | |
| R435 | 1k0 | CP | Scale illumination | A4/38680 | R1041 | 15 | CF | 1W | 19026 |
| R436 | 2k2 | CP | Trace Rotate | A4/38678 | R1042 | 2k7 | MO | | 26728 |
| R437 | 10k | CP | Intensity | A4/33681 | R1043 | 200 | MF | | 38577 |
| R438 | 1M | CP | Focus | A4/38679 | R1044 | 2k | MF | | 38601 |
| R439 | 100k | PCP | Astigmatism | 39269 | R1045 | | | | |
| R440 | 1M | PCP | Geometry | 39431 | R1046 | | | | |
| R444 | 47 | CF | | 28714 | R1047 | 200 | MF | | 38577 |
| R447 | 39k | CF | | 28728 | R1048 | 2k | MF | | 38601 |
| R448 | 82k | *CF | | 21818 | R1049 | 243 | MF | 1 | 36628 |
| R1001 | 2k2 | CF | | 21802 | R1050 | 750 | MF | 1 | 40369 |
| R1002 | 39 | CF | | 28713 | R1051 | 100 | PCP | | 39230 |
| R1003 | 4k7 | MF | | 38610 | R1052 | 100 | PCP | | 39230 |
| R1004 | | | | | R1053 | 1k5 | CF | | 21801 |
| R1005 | 1k2 | MF | | 38596 | R1054 | 5k6 | MF | | 38612 |
| R1006 | | | | | R1055 | 47 | CF | | 28714 |
| R1007 | 10 | CF | | 21793 | R1056 | 18k | MF | | 38624 |
| R1008 | 2k2 | MF | | 38602 | R1057 | 3k6 | MF | | 38607 |
| R1009 | 1k5 | CF | | 21801 | R1058 | 5k6 | MF | | 21806 |
| R1010 | | | | | R1101 | 150 | CF | | 28719 |
| R1011 | 47 | CF | | 28714 | R1102 | 1k | CF | | 21799 |
| R1012 | 18k | CF | | 21811 | R1103 | 68k | CF | | 21816 |
| R1013 | 5k6 | CF | | 21806 | R1104 | | | | |
| R1014 | 5k6 | MF | | 38612 | R1105 | 22k | CF | | 21812 |
| R1015 | | | | | R1106 | 50k | PCP | | 39268 |
| R1016 | 39k | CF | | 28728 | R1107 | | | | |
| R1017 | 100 | CF | | 21794 | R1108 | | | | |
| R1018 | 680 | CF | | 28723 | R1109 | 5k6 | CF | | 21806 |
| R1019 | 36k | MF | | 38631 | R1110 | | | | |
| R1020 | | | | | R1111 | 1k5 | CF | | 21801 |
| R1021 | 1k | CF | | 21799 | R1112 | 220 | CF | | 21796 |
| R1022 | 33k | CF | | 21814 | R1113 | 1k | CF | | 21799 |
| R1023 | 68k | CF | | 21816 | R1114 | 27k | CF | | 21813 |
| R1024 | 33k | CF | | 21814 | R1115 | | | | |
| R1025 | 6k8 | MF | | 38614 | R1116 | | | | |
| R1026 | 100 | CF | | 21794 | R1117 | 100 | CF | | 21794 |
| R1027 | 1k8 | WW | 2½W | 17823 | R1118 | 10k | CF | | 21809 |
| R1028 | | | | | R1119 | 1M | PCP | | 39431 |
| R1029 | 6k8 | MF | | 38614 | R1120 | 10k | CF | | 21809 |
| R1030 | | | | | R1121 | 15M | MG | | 40371 |
| R1031 | 4k7 | MF | | 38610 | R1122 | | | | |
| R1032 | 3k3 | CF | | 21803 | R1123 | 10k | CF | | 21809 |
| R1033 | 10 | CF | | 21793 | R1124 | 2M7 | MG | | 42133 |
| R1034 | | | | | R1125 | 22M | MG | | 40787 |
| R1035 | 33k | CF | | 21814 | R1126 | 27k | CF | | 21813 |
| | | | | | CAPACITORS | | | | |
| | | | | | C1 | 1000µF | E | 100V | A4/40765 |
| | | | | | C2 | 6800µF | E | 25V | A4/40766 |
| | | | | | C3 | 6800µF | E | 25V | A4/40766 |

Component List and Illustrations

Section 6

OS3600 POWER SUPPLY (Cont)

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|--------------------------|--------|-------------|--------|----------|----------------------------|-------|-------------|--------|-------------|
| CAPACITORS (Cont) | | | | | TRANSISTORS (Cont) | | | | |
| C1001 | 10nF | CE(1) | 250V | 22395 | TR1003 | | BC449 | | 42131 |
| C1002 | 10nF | CE(2) | 250V | 22395 | TR1004 | | BC450 | | 42130 |
| C1003 | 68pF | CE(1) | | 22374 | TR1005 | | 2N5771 | | 38089 |
| C1004 | 10nF | CE(1) | 250V | 22395 | TR1006 | | TIP30A | | 38415 |
| C1005 | 10nF | CE(1) | 250V | 22395 | TR1007 | | BC182B | | 33205 |
| C1006 | 22μF | E | 25V | 32181 | | | | | |
| C1007 | 10nF | CE(1) | 250V | 22395 | TR1101 | | BC182B | | 33205 |
| C1008 | 100nF | PE | 100V | 37018 | TR1102 | | BC212 | | 29327 |
| C1009 | 22μF | E | 25V | 32181 | TR1103 | | 2SC1173 | | 36188 |
| C1010 | 100pF | CE(2) | | 22376 | TR1104 | | BC212 | | 29327 |
| C1011 | 10nF | CE(1) | 250V | 22395 | TR1105 | | BC449 | | 42131 |
| C1012 | 10nF | CE(1) | 250V | 22395 | | | | | |
| | | | | | INTEGRATED CIRCUITS | | | | |
| C1014 | 47nF | CE(1) | 4kV | 40562 | IC1001 | | LM317 | | 40731 |
| C1015 | 10nF | PE | 5kV | 37854 | IC1002 | | LM317 | | 40731 |
| C1016 | 220μF | E | 16V | 42757 | IC1003 | | LM317 | | 40731 |
| C1017 | 470μF | E | 63V | 40586 | IC1004 | | μA723 | | 31228 |
| C1018 | | | | | DIODES | | | | |
| C1019 | 220μF | E | 100V | 40587 | D1 | | IN4003 | | 32771 |
| | | | | | D2 | | IN4003 | | 32771 |
| C1021 | 220μF | E | 100V | 40587 | D3 | | IN4003 | | 32771 |
| C1022 | 22μF | E | 25V | 32181 | D4 | | IN4003 | | 32771 |
| C1023 | 22μF | E | 25V | 32181 | D5 | | IN4003 | | 32771 |
| C1024 | | | | | D6 | | IN4003 | | 32771 |
| C1025 | 6800μF | E | 16V | A4/40559 | D7 | | IN4003 | | 32771 |
| C1026 | 22μF | E | 25V | 32181 | D8 | | IN4003 | | 32771 |
| C1027 | 4.7μF | T | 25V | 53249 | D9 | | IN4003 | | 32771 |
| C1028 | 4.7μF | T | 25V | 53249 | D10 | | IN4003 | | 32771 |
| C1029 | 10μF | E | 250V | 42137 | | | | | |
| C1030 | 10μF | E | 250V | 42137 | D401 | | IN4148 | | 23802 |
| C1031 | 10nF | CE(1) | 250V | 22395 | D402 | 9V1 | ZENER | 5 | 400mW 33934 |
| | | | | | | | | | |
| C1101 | 10nF | CE(1) | 250V | 22395 | D1001 | | IN4148 | | 23802 |
| C1102 | 22μF | E | 25V | 32181 | D1002 | | FH1100 | | 40352 |
| C1103 | | | | | D1003 | | FH1100 | | 40352 |
| C1104 | 100nF | PE | 100V | 37018 | D1004 | | FH1100 | | 40352 |
| C1105 | 0.1μF | PE | 250V | 39199 | D1005 | | IN4149 | | 1949 |
| C1106 | 220μF | E | 16V | 42757 | D1006 | | IN4149 | | 1949 |
| C1107 | | | | | D1007 | | IN4148 | | 23802 |
| C1108 | | | | | D1008 | 18V | ZENER | 5 | 400mW 33941 |
| C1109 | 1000pF | CE(1) | 4kV | 44443 | D1009 | | | | |
| C1110 | | | | | D1010 | | IN4003 | | 32771 |
| C1111 | 4700pF | CE(1) | 4kV | 40562 | D1011 | | IN4003 | | 32771 |
| C1112 | 10nF | CE(1) | 250V | 22395 | D1012 | | IN4003 | | 23462 |
| C1113 | 10nF | CE(1) | 500V | 24902 | D1013 | | IN4148 | | 23802 |
| C1114 | 4.7nF | CE(1) | 4kV | 40562 | D1014 | | | | |
| C1115 | 4.7nF | CE(1) | 4kV | 40562 | D1015 | | | | |
| C1116 | 4.7nF | CE(1) | 4kV | 40562 | D1016 | 47V | ZENER | 5 | 400mW 40049 |
| C1117 | 100nF | CE(1) | 25V | 36709 | D1017 | | IN4003 | | 32771 |
| | | | | | D1018 | | IN4003 | | 32771 |
| TRANSISTORS | | | | | D1019 | | | | |
| TR405 | | BFY51 | | 29329 | D1020 | | | | |
| TR406 | | BFX88 | | 23337 | D1021 | | IN4003 | | 32771 |
| TR1001 | | MPS3640 | | 24128 | D1022 | | IN4003 | | 32771 |
| TR1002 | | 2N5771 | | 38089 | | | | | |


Component List and Illustrations

Section 6

053600 POWER SUPPLY (Cont)

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|----------------------|-------|---------------------|--------|------------|-----------------------------|--------------------|----------------------------------|--------|----------|
| DIODES (Cont) | | | | | MISCELLANEOUS (Cont) | | | | |
| D1023 | | IN4003 | | 32771 | T1101 | | EHT Oscillator Trans- former | | A2/41747 |
| D1024 | | | | | | | | | |
| D1025 | | IS923 | | 3560 | | | | | |
| D1026 | | IN4148 | | 23802 | S1 | | Power Switch | | A4/36232 |
| D1027 | | IN4148 | | 23802 | | | | | |
| D1028 | | IN4003 | | 32771 | S15 | | Switch Slider | | |
| D1029 | | IN4003 | | 32771 | | | Supply Volts Selection | | 4069 |
| D1030 | | IN4148 | | 23802 | S16 | | Switch Slider | | |
| | | | | | | | Supply Volts Selection | | 4069 |
| D1101 | | IN4148 | | 23802 | | | | | |
| D1102 | | IN4148 | | 23802 | S400 | | Switch Push Button | | |
| D1103 | | IN4148 | | 23802 | | | Trace Locate | | 40741 |
| D1104 | | IN4148 | | 23802 | | | | | |
| D1105 | | IN4148 | | 23802 | | | | | |
| D1106 | | | | | FS1 | 500mA | Fuse 20mm Slo-Blo 240V Supply | | 33685 |
| D1107 | | BY409 | | 42356 | | 1A | Fuse 20mm Slo-Blo 115V Supply | | 34790 |
| D1108 | | BY409 | | 42356 | | | | | |
| D1109 | | IN4148 | | 23802 | FS1001 | 500mA | Fuse 20mm Slo-Blo | | 33685 |
| D1110 | | | | | | | | | |
| D1111 | | BY409 | | 42356 | PLA | | Plug Molex 8 Way | | 43219 |
| D1112 | | BY409 | | 42356 | PLB | | Plug Molex 9 Way | | 42633 |
| D1113 | | | | | PLC | | Plug Molex 11 Way | | 40323 |
| D1114 | 150V | ZENER | 1.3W | 37559 | PLD | | Plug Molex 8 Way | | 37877 |
| D1115 | | IN4148 | | 23802 | PLF | | Plug Molex 9 Way | | A2/42634 |
| | | | | | PLJ | | Plug Molex 2 Way | | 41391 |
| | | | | | PLK | | Plug Molex 3 Way | | 54181 |
| | | | | | PLL | | Plug Molex 12 Way | | 37879 |
| | | | | | PLQ | | Plug Molex 2 Way LKG | | 41391 |
| MISCELLANEOUS | | | | | | | | | |
| BR1001 | | WO2 | | 19725 | PLMM | | IEC Supply Connector | | 33787 |
| BR1002 | | WO2 | | 19725 | | | | | |
| L1 | | Rotation Coil | | Part of V1 | MPR1 | | EHT Multiplier | | 42452 |
| L5 | | Ferrite Bead FX1242 | | 26986 | V1 | | CRT D14-300GH | | |
| L6 | | Ferrite Bead FX1242 | | 26986 | | | Normal Version | | 42123 |
| L7 | | Ferrite Bead FX1242 | | 26986 | | or D14/300GM/93 or | D14-302GM/93 | | |
| L8 | | Ferrite Bead FX1242 | | 26986 | | | Long Persis- tence Version | | 42451 |
| L3101 | 150μH | | | 35826 | SKGG | | Socket 4mm | Z Mod | 29492 |
| T1 | | Supply Transformer | | A1/41751 | SKHH | | Socket 4mm | 0V | 29492 |

| RESIS | R1044 R1048 R1052 R1051 R1043 R1047 R1041 R1050 R1049 R1058 R1045 R1042 R1032 R1031 R1029 R1027 R1026 R1025 R1024 R1023 R1022 R1021 R1020 R1019 R1018 R1017 R1016 R1015 R1014 R1013 R1012 R1011 R1010 R1009 R1008 R1007 R1006 R1005 R1004 R1003 R1002 R1001 R1000 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------|---|----|-----|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|--------|--------|--------|-------|-------|
| CAP. | C1 | C2 | C3 | C1030 | C1027 | C1028 | C1021 | C1029 | C1022 | C1023 | C1025 | C1017 | C1019 | C1026 | C1016 | C1010 | C1006 | C1009 | C1101 | C1102 | C1007 | C1005 | C1031 | C1008 | C1004 | C1105 | C1011 | C1003 | | | |
| MISC. | S15 | T1 | D10 | D9 | D7 | D4 | D1018 | D1028 | D1029 | D1028 | D1029 | D1010 | D1011 | D1012 | D1016 | D1017 | D1023 | D1008 | D1011 | D1101 | D1104 | D1102 | TR101 | TR104 | TR103 | TR102 | TR1005 | TR1003 | TR1005 | D1026 | D1105 |



| | | | | | | | | | | | | |
|--------|-------------|--------|-------|--------|-------|-------|--------|-------|--------|-------|-------|-------|
| R1025 | R1019 R1017 | R1053 | R1011 | R1012 | R1007 | R1002 | R1003 | R1013 | R1001 | R444 | R437 | R440 |
| R1111 | R1021 | R1018 | R1022 | R1117 | R1008 | R1014 | R1005 | R1038 | R1125 | R429 | R438 | R433 |
| | R1112 R1113 | R1009 | | | R1039 | R1121 | R1123 | R1037 | R1120 | R436 | R447 | R436 |
| | | | | | R1118 | R1119 | R1126 | R1036 | | | R439 | R448 |
| | | | | | R1119 | | | R1035 | | | R448 | R432 |
| C1011 | C1003 | | C1109 | C1001 | | | C1002 | C1012 | C1011 | C79 | C80 | |
| C1106 | | | C1112 | C1111 | | | C1115 | C1116 | C1014 | | | |
| TR1004 | D1026 | TR1002 | D1007 | D1006 | D1004 | D1107 | TR1001 | D1111 | D1112 | D1002 | D1001 | D1005 |
| TR1003 | D1027 | TR1103 | T1101 | D1108 | D1104 | D1109 | D1003 | D1115 | TR1105 | D1114 | D1025 | |
| TR1005 | D1105 | | D1030 | TR1104 | | | | | | | L5 | D402 |
| | | | | | | | | | | | | S400 |
| | | | | | | | | | | | | D401 |
| | | | | | | | | | | | | V1 |
| | | | | | | | | | | | | TR406 |
| | | | | | | | | | | | | L1 |
| | | | | | | | | | | | | L7 |
| | | | | | | | | | | | | L8 |




Fig. 10 Power Supply Circuit Diagram

Component List and Illustrations


Section 6

OS3600 INTERCONNECTIONS


| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No | |
|-------------------|--------|----------------------|----------|----------|------------------------|---------------|--------------------------|----------------------|----------|----------|
| RESISTORS | | | | | SWITCHES (Cont) | | | | | |
| R2 | 10k | CP X Shift Coarse | } | A4/38689 | S3 | | Switch "A" T/Base Range | | 38686 | |
| R3 | 10k | CP X Shift Fine | | | S4 | | Switch "B" " " | | 38687 | |
| R4 | 10k | CP Trace Sep. | | | A4/38673 | S5 | | Switch "A" Uncal | | |
| R5 | 5k | CP Delay | | | A4/38635 | | | Part of R7 | | A4/38675 |
| R6 | 100k | CF | | | 21819 | S6 | | Switch "B" Uncal | | |
| R7 | 10k | CP A Var Vel | | | A4/38675 | | | Part of R8 | | A4/38675 |
| R8 | 10k | CP B Var Vel | | | A4/38675 | DIODES | | | | |
| R9 | 2k2 | CF | | | 21802 | D11 | | L.E.D. | | 39884 |
| R10 | 2k2 | CF | | | 21802 | D12 | | L.E.D. | | 39884 |
| R11 | 4k7 | | | | A4/42203 | D13 | | L.E.D. | | 39884 |
| R12 | 4k7 | | A4/42203 | D14 | | L.E.D. | | 39884 | | |
| R15 | 1k1 | MF | 0.5 | 41784 | D15 | | L.E.D. | | 39884 | |
| R21 | | Resistor Network | | A3/40102 | D16 | | L.E.D. | | 39884 | |
| R22 | | Resistor Network | | A3/40103 | D17 | | L.E.D. | | 39884 | |
| R25 | 22 | CF | | 28710 | LAMPS | | | | | |
| R26 | 22 | CF | | 28710 | LP1 | 12V | Lamp | | 40328 | |
| R28 | 100 | CF | | 21794 | LP2 | 12V | Lamp | | 40328 | |
| R36 | 10 | CF | | 21793 | MISCELLANEOUS | | | | | |
| R37 | 10 | CF | | 21793 | V ₁ | | CRT D14-300 GH | | | |
| R38 | 47 | CF | | 28714 | | OR | Normal Version | | 42123 | |
| R39 | 47 | CF | | 28714 | | | D14 300 GM | | | |
| CAPACITORS | | | | | | | Long Persistence Version | | 42451 | |
| C79 | 0.01μF | CE(1) | 250V | 22395 | MPR1 | | EHT Multiplier | | 42452 | |
| C80 | 0.01μF | CE(1) | 250V | 22395 | PLZ | | Plug Molex 13 Way | | 39387 | |
| L1 | | Rotation Coil | | | PLMM | | IEC Supply Connector | | 33787 | |
| | | Part of V1 | | - | SKAA | | Socket BNC | | | |
| L2 | | Delay Line | | 42647 | SKBB | | Socket BNC | Y ₁ Input | 1222 | |
| L5 | | Ferrite Bead FX1242 | | 26986 | SKCC | | Socket BNC | Y ₂ Input | 1222 | |
| L6 | | Ferrite Bead FX1242 | | 26986 | SKDD | | Socket BNC | Ext X "A" Input | 1222 | |
| L7 | | Ferrite Bead FX1242 | | 26986 | SKEE | | Terminal Feedthru | Ext X "B" Input | 1222 | |
| L8 | | Ferrite Bead FX1242 | | 26986 | SKEE | | Terminal Feedthru | Cal Signal | 31229 | |
| L9 | | Ferrite Ring | | | SKFF | | Terminal 4mm | Earth | A3/40833 | |
| | | Part of Coax Cable | | | SKGG | | Socket 4mm | Z Mod | 29492 | |
| | | P/No 43415 | | | SKHH | | Socket 4mm | 0V | 29492 | |
| L10 | | Ferrite Ring | | | SKJJ | | Socket BNC | "A" Ramp O/P | 1222 | |
| | | Part of Coax Cable | | | SKKK | | Socket BNC | "B" Ramp O/P | 1222 | |
| | | P/No 43413 | | | CABLEFORMS | | | | | |
| L11 | | Ferrite Ring | | | C/FORM | | | | | |
| | | Part of Coax Cable | | | A | | Y Amp Supply | | A3/42385 | |
| | | P/No 43414 | | | B | | Trigger Amp Supply | | A3/42644 | |
| L12 | | Ferrite Ring | | | SWITCHES | | | | | |
| | | Part of C/Form Cable | | | S2 | | Switch PULL X10 | | | |
| | | P/No A3/43660 | | | | | Part of R2 + R3 | | A4/38689 | |

OS3600 INTERCONNECTIONS (Cont)

| Ref | Value | Description | Tol %± | Part No | Ref | Value | Description | Tol %± | Part No |
|--------------------------|-------|---------------------|--------|----------|-----|-------|--------------------------|--------|----------|
| CABLEFORMS (Cont) | | | | | | | | | |
| C | | Trigger View Signal | | A3/43660 | J | | EHT & Y Output | | A2/42388 |
| D | | Timebase Supply | | A3/42387 | | | Driver Supply | | |
| E | | A Timebase Controls | | A3/41799 | K | | Scale Illumination | | A3/41804 |
| F | | B Timebase Controls | | A3/41800 | L | | Power Indicator | | A4/41805 |
| G | | DVM Shorting Socket | | | M | | C.R.T. Supply | | A3/42386 |
| | | Use where No DIM | | A4/41801 | P | | Y ₁ Uncal LED | | A3/43659 |
| | | Fitted | | | Q | | Y ₂ Uncal LED | | A3/43659 |



| | | | | | | | | | | | |
|-------|---------|------------|------------|----------------|------------|--------------|-----|------|-----|----|----|
| | R28 | | R36 R37 | | R25 R26 | R38 R39 | R21 | | R15 | | R5 |
| MISC. | LP1 LP2 | D11 | L1 | | D17 | S3bF S3bB | | | L8 | L7 | |
| | | L2 D15 D16 | | L10 L9 L11 L12 | | | | S3aF | D14 | | |



| | | | | | | | | |
|----|----|-----|----|-----|-----|----|-----|------|
| R5 | R9 | R6 | R4 | R10 | R8 | R2 | R3 | R22 |
| L7 | S5 | D12 | V1 | L6 | C80 | L5 | C79 | S6 |
| | | | | | | | | D13 |
| | | | | | | | | S4aF |
| | | | | | | | | S4aB |
| | | | | | | | | S2 |




Fig. 11 Interconnections Circuit Diagram




Fig. 12 Component Location Top Left View




Fig. 13 Component Location Top Right View




Fig. 14 Component Location Bottom View



Component List and Illustrations

Section 6

| Item No. | Pt. No. | Description | Qty. | Item No. | Pt. No. | Description | Qty. |
|----------|---------|--------------------------------|------|----------|---------|---|------|
| 1 | 42282 | Panel Front Composite | 1 | 31 | 39097 | Block Indexing | 2 |
| 2 | 40674 | Panel Rear | 1 | 32 | 40677 | Spacer to Bracket Assy. | 2 |
| 3 | 42898 | Side Support Bar | 2 | 33 | 40676 | Spacer to Bracket Assy. | 2 |
| 4 | 39096 | Corner Frame | 4 | 34 | 29206 | Spring | 2 |
| 5 | 40809 | Bracket Support E.H.T. C.R.T. | 1 | 35 | 32626 | Circlip | 2 |
| 6 | 39101 | Foot-Rear Support Moulding | 2 | 36 | 40726 | M3 Spacer | 4 |
| 7 | 43757 | Handle Assy. | 1 | 37 | 38006 | Fuse Holder | 1 |
| 8 | 43208 | Panel Attenuator | 1 | 38 | 33685 | Fuse Pt. No. 33685 500mA | 2 |
| 9 | 42382 | Heatsink | 1 | | 34790 | Fuse Pt. No. 34790 1A | |
| 10 | 42384 | Mounting Bracket | 1 | 39 | 40814 | Filter Blue (Pt. No. 41381 Filter Amber) | 1 |
| 11 | 40829 | Bracket P.C.B. Support | 1 | | | | |
| 12 | 42355 | Bracket P.C.B. Support | 1 | 40 | 41764 | M4 x 10 Hex. Hd. St. Cad. Plate | 2 |
| 13 | 40806 | Bracket Pot. Mounting | 1 | | | | |
| 14 | 43202 | Bracket (Etx. X Atten. P.C.B.) | 1 | 41 | | | |
| 15 | 43209 | Screen Attenuator | 2 | 42 | | | |
| 16 | 39100 | Bezel | 1 | 43 | 40836 | Knob P/B Light Brown | 11 |
| 17 | 41822 | Screen (Timebase/C.R.T.) | 1 | 44 | 38407 | Knob P/B Dark Brown | 25 |
| 18 | 43074 | Support Plate Front | 1 | 45 | 39884 | L.E.D. | 7 |
| 19 | 43075 | Support Plate Rear | 1 | 46 | 1222 | B.N.C. Socket | 6 |
| 20 | 39916 | Trim Side Rear | 2 | 47 | 31229 | Insert Feed Through | 1 |
| 21 | 39915 | Trim Side Front | 2 | 48 | 36851 | Dial Counting Knob | 1 |
| 22 | 40844 | Cover Rear | 1 | 49 | 40408 | Knob R2-234 | 4 |
| 23 | 40813 | Cover Bottom | 1 | 50 | 49635 | M4 Ø Bush | 2 |
| 24 | 40812 | Cover Top | 1 | 51 | 40923 | Knob R2-354 | 5 |
| 25 | 41002 | Screen (Trigger) | 1 | 52 | 40410 | Knob (Wing) R4-454 | 4 |
| 26 | 40808 | Screen E.H.T. | 1 | 53 | 41812 | Nut Cover D/P W7-219 | 2 |
| 27 | 42376 | Transformer Shield | 1 | 54 | 40925 | Knob R2-124 | 1 |
| 28 | 40641 | Foot Bottom Cover | 4 | 55 | 40922 | Knob R2-324 | 4 |
| 29 | 37864 | Latch | 8 | 56 | 43256 | Bezel - Pushbutton | 36 |
| 30 | 37915 | 'O' Ring | 8 | 57 | 40833 | Terminal 4mm Earth | 1 |

For serial Nos. from 5000 the following items have new part Nos.

| | | |
|----|---------|---|
| 1 | 44421 | Panel Front Composite |
| 2 | 44416 | Panel Rear |
| 3 | 44453 | Side Support Bar |
| 4 | 44412 | Corner Frame |
| 5 | 44529 | Bracket Support E.H.T. C.R.T. |
| 6 | 44413 | Foot Rear Support Moulding |
| 16 | 44405 | Bezel |
| 23 | 44943 | Cover Bottom |
| 24 | 44941 | Cover Top |
| 28 | 44528 | Foot Bottom Cover |
| 29 | Deleted | |
| 30 | Deleted | |
| 39 | 44481 | Filter Blue (Pt. No. 44482 Filter Amber) |






Fig. 15 Mechanical Assembly

This instrument is guaranteed for a period of two years from its delivery to the purchaser, covering faulty workmanship and replacement of defective parts other than cathode ray tubes and batteries (where fitted). Cathode ray tubes are subject to the manufacturers guarantee. This assumes fair wear and tear and usage in the specified environment and does not cover routine recalibrations and mechanical adjustments.

We maintain comprehensive after sales facilities and the instrument should be returned to our factory for servicing if this is necessary. The type and serial number of the instrument should always be quoted, together with full details of any fault and service required.

Equipment returned for servicing must be adequately packed, preferably in the box in which the instrument was supplied and shipped with transportation charges

Service Dept.,
Rothrock Road,
Hamault,
Essex,
UG6 3UE

Tel: 01-500 1000

Telex: 263785

Telegrams: Attenuate Ilford

prepaid. We accept no responsibility for instruments arriving damaged. Should the cause of failure during the guarantee period be due to misuse or abuse of the instrument, or if the guarantee has expired the repair will be put in hand without delay and charged unless other instructions are received.

Our Sales, Service and Engineering Departments are ready to assist you at all times.

The Service Department can provide maintenance and repair information by telephone or letter, if required.

Note: Please check fuses before returning instruments for service and ensure that any 13 Amp mains plugs fitted are removed. To prevent possible transit damage, we regret that mains plugs cannot be returned.